



PART 1

IMPORTANT PRODUCT INFORMATION

Safety Information



This symbol is to alert you to important operating or servicing instructions that may appear in this user's manual. Always follow basic safety precautions when using this product to reduce the risk of injury, fire, or electric shock.

- 1 Read and understand all instructions in the user's manual. Observe all markings on the product.**
- 2 During thunderstorms, avoid using telephones except cordless models.** There may be a slight chance of electric shock from lightning.
- 3 Do not use a telephone in the vicinity of a gas leak.** If you suspect a gas leak, report it immediately, but use a telephone away from the area where gas is leaking. If this product is a cordless model, make sure the base is also away from the area.
- 4 Do not use this product near water, or when you are wet.** For example, do not use it in a wet basement or shower, or next to a swimming pool, bathtub, kitchen sink, or laundry tub. Do not use liquids or aerosol sprays for cleaning. If the product comes in contact with any liquids, unplug any line or power cord immediately. Do not plug the product back in until it has dried thoroughly.
- 5 Install this product in a protected location** where no one can trip over any line or power cord. Protect cords from damage or abrasion.
- 6 If this product does not operate normally, read "In Case of Difficulty" in the user's manual.** If you cannot solve the problem, or if the product is damaged, refer to the Limited Warranty. Do not open this product except

(Continued)

as may be directed in your user's manual. Opening the product or reassembling it incorrectly may expose you to hazardous voltages or other risks.

7 If this product has user replaceable batteries, replace batteries only as described in your user's manual. Do not burn or puncture batteries — they contain caustic chemicals.

8 If this product has a three-prong (grounding) plug or a polarized plug with one wide prong, it may not fit in non-polarized outlets. Do not defeat the purpose of these plugs. If they do not fit in your outlet, the outlet should be replaced by an electrician.



CAUTION: Use only the power adapter provided with this product. To obtain a replacement, call 1 800 722-9125.

SAVE THESE INSTRUCTIONS

Especially About Cordless Telephones

Privacy: The same features that make a cordless phone convenient create some limitations. Telephone calls are transmitted between the base and the handset by radio waves, so there is a possibility that your cordless phone conversations could be intercepted by radio receiving equipment within range of the cordless handset. **For this reason, you should not think of cordless phone conversations as being as private as those on corded phones.**

Electrical Power: The base unit of this cordless telephone must be connected to a working electrical outlet. The electrical outlet should not be controlled by a wall switch. **Calls cannot be made from the handset if the base unit is unplugged or switched off, or if the electrical power is interrupted.**

Potential TV Interference: Some cordless telephones operate at frequencies that may cause interference to TVs and VCRs. To minimize or prevent such interference, do not place the base unit of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference. (Applies to 25 channel cordless phones only.)

Rechargeable Batteries: This product contains either Nickel-Cadmium or Nickel-Metal Hydride rechargeable batteries.

Nickel-Cadmium Rechargeable Batteries: Must be recycled or disposed of properly. Do not dispose of in household garbage. Do not burn or puncture. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.



The RBRC™ Seal means that the manufacturer is voluntarily participating in an industry program to collect and recycle Nickel-Cadmium rechargeable batteries when taken out of service within the United States. These batteries may be taken to a participating local retailer of replacement batteries or recycling center. Or you may call 1 800 8BATTERY for locations accepting spent Nickel-Cadmium Batteries.

Nickel-Metal Hydride Rechargeable Batteries: Dispose of these batteries in a safe manner. Do not burn or puncture. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.

Precautions for Users of Implanted Cardiac Pacemakers

Cardiac Pacemakers (applies only to 900 MHz Digital Cordless Telephones):

"Wireless Technology Research, LLC (WTR), an independent research entity led a multidisciplinary evaluation of the interference between portable wireless telephones and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR had recommended to physicians that:

PACEMAKER PATIENTS

- Should keep wireless phones at least 6 inches from the pacemaker
- Should **NOT** place wireless phones directly over the pacemaker, such as in a breast pocket, when it is turned ON
- Should use the wireless phone at the ear opposite the pacemaker

"WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless phones."

Especially About Telephone Answering Systems

Two-Way Recording: This unit does not sound warning beeps to let the other party know that the call is being recorded. To ensure that you are in compliance with any federal or state regulations regarding recording a telephone call, you should start the recording process and then inform your caller that you are recording the call.

FCC Registration and Repair Information

This telephone product has been registered with the Federal Communications Commission (FCC) in accordance with Part 68 of its rules. The FCC requires us to tell you the following information.

1 Connection and use with the nationwide telephone network

An FCC compliant telephone cord and modular plug is provided with this product. This product is designed to be connected to the telephone network or premises wiring using a compatible modular jack which is Part 68 compliant. See Installation Instructions in the user's manual.

This equipment may not be used with Coin Telephone Lines or with Party Lines.

2 Notification to the telephone company

Upon request of your local telephone company, you are required to provide them with the following information:

- a The "line" to which you will connect the telephone equipment (that is, your phone number), and
- b The telephone equipment's FCC registration number and ringer equivalence number (REN). These numbers are on the back or bottom of your telephone equipment.

The REN is useful to determine how many devices you may connect to your telephone line and still have them ring when you are called. In most, but not all areas, the sum of all RENs should be 5 or less. You may want to contact your local telephone company for more information.

3 Repair instructions

If it is determined that your telephone equipment is malfunctioning, the FCC requires that it not be used and that it be unplugged from the modular jack until the

problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents or by others who may be authorized by the FCC. For repair procedures, follow the instructions outlined under the Limited Warranty.

4 Rights of the telephone company

If this telephone product is causing harm to the telephone network, the telephone company may temporarily discontinue your telephone service. If possible, the telephone company will notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible.

You will be given the opportunity to correct the problem and you will be informed of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. If such changes are planned, you will be notified.

5 This telephone is compatible with inductively coupled hearing aids. *(NOTE: This applies only if this product is equipped with a corded or cordless handset.)*

6 Programming/testing of emergency numbers

If this product has memory dialing locations, you may choose to store police, fire department and emergency medical service telephone numbers in these locations. If you do, please keep three things in mind:

- a** We recommend that you also write the telephone number on the directory card, so that you can still dial the emergency number manually if the memory dialing feature doesn't work.
- b** This feature is provided only as a convenience, and the manufacturer assumes no responsibility for customer reliance upon the memory feature.
- c** Testing the emergency telephone numbers you have stored is not recommended. However, if you do make a call to an emergency number:
 - You must remain on the line and briefly explain the reason for the call before hanging up.
 - Programming/testing of emergency numbers should be performed during off-peak hours, such as in the early morning or late evening, when the emergency services tend to be less busy.

Interference Information: Part 15 of FCC Rules

Some telephone equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used properly, may cause interference to radio and television reception.

This product has been tested and found to meet the standards for a Class B digital device, as specified in Part 15 of the FCC Rules. These specifications are designed to provide against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

If this product causes interference to radio, VCR or television reception when it's in use, you might correct the interference with any one or all of these measures:

- Where it can be done safely, re-orient the receiving television, VCR or radio antenna.
- To the extent possible, relocate the television, VCR, radio, or other receiver with respect to the telephone equipment.
- If this telephone product runs on AC power, plug your product into an AC outlet that's not on the same circuit as one used by your radio, VCR or television.

Modifications to this product, not expressly approved by the manufacturer, could void the user's authority to operate the equipment.

Limited Warranty

YOU MAY HAVE GREATER RIGHTS PROVIDED UNDER LOCAL LAW THAN PROVIDED BY THIS WARRANTY. FOR EXAMPLE, IN BRAZIL, LOCAL LAW DOES PROVIDE GREATER RIGHTS DURING THE FIRST 90 DAYS OF THE WARRANTY.

1 What Does This Limited Warranty Cover?

Lucent Technologies Consumer Products L.P. ("Lucent") warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the product and all accessories provided by Lucent in the sales package ("Product") are free from material defects in material and workmanship, under normal installation and use in accordance with operation instructions and pursuant to the following terms and conditions. This limited warranty extends only to the Consumer for Products purchased and used in original country of purchase, provided that country is one of the following: the United States of America, Canada, Puerto Rico, the Virgin Islands, the Caribbean, Mexico and countries in South America, respectively ("Territory").

2 How Long Is The Limited Warranty Period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase, or in the country of Mexico only, the date of receipt of the Product, as documented by a valid proof of purchase (see 6 below).

3 What Will Lucent Do If The Product Is Not Free From Material Defects In Materials and Workmanship During The Limited Warranty Period ("Materially Defective Product")?

During the limited warranty period, Lucent's authorized service representative will repair or replace without charge for parts or labor, at Lucent's option, a Materially Defective Product, with new or refurbished parts or a new or refurbished, same or similar Product, and return such repaired or replaced Product to the Consumer in working condition. Lucent will retain defective parts, modules, or equipment. Repaired or replaced Product will be covered by this limited warranty for the greater of either (a) 90 days from the date the repaired or replaced Product is shipped back to the Consumer or (b) the time remaining under the original limited warranty. Repair or replacement of Product, at Lucent's option, is your exclusive remedy. In Venezuela only: if the repair or replacement cannot be satisfactorily made, then Lucent Technologies Consumer Products L.P. will

reimburse the cost of the Product upon receipt of the Product. The repair or replacement is expected to take approximately 30 days.

4 What Is Not Covered By This Limited Warranty?

This limited warranty does not cover:

- a** Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
- b** Product that has been damaged due to repair, alteration, or modification by anyone other than an authorized service representative of Lucent, or
- c** Product to the extent that the problem experienced is caused by signal conditions, network reliability or cable or antenna systems; or
- d** Product to the extent that the problem is caused by use with non-Lucent electrical accessories; or
- e** Product whose warranty/quality stickers, product serial numbers plates or electronic serial numbers have been removed, altered or rendered illegible; or
- f** Product purchased, used, serviced, or shipped for repair from outside the Territory, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
- g** Product returned without valid proof of purchase (see 6 below); or
- h** charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

5 How Do You Get Warranty Service?

To obtain warranty service in the United States of America, Canada, Puerto Rico, the Caribbean or the Virgin Islands, call 1 800 722-9125 for instructions regarding where to return the Product.

To obtain service in Mexico or South America, contact a Lucent local dealer or retailer for instruction. Before calling for service, please check the user's manual. A check of the Product controls and features may save you a service call.

Except as provided by applicable law, Consumer is responsible for transportation, delivery or handling charges incurred in the transport of Product(s) to the service location. Lucent will return repaired or replaced Product under this limited warranty to the Consumer, transportation, delivery or handling charges prepaid. In Columbia, Venezuela and Mexico only: Lucent Technologies Consumer Products L.P. will reimburse

the reasonable costs of transportation, delivery or handling charges incurred by the consumer.

Lucent assumes no risk for damage or loss of the Product in transit.

If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, Consumer will be notified and Lucent will request authorization for the cost of repair for any further repair activity. Consumer must pay for the cost of repair and return shipping costs for Products repaired that are not covered by this limited warranty.

6 What Will You Be Required To Return With The Product To Get Warranty Service?

You will be required to

- a** return the entire original package and contents including the Product to the Lucent service location along with a description of the malfunction or difficulty; and
- b** include "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model and Electronic Serial Number, if applicable) and the date of purchase or receipt.

7 Other Limitations; This Warranty Is The Entire Agreement.

THERE ARE NO OTHER EXPRESS WARRANTIES. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED TO THE EXTENT LOCAL LAWS ALLOW DISCLAIMERS. IF NO DISCLAIMER IS ALLOWED, THE IMPLIED WARRANTIES ARE LIMITED IN TIME TO THE DURATION OF THIS LIMITED WARRANTY. Local law may not allow limitations of implied warranties, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state, province to province, or country to country.

LUCENT'S TOTAL LIABILITY FOR DAMAGES RELATING TO OR ARISING OUT OF THE USE OF THE PRODUCT, REGARDLESS OF THE TYPE OR CAUSE OF SUCH DAMAGE, SHALL NOT EXCEED THE ORIGINAL PURCHASE PRICE PAID FOR THE PRODUCT.

IN NO EVENT SHALL LUCENT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR SIMILAR DAMAGES (INCLUDING BUT NOT LIMITED TO LOST PROFITS OR REVENUE, INABILITY

TO USE THE PRODUCT OR OTHER ASSOCIATED EQUIPMENT, COST OF SUBSTITUTE EQUIPMENT, AND CLAIMS BY THIRD PARTIES) RESULTING FROM USE OF THE PRODUCT. SOME STATES OR COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF DAMAGES ANY OR ALL OF THESE DAMAGES; THEREFORE THE FOREGOING LIMITATIONS MAY NOT APPLY TO YOU.

Unless modified by a written agreement signed by Lucent, this limited warranty represents the complete and exclusive agreement between Consumer and Lucent with respect to the Product, superseding all prior agreements between the parties, oral or written, and all other communications between the parties relating to the subject matter of this limited warranty. No carrier, retailer, agent, dealer, employee thereof, or employee of Lucent is authorized to make modifications to this limited warranty and you should not rely on any such representation.

© 1999 Lucent Technologies Consumer Products L.P.

All Rights Reserved.

Printed in Mexico. 848232658 Issue 2AT&T