

INSTRUCTIONS

WIRELESS TRANSMITTER

POWER ON

Hold the Power button for a few seconds and it will light up blue to indicate powering on.

POWER OFF

Hold the Power button for a few seconds and it will light up red to indicate powering off.

PAIRING

1. Once the transmitter is turned on, wait 10 seconds or so and it should start to blink alternating red and blue.
2. Place your Bluetooth device (earbuds/headphones/speaker) into pairing mode. See your device manual for instruction on how to do this.
3. After both devices are in pairing mode, they should automatically pair together. Once they are paired, the transmitter power button will stay blue.
4. The pairing process can take up to 30 seconds or more. If unsuccessful, turn off both devices and start over.
5. Connect the transmitter and the audio source device with the 3.5mm AUX cable.

The transmitter that was previously paired, will automatically connect with the device, if the device is powered on and within connecting range.



DISCONNECT

Press the Power button to disconnect the transmitter with your wireless device. Press again to re-connect.

CHARGING

The indicator will turn red while charging and turn off while fully charged. When the battery is low, the indicator will flash red every minute until the transmitter is charged or the battery is exhausted.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

WARNING! Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio / TV technician for help

Technical Specification:

- Operating range: 10 m
- Battery capacity: 250 mAh
- Working time: 6 hours
- Charging time: 3 hours
- Includes a 3.5 mm AUX cable and a Micro-USB cable

