



User Manual

Package Contents




Connection Interface



Installation Steps

- 01 Connect the TV Box with the power supply .
- 02 Connect the TV Box to the TV with an HD cable or AV cable.
- 03 For a wired connection, plug in Ethernet cable from the TV Box to your modem or router. For wireless, choose your Wi-Fi network and input the Wi-Fi password.

Multi-screen Interaction



The Screen Casting

Introduction:
The TV Box lets you play photos, music and videos from smart phone or tablet computer on TV.

Preparation:
Make sure your device (s) and TV Box are connected to the same network.

How to use:
After your device (s) and TV Box are connected to the same network, the logo  will show up in the related applications of your device (s). Click the  and share the photos, music and videos on TV.

Key Features

- Rockchip RK3566** CPU:Quad-core Cortex-A55 up to 1.8GHz. GPU:Mali-G52 GPU.Support OpenGL ES 1.1/2.0/3.2, OpenCL 2.0, Vulkan 1.1, Embedded high-performance 2D acceleration hardware.
- 8K** Video Decoder: H.265 HEVC/MVC Main10 Profile yuv420 @L5.1 up to 4096x2304@60fps. JPEG Encoder: up to 8192x8192.
- Wi-Fi** RAM 4GB/8GB: 100/1000M Ethernet, 802.11b/g/n/ac 2.4G and 5GWiFi, Support BT.
- OS** Android 11 OS, OTA upgrade supported.
- NPU** Support 8M ISP.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.