

X16PRO Wireless Earbuds User Manual



Button Function

1. Power on: Pick up the earbuds from the charging case. The earbuds will power on automatically or long press Touch button for 3 seconds.
2. Power off: Put it into the charging case to automatically power off or long press touch button for 5 seconds until red light flashes.
3. Play/Pause: Click one of the earbuds touch buttons during play to pause, and click touch buttons Replay during pause.
4. Answer/hangup call: Click one of the earbuds touch buttons to answer the call, To end the call click one of the earbudst touch buttons.
5. Reject the call: Long press touch button for 1 second in the coming call.
6. Increase the volume: double click right earbuds when the mobile phone is connected.
7. Turn Down the volume: double click left earbuds when the mobile phone is connected.
8. Previous song: three click left earbuds when connected to mobile phone
9. Next song: three click right earbuds connected to mobile phone
10. Wake up siri :Long press touch button 2 seconds in connecting state to activate siri.
11. Switch mode: consecutive Click touch button 4 times, and there are voice prompts to switch game mode and music mode.

Pairing & Connection

1. Pick up the earbuds from the charging case, the earbuds will auto-power on and auto-pairing in 5 -10 seconds waiting. The red light and blue light flash quickly, and then the red light and blue light flash slowly. Both earbuds have been paired successfully.
2. Turn on the Wireless function on your device and search for X16, and click it to connect. After successfully connecting the phone, the earbuds

indicator off.

3. Put in the earbuds to the charger case and the earbuds will auto-power off and start to charge.

4. To use it again, please pick up the earbuds from the charger case and it will auto-power on and auto-reconnect with your mobile phone.

Charging Overview

In charge: Red light always on

Charging full: No light

Product specifications

Mode	X16PRO
Wireless Version	V5.2+EDR
Music time	4-5hous
Talk time	4-5 hours
Power display	Support
Profiles Supported	A2DP/HFP/HSP/AVRCP
The weight of earphone	2.8g
Headphone battery capacity	30mAh
Charging case battery capacity	200mAh
Earphone Charging time	About 40 min
Charging case charging time	1.5H
Transmission distance	15M

Note: Product parameters will vary depending on model, usage, environment, etc.

Precautions

1. The earphones should be stored in a dry and ventilated environment. to avoid oil water moisture and dust affecting product performance.
2. Avoid using stimulus, organic solvents or items containing these ingredients to clean the earphones.
3. The use of earphones should be correct as per the specification, pay attention to using the influence of the environment on the earphones. In order to ensure a smooth connection, it's recommended that the distance between the earphones and phones is within 10 meters.
4. If the earphones fail to connect or with poor connection, please do not take apart the earphones or the accessories on your own. Otherwise, no warrant.
5. To charge the charging case, please use the standard charger or the charger that meets the requirements.
6. In order to ensure normal use, please ensure sufficient power of the earphones.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.

- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.