

User manual

There are four keys on the product, and each key stands for a sole code with the carrier of 315MHZ.

For example:

If you press k1 button, the transmitter will transmit a serial code with the carrier of 315MHZ, and it is sole, we called it channel 1. and at the same time, the receiver which have the same code with the transmitter, received the code, it will take some action, just for example, control the relay, led, beep, and so on.

K2 stands for channel 2, and has the same usage with K1 which describe above.

And so do k3, k4...

Product Description

Name of EUT: Remote Control

Model No.: T183-315

Power supply: DC3.0V from battery

Operation frequency: 315.0MHz

Channel number: 1

Antenna type: Integral Antenna

Antenna gain: 0dBi

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.