

CORSAIR

M75 WIRELESS

FPS Gaming Mouse

CHARGING THE MOUSE

IMPORTANT: The M75 WIRELESS mouse must be fully charged before its first use.

Connect the mouse to an available USB 2.0 or 3.0 port on your PC with the USB CHARGING / DATA CABLE (N).

The MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB (H) on the mouse will begin pulsing green to denote battery charging and will turn solid when charging is complete.

GETTING TO KNOW YOUR MOUSE



IMAGE FPO

A	LEFT MOUSE BUTTON	H	MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB
B	RIGHT MOUSE BUTTON	I	DPI BUTTON
C	MIDDLE CLICK / SCROLL WHEEL	J	USB CHARGING / DATA PORT
D	LEFT FORWARD BUTTON	K	POWER / WIRELESS MODE BUTTON
E	LEFT BACK BUTTON	L	USB WIRELESS RECEIVER STORAGE
F	RIGHT FORWARD BUTTON	M	USB WIRELESS RECEIVER
G	RIGHT BACK BUTTON	N	USB CHARGING / DATA CABLE

SETTING UP 2.4GHz SLIPSTREAM WIRELESS

Hyper-fast sub-1ms wireless connection is designed for no-compromise gaming grade performance.

- Connect the USB WIRELESS RECEIVER (L) to an available USB 2.0 or 3.x port located on the front panel of your PC or nearby USB port. (e.g. on CORSAIR MM700, MM800, MM1000 mousepads).
- The MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB (H) will turn solid white when connected.
- If the MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB (H) is blue, simply press the POWER / WIRELESS MODE BUTTON (K) once and it will turn white.
- Download the iCUE software from www.corsair.com/downloads.
- Run the installer program and follow instructions for installation.

If reconnection is required, initiate USB wireless receiver pairing via the iCUE software settings menu.

SETTING UP BLUETOOTH WIRELESS

Bluetooth wireless is best for everyday computing tasks, productivity, and office applications.

- Initiate Bluetooth pairing on your Bluetooth 4.0 or higher enabled device.

- Power on your mouse by holding down on the POWER / WIRELESS MODE BUTTON (K) for 5 seconds, or until the MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB (H) lights up.
- Press and hold down the SCROLL WHEEL (C) and then press the POWER / WIRELESS MODE BUTTON (K) once to enter Bluetooth pairing mode.
- Follow the instructions provided to successfully connect your device.
- The MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB (H) will turn solid blue when connected.

ON-THE-FLY DPI TUNING

This mouse has a unique feature where you can adjust the current onboard DPI stage setting in 50 DPI increments without the software, so you can jump right into the action while you find the perfect sensitivity setting.

Function	Shortcut	Multi-Purpose LED Indicator
Increase DPI by 50	Hold DPI BUTTON (I) and press FORWARD BUTTON (D or F)	Blinks green
Decrease DPI by 50	Hold DPI BUTTON (I) and press BACK BUTTON (E or G)	Blinks red
Reset DPI Stage	Hold DPI BUTTON (I) then both FORWARD (D or F) and BACK (E or F) buttons for 2 seconds	Blinks yellow

On-the-fly DPI changes are saved to the onboard memory and can be further adjusted in granular 1 DPI steps in iCUE software. If iCUE is running, then changes are saved to the software profile directly.

MOUSE STATUS AND INDICATIONS

Wireless connection, battery status, and DPI stages are communicated through the MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB (H).

BATTERY STATUS	MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB
Battery charging	Pulsing green
Battery critical, recharge required	Pulsing red
Battery low, recharge soon	Blinking red
Battery Medium	Blinking amber
Battery high	Blinking green
Battery charged	Green

WIRELESS STATUS	MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB
2.4GHz wireless mode – pairing	Blinking white
2.4GHz wireless mode – paired	White
2.4GHz wireless mode – pairing failed	Pulsing white
BT wireless mode – pairing	Blinking blue
BT wireless mode – paired	Blue
BT wireless mode – pairing failed	Pulsing blue

DPI STAGE STATUS	MULTIPURPOSE INDICATOR & CUSTOMIZABLE RGB
Stage #1 – 400 DPI	Red
Stage #2 – 800 DPI	Orange
Stage #3 – 1200 DPI	Yellow
Stage #4 – 1600 DPI	Green
Stage #5 – 3200 DPI	Blue

CHANGING DPI AND PROGRAMMABLE BUTTONS

To tailor your DPI and programmable buttons to your preferences, you must have iCUE installed on your device.

- Download the iCUE software from www.corsair.com/downloads.
- Run the installer program and follow instructions for installation.

- Connect the USB WIRELESS RECEIVER (M) to an available USB 2.0 or 3.x port located on the front panel of your PC or nearby USB port. (e.g. on CORSAIR MM700, MM800, MM1000 mousepads).
- Once connected, follow the instructions presented in iCUE for how to customize your M75 WIRELESS.

BATTERY REMOVAL INFORMATION

NEED IMAGE

This product uses a rechargeable battery and safety guidelines must be followed in the event that the product is disabled for disposal and recycling. To safely remove the battery for disposal and recycling, follow the numbered steps with the below diagrams.

CORSAIR MEMORY, Inc. encourages customers to recycle used electronic hardware and rechargeable batteries in accordance with local laws and regulations.

FCC ID: 2AAFMRGP0158 (Mouse)

FCC ID: 2AAFMRGP0146 (Dongle)

IC: 10954A-RGP0158 (Mouse)

IC: 10954A-RGP0146 (Dongle)