



Bluetooth[®] Sound Art[™] Speaker

OSA119S

User's Guide & Operating Instructions

Art Never Sounded So Good[™]

INTRODUCTION

Thank you for choosing Onsia's *Bluetooth* Sound Art Speaker. These unique flat-panel speakers, concealed in custom framed art, have reliable, proven components and a proprietary design that will provide a truly enjoyable listening experience. ONSIA's *Bluetooth* Sound Art speakers have been designed to be compatible with *Bluetooth* wireless technology-enabled smartphones, laptops, tablets and PCs. We've developed this installation guide to give you step-by-step pointers for a successful do-it-yourself install. Please read this installation guide & operating instructions document completely before you start. If you have doubts about completing this installation, you should contact a qualified contractor, or a professional audio/video installer. The facility where you purchased your *Bluetooth* Sound Art Speaker can refer you to a qualified installer in your area.

LIMITATION OF LIABILITY

DEDICATED SOUND AND AUDIO AND ITS AFFILIATES DO NOT MAKE ANY GUARANTEES, EXPRESSED OR IMPLIED, INCLUDING MERCHANTABILITY AND FITNESS FOR PURPOSE, WITH RESPECT TO ANY OF THESE SUGGESTIONS OR INSTRUCTIONS. DEDICATED SOUND AND AUDIO SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, LOSS OF USE, COST OF REPLACEMENT, BREACH OF CONTRACT, INJURY, OR ANY OTHER CAUSE WHATSOEVER EVEN IF LOUISIANA ART SUPPLY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

IMPORTANT SAFETY INSTRUCTIONS

General Instructions



- Read these instructions before using or installing this product.
- Keep these instructions for future reference.
- Heed all warnings in this guide.
- Follow all instructions.
- Install and operate in accordance to this document's instructions only.

Fire and Electric Shock Hazard



- DO NOT open, dismantle, disassemble or modify speaker.
- DO NOT block any ventilation openings.
- DO NOT expose to excessive cold, heat, humidity or direct sunlight.
- DO NOT push objects into holes or any openings.
- ONLY use wall charger supplied.
- Turn off power in areas you'll be drilling when installing unit to avoid electric shock.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

INSTALLATION GUIDE

Package Contents

- 1 *Bluetooth* Sound Art Speaker.
- 1 Wall Charger.
- 1 Metal Wire Foot
- 1 User's guide & operating instructions document.

General Speaker Placement

Because of the unique technology used in the design of your *Bluetooth* Sound Art Speaker, there is more flexibility in placing it relative to the primary listening area. In other words, the location of the speaker can be based on interior design requirements as well as acoustical considerations. You can simply place it where it looks the best. However, do not place your loudspeaker in corners, as this tends to create reverberation and sonic reflections.

Metal Foot Installation


Slide the metal wire foot into the metal wire holes on the back of the speaker. Use the holes for a vertical or a horizontal application. Apply moderate pressure until the metal wire foot stops sliding.

OPERATION

1) Charge it.

It's recommended to charge your Artist's *Bluetooth* Sound Art Canvas Speaker unit completely after unpacking.


Connect the wall charger unit to an AC outlet and to the DC jack located in the back of the speaker.



A **red** LED indicator on the wall charger indicates the speaker is charging.



A **green** LED indicator on the wall charger indicates the speaker is fully charged and can be unplugged.




2) Power it.

Slide the switch on the back of your speaker to the "ON" position. When the speaker is powered on you will hear a series of tones indicating the unit is ready to be paired or play music.



A **blue** LED indicator located next to the DC jack will turn ON and will remain ON to indicate the unit is powered.



Once your speaker is mounted on the wall, because of its long standby time, you may leave the unit ON. Your speaker will automatically enter a power saving mode when not in use.

3) Pair it. Play it. Love it!

To pair your speaker, enable *Bluetooth* on your music source device and scan for *Bluetooth* devices (read your device's manual or user's guide to add or setup a *Bluetooth* device). Pair your device with the *Bluetooth* device named "OSA119S" and enter "1234" when asked for a passcode. Once paired, you can start streaming music.

Your *Bluetooth* Sound Art Speaker features a speakerphone function. If you are paired to a cellphone, or a device capable of receiving phone calls, you can use the speaker function by selecting the speakerphone option on your device. If you are streaming music and a phone call is received, you will hear the ring tone through the speaker. When the phone call is answered, the music streaming will be paused. You will then have the option of routing the call through your *Bluetooth* Sound Art Speaker by selecting the speakerphone option on your device. Once the call is terminated, the music streaming will resume automatically.

Your *Bluetooth* Sound Art Speaker will give you many hours of enjoyable wireless play time on a single charge. When it's time to recharge, it will let you know by flashing its low battery indicator continuously.



Your *Bluetooth* Sound Art Speaker can be played and recharged at the same time.

**Good Bye Speakers,
Hello Sound Art!**



PRODUCT CARE

Do not use any solvents or liquids to clean your *Bluetooth* Sound Art Speaker. Simply dust unit with a dry piece of cloth.

WARRANTY INFORMATION

Dedicated Sound and Audio warrants its *Bluetooth* Sound Art Speaker products to be free from defects in material and workmanship for one year from the date of purchase. This product contains no user serviceable parts. *DO NOT attempt to open, dismantle, disassemble or modify the unit; doing so will void its warranty.* Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser. This warranty gives you specific legal rights and you may also have other rights that vary under local laws.

In the event of a defect, Dedicated Sound and Audio will, at its option, repair or replace the product with no charge to the purchaser for parts or labor. The repaired or replaced product will be warranted for 90 days from the date of return shipment, or for the balance of the original warranty, whichever is longer.

To obtain warranty service, the purchaser must obtain a Return Materials Authorization (RMA) number by calling Dedicated Sound and Audio at 1-800-279-7686. To obtain an RMA number, the purchaser must provide a copy of the original sales receipt. The purchaser must return the product postpaid with the purchaser's return address and the RMA number clearly printed on the outside of the package to the Authorized ONSIA Service Center provided by Dedicated Sound and Audio provided with the RMA number. Dedicated Sound and Audio will not be responsible for any losses or damage to the product incurred while the product is in transit or is being shipped for repair. Insurance is highly recommended.

Dedicated Sound and Audio, Inc.
Lake Forest, California 92630 USA

www.onsia.com

©2016 Dedicated Sound and Audio, Inc. All rights reserved. The ONSIA logo, ONSIA®, *Sound Art™* and *Art Never Sounded So Good™* are trademarks owned by Dedicated Sound and Audio, Inc. The *Bluetooth®* word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Dedicated Sound and Audio, Inc. is under license.