


Pioneer

SE-MJ771BT

WIRELESS STEREO HEADPHONES
CASQUE STÉRÉO SANS FIL
KABELLOSER STEREO-KOPFHÖRER
CUFFIA STEREO WIRELESS
AURICULARES INALÁMBRICOS ESTÉREO
DRAADLOZE STEREO HOOFDTELEFOON
AUSCULTADORES ESTEREO SEM FIOS
TRÄDLÖSA STEREOHÖRLURAR
ΑΣΥΡΜΑΤΑ ΣΤΕΡΕΟΦΩΝΙΚΑ ΑΚΟΥΣΤΙΚΑ
KABLOSUZ STEREO KULAKLIKAR
TRÄDLØSE STEREO HØDETELEFONER
BEZDRÁTOVÁ STEREOFONNÍ SLUCHÁTKA
VEZETÉK NÉLKÜLI SZTEREÓ FEJHALLGATÓ
BEZDRÔTOVÉ STEREOFÓNNE SLÚCHADLÁ
БЕСПРОВОДНЫЕ СТЕРЕОФОНИЧЕСКИЕ НАУШНИКИ
BEZPRZEWODOWE SŁUCHAWKI STEREO
ワイヤレスステレオヘッドホン



Operating Instructions
Mode d'emploi
Bedienungsanleitung
Istruzioni per l'uso
Manual de instrucciones

Handleiding
Manual de instruções
Bruksanvisning
Οδηγίες λειτουργίας
Çalıştırma Talimatları

Bruksanvisning
Provozní pokyny
Használati Útmutató
Návod na obsluhu
Инструкция по эксплуатации
Instrukcja obsługi
取扱説明書

Europe Only / Europe seulement

Declaration of Conformity with regard to the R&TTE Directive 1999/5/EC

Manufacturer:

**Onkyo & Pioneer Innovations
Corporation**

2-3-12, Yaesu, Chuo-Ku, Tokyo
104-0028, Japan / Japon

EU Representative's:

Pioneer Europe NV

Haven 1087, Keetberglaan 1,
9120 Melsele, Belgium / Belgique
<http://www.pioneer.eu>



[*] : SE-MJ771BT-K, SE-MJ771BT-W

English:

Hereby, Pioneer, declares that this
[*] is in compliance with the essential
requirements and other relevant
provisions of Directive 1999/5/EC.

Suomi:

Pioneer vakuuttaa täten että [*]
tyyppinen laite on direktiivin 1999/5/EY
oleellisten vaatimusten ja sitä koskevien
direktiivin muiden ehtojen mukainen.

Nederlands:

Hierbij verklaart Pioneer dat het toestel
[*] in overeenstemming is met de
essentiële eisen en de andere relevante
bepalingen van richtlijn 1999/5/EG

Français:

Par la présente Pioneer déclare que
l'appareil [*] est conforme aux
exigences essentielles et aux autres
dispositions pertinentes de la directive
1999/5/CE

Svenska:

Härmed intygar Pioneer att denna [*]
står i överensstämmelse med de
väsentliga egenskapskrav och övriga
relevanta bestämmelser som framgår
av direktiv 1999/5/EG.

Dansk:

Undertegnede Pioneer erklærer herved,
at følgende udstyr [*] overholder de
væsentlige krav og øvrige relevante
krav i direktiv 1999/5/EF

Deutsch:

Hiermit erkläre Pioneer, dass sich
dieses [*] in Übereinstimmung mit den
grundlegenden Anforderungen und den
anderen relevanten Vorschriften der
Richtlinie 1999/5/EG befindet". (BMW)

Ελληνικά:

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Pioneer ΔΗΛΩΝΕΙ
ΟΤΙ [*] ΣΥΜΜΟΡΦΩΝΕΤΑΙ
ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ
ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ
ΟΔΗΓΙΑΣ 1999/5/ΕΚ

Italiano:

Con la presente Pioneer dichiara che
questo [*] è conforme ai requisiti essenziali
ed alle altre disposizioni pertinenti stabilite
dalla direttiva 1999/5/CE.

Español:

Por medio de la presente Pioneer
declara que el [*] cumple con los
requisitos esenciales y cualesquiera
otras disposiciones aplicables o
exigibles de la Directiva 1999/5/CE

Português:

Pioneer declara que este [*] está
conforme os requisitos essenciais e
outras disposições da Directiva
1999/5/CE.

Čeština:

Pioneer tímto prohlašuje, že tento [*] je
ve shodě se základními požadavky a
dalšími příslušnými ustanoveními
směrnice 1999/5/ES

Eesti:

Käesolevaga kinnitab Pioneer seadme
[*] vastavust direktiivi 1999/5/EÜ
põhinõuetele ja nimetatud direktiivist
tulenevatele teistele asjakohastele
säteletele.

Magyar:

Alulírott, Pioneer nyilatkozom, hogy a [*]
megfelel a vonatkozó alapvető
követelményeknek és az 1999/5/EC
irányelv egyéb előírásainak.

Latviešu valoda:

Ar šo Pioneer deklarē, ka [*] atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Lietuvių kalba:

Šiuo Pioneer deklaruoją, kad šis [*] atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Malti:

Hawnhekk, Pioneer jiddikjara li dan [*] jikkonforma mal-htigijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Direttiva 1999/5/EC

Slovenščina:

Pioneer týmto vyhlasuje, že [*] splňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Slovenščina:

Pioneer izjavlja, da je ta [*] v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Română:

Prin prezenta, Pioneer declara ca acest [*] este în conformitate cu cerințele esențiale și alte prevederi ale Directivei 1999/5/EU.

български:

С настоящето, Pioneer декларира, че този [*] отговаря на основните изисквания и други съответни постановления на Директива 1999/5/EC.

Polski:

Niniejszym Pioneer oświadcza, że [*] jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC

Norsk:

Pioneer erklærer herved at utstyret [*] er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Íslenska:

Hér með lýsir Pioneer yfir því að [*] er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC

Hrvatski:

Ovime tvrtka Pioneer izjavluje da je ovaj [*] u skladu osnovnim zahtjevima i ostalim odredbama Direktive 1999/5/EC.

R-TTE-24L_C1_En

1

1



2




3




2

L


R




3




4



5



6



Thank you for buying this Pioneer product. Please read through these operating instructions so you will know how to operate your model properly. After you have finished reading the instructions, put them away in a safe place for future reference.

Informational Note for Customers in EU Only:

Information for users on collection and disposal of old equipment and used batteries

(Symbol for equipment)



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points in accordance with your national legislation.

(Symbol examples for batteries)



By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.



These symbols are only valid in the European Union.

For countries outside the European Union:

If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

K058a_A1_En

The Safety of Your Ears is in Your Hands

Get the most out of your equipment by playing it at a safe level – a level that lets the sound come through clearly without annoying blaring or distortion and, most importantly, without affecting your sensitive hearing. Sound can be deceiving. Over time, your hearing “comfort level” adapts to higher volumes of sound, so what sounds “normal” can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level BEFORE your hearing adapts.

ESTABLISH A SAFE LEVEL:

- Set your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, without distortion.
- Once you have established a comfortable sound level, set the dial and leave it there.

BE SURE TO OBSERVE THE FOLLOWING GUIDELINES:

- Do not turn up the volume so high that you can't hear what's around you.
- Use caution or temporarily discontinue use in potentially hazardous situations.
- Do not use headphones while operating a motorized vehicle; the use of headphones may create a traffic hazard and is illegal in many areas.

S001a_A1_En

WARNING

This equipment is not waterproof. To prevent a fire or shock hazard, do not place any container filled with liquid near this equipment (such as a vase or flower pot) or expose it to dripping, splashing, rain or moisture.

D3-4-2-1-3_A1_En

Operating Environment

Operating environment temperature and humidity:

+5 °C to +35 °C (+41 °F to +95 °F); less than 85 %RH (cooling vents not blocked)
Do not install this unit in a poorly ventilated area, or in locations exposed to high humidity or direct sunlight (or strong artificial light)

D3-4-2-1-7c*_A1_En

WARNING

To prevent a fire hazard, do not place any naked flame sources (such as a lighted candle) on the equipment.

D3-4-2-1-7a_A1_En

This product is for general household purposes. Any failure due to use for other than household purposes (such as long-term use for business purposes in a restaurant or use in a car or ship) and which requires repair will be charged for even during the warranty period.

K041_A1_En

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

D3-4-2-3-2_A1_En

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

Information to User

Alterations or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

D8-10-2_A1_En

**Note****Internal Rechargeable Lithium-ion Battery**

This device uses an internal rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead, try charging it several times. If the battery does not recharge, please contact us for repair information.

WARNING/DISPOSAL OF UNIT

Please do NOT attempt to change the battery yourself. If the battery has died and you do not want us to replace your battery, you should follow the disposal instructions below:

- Never dispose of used batteries/electronics with ordinary solid wastes, since they contain toxic substances.
- Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices.
- Many electronics retailers now recycle batteries and other electronic devices at no charge. Check to see which ones in your area do so.

Informational Note for Customers in U.S.A. Only:

WARNING: This product contains chemicals known to the State of California and other governmental entities to cause cancer and birth defects or other reproductive harm.

Wash hands after handling.

D36-PS_C1_En

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption ratio (SAR).

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- MODIFICATION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Please read through these operating Instructions so you will know how to operate your model properly.



WARNING

- Adjust headphones sound to the proper volume. Loud sound may damage your ears.
- For traffic safety, never use the headphones while riding a bicycle, motor bike, or while driving a car. It is dangerous to increase the sound volume too much because you cannot hear external sounds; take great care about traffic around you.
- This unit should not be used by persons who have heart pacemakers installed, since adverse affects could occur.
- Do not use this unit in hospitals or clinics, or near medical equipment.
- Do not use inside airplanes or in the vicinity of automatic doors to avoid danger of causing malfunctions.



CAUTION

- Never inspect the inside OR remodel this machine. This device includes high-voltage internal parts, and contacting them could result in fire or electrical shock. If the customer remodels this machine, PIONEER will no longer guarantee its performance.

Precautions for use

- Caution should be observed during use, since adjustable parts may pinch the user's hair, depending on the way in which headphones are used.
- Do not subject the headphones to strong forces or impacts, since damage could occur to the exterior appearance or product performance.
- When headphones are dirty, wipe with a dry, soft cloth. Take care not to blow into the speaker unit.
- Ear pads may degrade over long periods of use or storage. In this event consult your dealer.
- Sound quality might deteriorate or sound maybe interrupted if the plug is dirty. Keep the plug clean by wiping it with a soft, dry cloth occasionally.
- If any itching or skin discomfort occurs during use, cease use immediately.
- This product is not edible. Place out of reach of small children to prevent accidental ingestion of small parts.
- If any of the following symptoms appear, immediately cease use of the headphones, turn power to OFF, and consult your Pioneer Service Center:
 - The headphones exhibits unnatural heating, smells, deformation, discoloration, etc.
 - A foreign object enters the headphones.

Specifications

Transmission format	Bluetooth Standard Protocol Ver. 4.0
Output	Bluetooth Standard Protocol Power Class 2
Maximum transmission distance	About 10 m line of sight *1
Frequency used	2.4 GHz (2.4000 GHz to 2.4835 GHz) *2
Modulation	FHSS
Supported Bluetooth profiles	A2DP, AVRCP, HFP, HSP
Supported CODEC	SBC, AAC, aptX®
Contents protection	SCMS-T
Battery life with continuous use	Maximum 32 hours of continuous transmission (including music-play time)
Battery life in continuous standby mode	Maximum 800 hours
Recharging time	About 5 hours
Rating input	5 V  200 mA or 3.7 V 650 mAh Battery
Power	DC 3.7 V internally rechargeable lithium-ion battery
Weight	215 g

HEADPHONES

Type	Fully-enclosed dynamic headphones
Driver units	ø40 mm
Frequency response	9 Hz to 22 000 Hz (With Bluetooth connection) 6 Hz to 28 000 Hz (With wired connection)
Maximum input power	1 000 mW (With wired connection)
Impedance	32 Ω (With wired connection)
Sensitivity	105 dB
Ear pad	Polyurethane (leather finish)

MICROPHONE

Type	Electret condenser type
Directionality	Omni-directional microphone
Frequency response	20 Hz to 16 000 Hz

ACCESSORIES

Micro-USB cable	1
Headphone cord	1
Warranty (Europe/Japan)	1
Operating Instructions (this document)	1

*1 Transmission distance is an approximation. Actual usable distance may vary depending on surrounding conditions.

*2 This product utilizes radio waves in the 2.4 GHz spectrum. Some signal dropouts may be experienced due to interference with radios, microwave ovens, and other devices using the 2.4 GHz spectrum.



Note

Specifications and design are subject to possible modifications without notice due to improvements.

- "Pioneer" is a trademark of Pioneer Corporation, and is used under license.
- The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Onkyo Corporation is under license. Other trademarks and trade names are those of their respective owners.
- © 2013 CSR plc and its group companies. The aptX® mark and the aptX logo are trade marks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.
- The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.
- Android is a trademark of Google Inc.

Main Features

Wireless music enjoyment

- Wireless music enjoyment on *Bluetooth* devices (smart phones and other cell phones, digital music players, etc.) *1
For operating details consult the user's manual for the device to be connected.
- Allows control of play, stop, forward and reverse selection. *2


Hands-free communication

- Hands-free communication is possible even with the *Bluetooth* telephone placed in your bag or briefcase. *3

*1 The corresponding *Bluetooth* device must support the A2DP profile.

*2 The corresponding *Bluetooth* device must support the AVRCP profile. Also, remote control operation cannot be guaranteed for all devices.

*3 The corresponding *Bluetooth* device must support the HSP or HFP profile.



Glossary

A2DP : High-quality musical contents transmission profile

HSP : Communication/cell-phone operation profile

HFP : Hands-free communication/cell-phone operation profile

AVRCP : AV components remote control profile

NFC : Advanced technology for short-range communication between electronic devices

1. Set Contents

Confirm the presence of all parts and components before use.

- 1 : Headphones
- 2 : Micro-USB cable
- 3 : Headphone cord
- 4 : Warranty (Europe/Japan)
- 5 : Operating instructions (this document)

2. Names of Parts

Also refer to Figure 2 on the reverse side of this manual's cover.

For more information about the operation of each button, consult the explanations given regarding each function.

- 1 : N-mark
- 2 : (▶/||◀) button
- 3 : (⏻) button
- 4 : LED indicator
- 5 : Micro-USB port
- 6 : Headphone jack
- 7 : Microphone
- 8 : (+) button
- 9 : (▶▶) button
- 10 : (◀◀) button
- 11 : (—) button

3. Charging the batteries

The unit's battery must be recharged before use.

The accessory micro-USB cable must be used for recharging the unit's battery.

Connect the appropriate connector on the accessory micro-USB cable to the micro-USB port on the headphones, and the USB plug on the other end to a USB port on a computer. (see Fig. 3).

- When recharging begins, the LED indicator on the headphones will light red.
- If recharging is performed with the unit's power turned ON, the power will automatically turn OFF. The unit cannot be used during recharging.
- Full recharging requires about 5 hours; when recharging is completed, the LED indicator will turn off.
- With a full battery charge, the maximum continuous usable time is about 32 hours; the maximum continuous time the headphones can be left in standby mode is about 800 hours.
- When the rechargeable battery's power becomes low, a beeping sound can be heard from the unit once every 3 minutes, and the LED indicator flashes red. In this case, recharge the battery before using the unit.



Note

- Battery recharging time and usable battery time may vary depending on ambient temperature and frequency of use.
- Do not place metal objects near the headphones' charging contacts, since dangerous electrical shorts or abnormal heating may result.

Notes on battery charging

- Battery performance is influenced by the surrounding temperature. Charge the supplied rechargeable batteries within a temperature range of 10 to 35 degrees Celsius.
- Do not overcharge batteries. In order to protect batteries, do not repeatedly charge the batteries that are already fully charged.
- Batteries become slightly warm when charging. This is not a malfunction.
- Please use the accessory micro-USB cable for recharging; using other cables may result in malfunction.
- Recharging may not be possible if computer is in power-saving mode.
- Always confirm the proper shape and orientation of the micro-USB cable plugs before attempting to connect to the headphones and computer.
- Do not use micro-USB cables when tightly twisted or bundled, since fire or electric shock might result.
- *Bluetooth* function cannot be used during recharging.
To listen to playback while recharging, see page 12, "Using the Headphone cord."

4. Pairing

Pairing must be performed before the headphones can be used to listen to music or communicate using a *Bluetooth* device.
For further details regarding the pairing procedure, consult the user's manual for your *Bluetooth* device.

- (1) Hold the (P) button depressed while the unit's power is turned off to enter the pairing mode.
 - The pairing mode is confirmed by the LED indicator's alternately flashing blue and red. (see Fig. 4).
 - Release the (P) button after confirming that the LED indicator is alternately lighting blue and red.
 - When in the pairing mode, if pairing is not completed within about 10 minutes, the power will automatically turn off.
- (2) Turn on the power to the *Bluetooth* device you wish to pair with, and begin pairing:
 - search for this unit (wireless headphones) from the paired *Bluetooth* device.
 - Set the *Bluetooth* device close (within one meter) to the wireless headphones.
 - These wireless headphones will appear in the *Bluetooth* device's display as "SE-MJ771BT".
 - For operating details consult the user's manual for the device to be connected.
- (3) Confirm that pairing has been successfully completed with the *Bluetooth* device.
 - Look at the display for the *Bluetooth*-enabled device and select "SE-MJ771BT".
 - Pairing is completed if the LED indicator blinks in blue once every three seconds.
 - The PIN code for these wireless headphones has been factory set at "0000". Input this code if requested by the *Bluetooth* device.

Connect to the *Bluetooth* device

- Confirm that the power to the wireless headphones is ON before connecting to the *Bluetooth* device.
- Depending on the device, connection between the wireless headphones and *Bluetooth* device may be effected automatically after pairing.

Disconnecting from the *Bluetooth* device

- Hold the wireless headphones' (P) button depressed for about 5 seconds to turn off the power.



Note

- Depending on the device connected, the A2DP profile may need to be designated when playing music, and the HFP or HSP profiles for hands-free communication.
- For details regarding operating and setting methods, consult the user's manual for the *Bluetooth* device.
- Once pairing has been accomplished, connections will be performed automatically, but if connection to the device was not successful, perform the pairing operation again.
- These wireless headphones can record pairing information for up to 8 *Bluetooth* devices. If pairing is performed for a ninth device, the information for the first paired device will be overwritten and lost. If you wish to reconnect to that device on a subsequent occasions, it will be necessary to repeat pairing with that device.
- Whenever using a device with which pairing has been performed, first turn on the power to the wireless headphones, then perform the connection operation for the paired *Bluetooth* device.

5. Using NFC for pairing

When a smart phone or tablet device is equipped with NFC, *Bluetooth* pairing (and depairing) can be performed simply by merely swiping the device over the headphones.

- Supported OS: Android 4.2 and later.
- Depending on the smart phone or tablet device used, the NFC signal reception may be too weak to perform one-touch connections. The unit may pair with a device other than the desired one if multiple NFC devices are nearby. In that case, follow the manual pairing procedure outlined in step 4.

How to set pairing

- (1) Hold the (P) button depressed while the unit's power is turned off to enter the pairing mode.
 - (2) Pass the "N" mark on the device to be paired closely over the "N" mark on L side housing. (see Fig. 5).
 - (3) The device will automatically begin setting the pairing.
Pairing is completed if the LED indicator blinks in blue once every three seconds.
- * Only one device can be connected at a time.

Disconnecting

With the other device connected to the headphones, pass the "N" mark on the device closely over the "N" mark on L side housing.

The connection will be automatically undone.

Depending on the specifications of the connected *Bluetooth* device, the connection cannot be terminated from the NFC device. In that case, perform the procedure of "Disconnecting from the *Bluetooth* device" in "4. Pairing".

6. Enjoying music

To use the wireless headphones to listen to music from a *Bluetooth* device, you must first perform pairing with the *Bluetooth* device using the A2DP audio profile. For details on how to perform pairing, see P.10.

- (1) With power to the wireless headphones' turned off, hold the (⏻) button depressed for about three seconds.
The headphones' power will turn on and the LED indicator will flash blue.
 - (2) Turn on the *Bluetooth* function on the device you wish to connect to.
When pairing is completed, the wireless headphones will automatically connect to the *Bluetooth* device.
- * If automatic connection is not achieved, or the headphones automatically connect to a different *Bluetooth* device than the one you wish to use, follow the instructions for the desired *Bluetooth* device regarding manual connection.

Controls when listening to music

If the connected *Bluetooth* device supports AVRCP, the following operations can be used.

● Press once

- (+) button : Increase volume.
- (-) button : Decrease volume.
- (▶▶) button : Advance to next track or chapter.
- (◀◀) button : Return to beginning of track or chapter.
- (▶/||◀) button : Play/Pause.

- * When sound volume is set to maximum or minimum levels a beep sound will be produced from the headphones.
- * Sound volume can be adjusted on the matching *Bluetooth* device.
- * Depending on the specifications of the connected *Bluetooth* device, the controls noted above and controls on the *Bluetooth* device may not be supported.
- * Depending on the specifications of the connected *Bluetooth* device, the music playback settings may need to be configured. Consult the user's manual for the *Bluetooth* device.
- * Depending on the specifications of the connected *Bluetooth* device, a music playback application may start automatically or the music cannot be paused/played. Consult the user's manual for the *Bluetooth* device.

Using the headphones cord

The furnished headphones cord can be used to listen to playback. (see Fig. 6).



Note

- Connect the straight plug to the headphones' jack, and connect the L-type plug to the playback device.
- Insert the plug fully and securely.
Failure to insert the plug sufficiently may result in reduced audio output from the headphones, or other malfunctions.
- The *Bluetooth* function cannot be used while the headphone cord is in use.
- If you begin using the headphone cord when power is already turned on, power to the unit will be automatically disconnected.

7. Vocal communication

To use the wireless headphones for vocal communication, pairing must be performed with the desired *Bluetooth* device using the "hands-free profile" (HFP) or "headset profile" (HSP).

For details on how to perform pairing, see P.10.

* If the *Bluetooth* device supports both profiles HFP and HSP, use the profile HFP.

- (1) With power to the wireless headphones' turned off, hold the (D) button depressed for about three seconds.
The headphones' power will turn on and the LED indicator will flash blue.
 - (2) Turn on the *Bluetooth* function on the device you wish to connect to.
When pairing is completed, the wireless headphones will automatically connect to the *Bluetooth* device.
- * If automatic connection is not achieved, or the headphones automatically connect to a different *Bluetooth* device than the one you wish to use, follow the instructions for the desired *Bluetooth* device regarding manual connection.

Vocal communication controls

If the connected *Bluetooth* device supports AVRCP the following operations can be used.

● Press once

(+) button : Increase volume.

(-) button : Decrease volume.

(▶/||↶) button

- Press once when receiving a message : Enables conversation.
Press once again to end conversation.

■ Press and hold when receiving a message : Refuse communication.

●● Press twice : Performs redialing.

- * When sound volume is set to maximum or minimum levels a beep sound will be produced from the headphones.
- * Sound volume can be adjusted on the matching *Bluetooth* device.
- * Depending on the specifications of the connected *Bluetooth* device, the controls noted above and controls on the *Bluetooth* device may not be supported.
- * Depending on the specifications of the connected *Bluetooth* device, the phone settings may need to be configured. Consult the user's manual for the *Bluetooth* device.



8. LED indicator

Operation	LED indicator
When not connected to a <i>Bluetooth</i> device	LED flashes blue twice every three seconds.
Pairing mode	LED alternately flashes blue and red.
When connected to a <i>Bluetooth</i> device	LED flashes blue once every three seconds.
During recharging	LED lights red.

9. Troubleshooting

Problem	Remedy
Power won't turn on.	Recharge the wireless headphones.
The batteries will not charge.	Confirm that computer's power is ON.
	Confirm that computer is not in power-saving mode.
	Confirm that accessory micro-USB cable is securely connected to both the wireless headphones and the computer.
Can't perform pairing.	Place the wireless headphones and <i>Bluetooth</i> device closely together when performing pairing.
Can't perform <i>Bluetooth</i> connection.	Confirm that power is turned on for both wireless headphones and <i>Bluetooth</i> device.
	Confirm that <i>Bluetooth</i> function is turned ON in the device you are connecting to.
No sound. (When playing music)	Confirm that power is turned on for both wireless headphones and <i>Bluetooth</i> device.
	Confirm that connection with <i>Bluetooth</i> device is set for profile A2DP.
	Confirm that the connected music playback device is set for PLAY.
	Confirm that sound volume controls on both wireless headphones and music playback device are set to appropriate levels.
Sound is distorted. (When playing music)	Check that no other devices utilizing the 2.4 GHz wavelength (including microwave ovens, wireless radios, etc.) are nearby, and that no obstructions block the signal path.
Can't use hands-free operation.	Confirm that wireless headphones and <i>Bluetooth</i> device are connected using the profile HFP or HSP.
	If connection to the <i>Bluetooth</i> device is in profile A2DP, it may be necessary to change connection profiles (depending on the specifications of the <i>Bluetooth</i> device).
Communication distance is short, sound is garbled.	Check that no other devices utilizing the 2.4 GHz wavelength (including microwave ovens, wireless radios, etc.) are nearby, and that no obstructions block the signal path.

Problem	Remedy
Can't perform connection with NFC.	Confirm that the <i>Bluetooth</i> device is equipped with NFC function.
	Activate the NFC setting on the <i>Bluetooth</i> device.
	Confirm that the orientation of the wireless headphones and <i>Bluetooth</i> device is correct when swiping.
	In some cases recognition of the device may require more time; in this event continue swiping the devices until connection is completed.
	Remove the <i>Bluetooth</i> device from its case or cover.



English

このたびは、バイオニア製品をお買い上げいただき、まことにありがとうございます。
ご使用前にこの「取扱説明書」を最後までよくお読みのうえ、「安全上のご注意」に従い正しくお使いください。お読みになったあとは、大切に保管してください。

安全上のご注意

安全に正しくお使いいただくために、必ずお守りください。

● ご使用前に、この「安全上のご注意」と「使用上のご注意」をよくお読みのうえ、正しくお使いください。

● お読みになったあとは、いつでも見られる所に必ず保存してください。

この「安全上のご注意」、「使用上のご注意」および製品への表示は、製品を安全に正しくお使いいただき、あなたや他の人々への危害や財産への損害を未然に防止するために、いろいろな絵表示をしています。その表示と意味は次のようになっています。

	危険	この表示の欄は「人が死亡または重傷を負う危険が切迫して生じることが想定される内容」を示しています。
	警告	この表示の欄は「人が死亡または重傷を負う可能性が想定される内容」を示しています。
	注意	この表示の欄は「人が軽傷を負う可能性が想定される内容、および物的損害のみの発生が想定される内容」を示しています。
絵記号の例		
	○記号は禁止（やってはいけないこと）を示しています。図の中や近くに具体的な禁止内容（左図の場合は分解禁止）が描かれています。	
	●記号は行動を強制したり指示する内容を示しています。図の中に具体的な指示内容（左図の場合は電源プラグをコンセントから抜く）が描かれています。	

警告

- 異常があった場合は使用を中止する**
 - 内部に金属や水などの液体が入ったとき
 - 落下などで本体（外装ケース）が破損したとき
 - 煙や異臭、異音が出たとき
 - 手で触れられないほど熱いときそのまま使うと、火災・感電の原因になりますので、ご相談窓口へお問い合わせください。
お客様による修理は危険ですから絶対おやめください。
- 本機を布や布団でおおったりつつんだり、ホットカーペットの上やコタツの中で使用しない**
 - 熱がこもり、ケースが変形し、火災の原因となります。
- 付属以外のマイクロ USB ケーブルは使わない**
 - 機器本来の性能が出ないことや、電流容量不足による発熱から火災・感電の原因となることがあります。
- 風呂場やシャワー室では使用しない**
 - 火災・感電の原因になります。
- 自転車、オートバイ、または自動車などの運転中には絶対に使用しない**
 - 運転中に使用すると、交通事故の原因になります。
- 踏切や駅のホーム、車道、工事現場など、危険な場所では使用しない**
 - 周囲の音が聞こえず、不慮の事故の原因となります。
- 耳を刺激するような大音量での長期間の使用はしない**
 - 聴力が大きく損なわれる原因になります。

⚠ 注意

日本語

- ⊘ 油煙や湯気が当たるところ、湿気やほこりの多い場所に置かない
 - 電気が油分や水分、ほこりに伝わり、火災・感電の原因となることがあります。
- ⚠ 電源を切る前は音量を下げる
 - 電源を入れたとき、突然大きな音が出て聴力障害などの原因となることがあります。
- ⊘ 電源を入れる時は徐々に音量を上げる
 - 電源を入れたとき、突然大きな音が出て聴力障害などの原因となることがあります。
- ⊘ マイクロ USB ケーブルのコードをグルグル巻き付けて使用しない
 - 異常発熱により、火災・感電の原因となることがあります。
- ⚠ 肌に直接触れる部分に異常を感じたら使用を中止する
 - そのまま使用するとかぶれや炎症などの原因になることがあります。医師にご相談ください。
- ⊘ 異常に温度が高くなるところに置かない
 - 外装ケースや内部部品が劣化するほか、火災の原因となることがあります。
 - 窓を閉め切った自動車の中や直射日光が当たる場所、ストーブの近くでは特にご注意ください。
- ⊘ 本機を使用するときは、音量を上げすぎない
 - 耳を刺激するような大きな音量で長時間続けて聞くと、聴力が大きく損なわれる原因になります。
- ⊘ 本機に水を入れたり、ぬらさない
 - 火災・感電の原因となることがあります。
 - 雨天、降雪中、海岸、水辺での使用は特にご注意ください。
- ⊘ 分解・改造しない
 - 内部には電圧の高い部分があり、火災・感電の原因となることがあります。
 - 内部の点検・設備・修理は、販売店にご依頼ください。
- ⚠ 心臓ペースメーカーをお使いの方は使用しない
 - ペースメーカーに影響を与えるおそれがあります。
- ⚠ 病院などの医療機関、医療機器の近くでは使用しない
 - 機器に影響を与えるおそれがあります。
- ⚠ 本機を航空機内で使用しない
 - 電波が影響を及ぼし、誤動作による事故の原因となるおそれがあります。
- ⚠ 本機を自動ドア、火災報知機などの自動制御機器の近くで使用しない
 - 電波が影響を及ぼし、誤動作による事故の原因となるおそれがあります。
- ⊘ 飲み込む恐れのある小さな部品は幼児の手の届くところに置かない
 - 万一口飲み込んだ場合はただちに医師にご相談ください。

使用上のご注意

- ご使用のしかたによっては、可動部に髪の毛などを挟む場合がありますのでご注意ください。
- プラグを抜き差しするときは、コードを引っ張らずに必ずプラグを持って抜き差ししてください。
- 強い力を与えたり、強い衝撃を与えると機器の外観・性能を損ねたり、故障や破壊の原因となります。
- 汚れは、乾いた柔らかい布で拭き取ってください。その際にスピーカーユニット部に息を吹きかけたりしないでください。

- イヤーパッドは消耗品ですので、長期的使用・保存により劣化します。劣化した場合は、部品受注センターにてお買い求めください。
- マイクロUSBケーブルの端子を汚れたままにしておくと、充電できない場合があります。時々柔らかい布でから拭きし、清潔に保ってください。
- プラグ部分を汚れたままにしておくと音質が悪くなったり、音がとぎれたりすることがあります。時々柔らかい布でから拭きし、清潔に保ってください。

電池についての安全上のご注意

電池は使用形態や使用環境、保存状態などによって、液漏れ・破裂・発熱・発火などで、けがや機器故障の原因となることがありますので、下記の注意事項を必ずお守りください。

本機では以下の電池を内蔵しています。

- ・ 充電式電池 専用充電式リチウムイオン電池



危険 充電式の電池の液が漏れたときは…

- 素手で液を触らない
- 液が目に入ったときは、目をこすらず、すぐに水道水などのきれいな水で十分に洗い、ただちに医師の治療を受けてください。
- 液が身体や衣服についたときは、すぐにきれいな水で十分に洗い流してください。皮膚の炎症やけがの症状があるときは医師に相談してください



危険 充電式電池について

- 付属のマイクro USB ケーブル以外で充電しない。
- 火の中に入れない。分解、加熱しない。
- 火のそばや直射日光の当たるところ・炎天下の車中など、高温になる場所で使用・保管・放置しない。
- ショートさせない。
- 液漏れした電池は使わない。



お願い

使用済み充電式リチウムイオン電池はリサイクル可能な貴重な資源です。

本製品を廃棄する場合は充電電池の取り外しをお客様自身で行わず、弊社修理受付窓口（P.15 参照）にご相談ください。

Li-ion

電波に関するご注意

本機は、2.4 GHz の周波数帯の電波を利用しています。この周波数の電波は、下記①に示すようにいろいろな機器で使用しています。また、お客様に存在がわかりにくい機器として下記②に示すような機器もあります。

- ① 2.4 GHz を使用する主な機器の例
 - ・ コードレスフォン
 - ・ コードレスファクシミリ
 - ・ 電子レンジ
 - ・ 無線 LAN 機器
 - ・ ワイヤレス AV 機器
 - ・ ゲーム機のワイヤレスコントローラー
 - ・ マイクロ波治療機器類
- ② 存在がわかりにくい 2.4 GHz を使用する主な機器の例
 - ・ 万引き防止システム
 - ・ アマチュア無線局
 - ・ 工場や倉庫などの物流管理システム
 - ・ 鉄道車両や緊急車両の識別システム

これらの機器と本機を同時に使用すると、電波の干渉により、音かとぎれて雑音のように聞こえたり、音が出なくなることがあります。
受信状況の改善方法としては以下の方法があります。

- ・ 電波を発生している相手機器の電源を切る
- ・ 干渉している機器の距離を離して設置する

次の場所では本機を使用しないでください。ノイズが出たり、送信 / 受信ができなくなる場合があります。

- ・ 2.4 GHz を利用する無線 LAN、または電子レンジなどの機器の磁場、静電気、電波障害が発生するところ。（環境により電波が届かない場合があります）
- ・ ラジオから離してお使いください。（ノイズが出る場合があります）
- ・ テレビにノイズが出た場合、Bluetooth 機能搭載機器や本機（および本機対応製品）がテレビ、ビデオ、BS チューナー、CS チューナーなどのアンテナ入力端子に影響を及ぼしている可能性があります。Bluetooth 機能搭載機器や本機（および本機対応製品）をアンテナ入力端子から離して設置してください。

■ 電波法に基づく認証について

本機は、電波法に基づく小電力データ通信の無線設備として認証を受けています。したがって、本製品を使用するときに無線局の許可は必要ありません。ただし、以下の行為をすると法律で罰せられることがあります。

- ・ 本機を分解 / 改造すること。
- ・ 本機に印刷されている証明番号を消すこと。

■ 周波数について

周波数表示の見かた（個装箱 裏面に表示）

2.4 FH1



- ① 「1」 想定される干渉距離（約 10 m）を表します
- ② 「FH」 変調方式を表します
- ③ 「2.4」 GHz 帯を使用する無線設備を表します

使用範囲について

通信の環境により伝送距離が短くなることがあります。

次のような場合、電波状態が悪くなったり電波が届かなくなることが原因で、音声がかたたり停止したりします。

- ・鉄筋コンクリートや金属の使われている壁や床を通して使用する場合。
- ・大型の金属製家具の近くなど。
- ・人混みの中や、建物障害物の近くなど。
- ・2.4 GHz を利用する無線 LAN、または電子レンジなどの機器の磁場、静電気、電波障害が発生するところ。
- ・集合住宅（アパート・マンションなど）にお住まいで、お隣で使用している電子レンジ設置場所が本機に近い場合。なお、電子レンジは使用していなければ電波干渉はおこりません。

電波の反射について

本機が通信する電波には、直接届く電波（直接波）と、壁や家具、建物などに反射して様々な方向から届く電波（反射波）があります。これにより、障害物と反射物とのさまざまな反射波が発生し、電波状態の良い位置と悪い位置が生じ、音声がかたたり受信できなくなることがあります。このような時は、Bluetooth 機能搭載機器の場所を少し動かしてみてください。Bluetooth 機能搭載機器と本機の間を人間が横切ったり、近づいたりすることによっても、反射波の影響で音が途切れたりすることがあります。



注意

- ・本機の使用によって発生した損害については、法令上賠償責任が認められる場合を除き、当社は一切の責任を負いませんので、あらかじめご了承ください。
- ・本機は、すべての Bluetooth 搭載機器との接続動作を保証するものではありません。

安全にお使いいただくために

- ・高精度な制御や微弱な信号を採取う電子機器の近くでは使用しない。電子機器に誤動作するなどの影響を与え、事故の原因となる恐れがあります。
- ・航空機器や病院など、使用を禁止された場所では使用しないでください。電子機器や医療用電気機器に影響を与え、事故の原因となる恐れがあります。医療機関の指示にしたがってください。

ご注意ください電子機器の例

補聴器、ペースメーカー、その他医療用電気機器、火災報知器、自動ドア、その他自動制御機器など。

ペースメーカー、その他医療用電気機器をご使用される方は、該当の各医療用電気機器メーカーまたは販売業者に電波による影響についてご確認ください。

この機器の使用周波数帯では、電子レンジなどの産業・科学・医療用機器のほか、工場の製造ラインなどで使用されている移動体識別用の構内無線局（免許を要する無線局）および特定小電力無線局（免許を要さない無線局）並びにアマチュア無線局（免許を要する無線局）が運用されています。この機器を使用する前に、近くで移動体識別用の構内無線局および特定小電力無線局並びにアマチュア無線局が運用されていないことを確認してください。万一、この機器から移動体識別用の構内無線局に対して有害な電波干渉の事例が発生した場合には、すみやかに電波の発射を停止しうえ、ご相談窓口（P.15 参照）にご連絡いただき、混信回避のための処置など（たとえば、パーティションの設置など）についてご相談ください。

その他、この機器から移動体識別用の特定小電力無線局あるいはアマチュア無線局に対して有害な電波干渉の事例が発生した場合など、何かお困りのことが起きたときは、ご相談窓口（P.15 参照）へお問い合わせください。

主な仕様

通信方式	Bluetooth 標準規格 Ver. 4.0
出力	Bluetooth 標準規格 Power Class 2
最大通信距離	見通し距離 約 10 m *1
使用周波数帯域	2.4 GHz 帯 (2.4000 GHz ~ 2.4835 GHz) *2
変調方式	FHSS
対応 Bluetooth プロファイル	A2DP、AVRCP、HFP、HSP
対応 CODEC	SBC、AAC、aptX®
対応コンテンツ保護	SCMS-T 方式
電池持続時間	連続通信 最大 32 時間 (音楽再生時間含む)
連続待受け時間	最大 800 時間
充電時間	約 5 時間
定格入力	5 V $\overline{\text{---}}$ 200 mA (3.7 V 650 mAh 電池)
電源	DC3.7 V 内蔵充電式リチウムイオン電池
質量	215 g

ヘッドホン

型式	密閉型ダイナミック
使用ユニット	ϕ 40 mm
再生周波数帯域	9 Hz ~ 22 000 Hz (Bluetooth 接続時) 6 Hz ~ 28 000 Hz (有線接続時)
最大入力	1 000 mW
インピーダンス	32 Ω
出力音圧レベル	105 dB
イヤークッション	ポリウレタン (レザータイプ)

マイク

型式	エレクトレットコンデンサー型
指向特性	全指向性
周波数特性	20 Hz ~ 16 000 Hz

付属品

マイクロ USB ケーブル	1
ヘッドホンコード	1
保証書 (欧州 / 日本)	1
取扱説明書 (本書)	

*1 通信距離は目安です。周囲環境により通信距離が変わる場合があります。

*2 本製品は 2.4 GHz 帯の電波を使用しています。他の 2.4 GHz 帯を使用する無線機器、電子レンジなどの干渉により音声途切れる場合があります。

※ 上記の仕様および外観は改良のために予告なく変更することがあります。

各種ライセンス

- 「Pioneer」は、パイオニア株式会社の商標であり、ライセンスに基づき使用されています。
- Bluetooth® ワードマークおよびロゴは、Bluetooth SIG, Inc. が所有する登録商標であり、オンキヨー株式会社は、これら商標を使用する許可を受けています。他のトレードマークおよび商号は、各所有権者が所有する財産です。
- © 2013 CSR plc およびそのグループ企業。aptX® マークおよび aptX のロゴは、CSR plc またはそのグループ企業の登録商標であり、1 か所またはそれ以上の管轄において登録されている可能性があります。
- N-Mark は米国およびその他の国における NFC Forum, Inc. の商標または登録商標です。
- Android は Google Inc. の商標であり、この商標の使用は、Google の許可の対象となります。

本機でできること

ワイヤレスで音楽を聞く

- Bluetooth 機器（携帯電話、スマートフォン、デジタル音楽プレーヤーなど）の音楽やワンセグの音声をワイヤレスで聞くことができます。*1
- 詳しくは、相手側 Bluetooth 機器の取扱説明書をご覧ください。
- 音楽の再生、停止、曲送り / 曲戻しなどの操作ができます。*2

ハンズフリーで通話する

- Bluetooth 対応電話器をカバンなどに入れたまま、ハンズフリーで通話ができます。*3
- *1 相手側 Bluetooth 機器が A2DP プロファイルに対応している必要があります。
- *2 相手側 Bluetooth 機器が AVRCP プロファイルに対応している必要があります。また、すべての機器に対するリモコン動作を保証するものではありません。
- *3 相手側 Bluetooth 機器が HSP または HFP プロファイルに対応している必要があります。



Bluetooth 機器:スマートフォン



Bluetooth 機器:デジタル音楽プレーヤー >>>



その他デジタル音楽プレーヤー
+
Bluetooth オーディオ送信機(市販)



Bluetooth 機器:スマートフォン >>>



用語解説

A2DP (Advanced Audio Distribution Profile) : 高音質な音楽コンテンツを送受信するプロファイル
HSP (Headset Profile) : 通話 / 携帯電話を操作するプロファイル
HFP (Hands-Free Profile) : ハンズフリーで通話 / 携帯電話を操作するプロファイル
AVRCP (Audio/Video Remote Control Profile) : AV 機器をリモートコントロールするプロファイル
NFC (Near Field Communication) : さまざまな機器間で近距離無線通信を行うための技術

1. 部品の構成

本製品をお使いになる前に、すべて揃っているか確かめてください。

- 1: ヘッドホン
- 2: マイクロ USB ケーブル
- 3: ヘッドホンコード
- 4: 保証書（欧州 / 日本）
- 5: 取扱説明書（本書）

2. 各部の名称

本書の表紙裏面にあります図 2 と合わせてご参照ください。
各ボタンの機能については、使い方をご確認ください。

- | | |
|----------------|--------------|
| 1: N マーク | 8: (+) ボタン |
| 2: (▶/⏮) ボタン | 9: (▶▶) ボタン |
| 3: (⏭) ボタン | 10: (◀◀) ボタン |
| 4: LED インジケータ | 11: (—) ボタン |
| 5: マイクロ USB 端子 | |
| 6: ヘッドホンジャック | |
| 7: マイク | |

3. 充電する

ご使用になる前に、本機を充電する必要があります。
充電には付属の「マイクロ USB ケーブル」を使用する必要があります。

付属のマイクロ USB ケーブルを本機に接続し、もう一方の USB プラグをパソコンの USB 端子に接続します。(図 3 参照)

- ・ 充電が始まると、本機の LED ランプが赤く点灯します。
- ・ 電源が入っている状態で充電すると、本機の電源が自動的に切れます。
- ・ 充電は約 5 時間で完了し、充電完了後は LED ランプが自動で消灯します。
- ・ 充電完了からの使用可能時間は、連続通信時で最大 32 時間、連続待ち受け時で最大 800 時間です。
- ・ 電池の充電残量が少なくなると、本機から約 3 分ごとに音が鳴ります。

※ 充電時間や使用時間は温度環境や使用頻度により異なる場合があります。



ご注意

- ・ 充電温度範囲内 (5℃～35℃) で充電を行ってください。
- ・ パソコンが省電力モードになると充電できません。
- ・ マイクロ USB ケーブルは、コネクタの向きや形状をよく確認してから接続してください。
- ・ 充電中は Bluetooth 機能を使用できません。
充電中に音楽再生する場合は、P.12 の<ヘッドホンコードの使い方>をご参照ください。

4. ペアリングする

本機で、Bluetooth 機器の音楽を聞いたり通話するには、事前にペアリングを行う必要があります。

ペアリングの方法は、ご使用の Bluetooth 機器の取扱説明書もあわせてご覧ください。

- ① 本体の電源が切れている状態で、(○) ボタンを長押しし、ペアリングモードに入ります。
 - LED ランプが青と赤の交互に点滅した状態がペアリングモードです。(図 4 参照) 交互に点灯したら (○) ボタンを離してください。
 - ペアリングモード中にペアリングが完了しない場合、約 10 分後に電源が切れます。
- ② 相手側 Bluetooth 機器の電源を入れてペアリング操作を行い、本機を検索します。
 - 相手側 Bluetooth 機器は、本機の近く (1 m 以内) に置いてください。
 - 本機は、相手側 Bluetooth 機器の画面に 'SE-MJ771BT' と表示されます。
 - 詳しくは接続する相手側 Bluetooth 機器の取扱説明書をご確認ください。
- ③ 相手側 Bluetooth 機器がペアリングされたことを確認します。
 - 相手側 Bluetooth 機能搭載機器の画面に表示されている 'SE-MJ771BT' を選択します。
 - LED ランプが 3 秒毎に青色の 1 回点滅になったらペアリングの完了です。
 - 本機の PIN コードは '0000' に設定されています。
 - 相手側 Bluetooth 機器から PIN コードを要求された場合は '0000' と入力してください。

Bluetooth 機器と接続する

- 本機の電源が入った状態の時に、相手側 Bluetooth 機器で接続操作をします。
- 機器によってはペアリング完了後、自動的に接続される場合があります。

Bluetooth 機器との接続を切断する

- (○) ボタンを約 5 秒間長押しし、本機の電源を切ります。



ご注意

- 機器によっては音楽再生時には A2DP、ハンズフリー使用時には HFP または HSP を指定して接続する必要があります。
- 操作 / 設定方法は各 Bluetooth 機器の取扱説明書をご参照ください。
- 一度ペアリングすると自動で接続されますが、機器と接続できなくなってしまうときは再度ペアリングを行ってください。
- 本機は 8 台分の Bluetooth 機器のペアリング情報を登録できます。9 台目の機器とペアリングすると、最初に登録した機器のペアリング情報が消去されます。
- 消去された機器と本機を再接続する場合は再度ペアリングを行ってください。
- ペアリングした機器を使用するときは、本機の電源を入れたあと、ペアリング相手の Bluetooth 機器側で接続操作を行うだけで使用できます。

5. NFC を使ってペアリングする

NFC 搭載のスマートフォン / タブレット機器をかざすと、Bluetooth のペアリングや接続 / 解除が簡単にできます。

詳しくは、NFC 搭載機器の取扱説明書をご覧ください。

- ・対応 OS : Android 4.2 以降
 - ・お使いのスマートフォン / タブレット機器によっては、NFC の受信感度が弱くワンタッチ接続ができない場合があります。
- また、NFC 搭載機器が近くに複数ある場合には、ペアリングしたい機器とは異なる機器にペアリングしてしまう場合があります。
- その場合は“4. ペアリングする”の手順に従って接続を行ってください。

接続のしかた

- ① 本体の電源が切れている状態で、(Ⓛ) ボタンを長押しし、ペアリングモードにします。
- ② L 側ハウジング部にある ‘N’ マークに、接続する機器の ‘N’ マークをかざします。(図 5 参照)
- ③ 機器が自動的にペアリングを開始します。
LED ランプが 3 秒毎に青色の 1 回点滅になったらペアリングの完了です。

※接続できる機器は 1 台です。

解除のしかた

本機と接続している状態で、L 側ハウジング部にある ‘N’ マークに相手機器の ‘N’ マークをかざします。

接続が自動で解除されます。

相手側 Bluetooth 機器の仕様によっては、NFC で解除できない場合があります。その場合は、“4. ペアリングする”の Bluetooth 機器との接続を切断する”を行ってください。

6. 音楽を聞く

本機で音楽を聞くには、事前にご使用の Bluetooth 機器とオーディオプロファイル A2DP でペアリングする必要があります。
ペアリング操作方法は P.10 をご参照ください。

- ① 本機の電源が切れている状態で、(Ⓛ) ボタンを約 3 秒間長押しします。
本機の電源が ON になり、LED ランプが青色に点滅します。
 - ② 相手機器の Bluetooth 機能を ON にします。
ペアリングが完了していると自動で接続されます。
- ※ 自動的に接続しない場合や異なる Bluetooth 機器と接続される場合は、相手機器を操作してください。

音楽再生の操作

相手側 Bluetooth 機器が AVRCP に対応しているときは本機側で以下の操作ができます。

- 1 回押し
- (+) ボタン : 音量が上がります。
- (-) ボタン : 音量が下がります。
- (▶▶) ボタン : 次の曲またはチャプターに進みます。
- (◀◀) ボタン : 曲またはチャプターの頭に戻ります。
- (▶◀) ボタン : 再生または一時停止します。

※ 音量を最大または最小にしたときは本機からビーと音が鳴ります。

※ 相手側 Bluetooth 機器での音量調整も可能です。

- ※ 相手側 *Bluetooth* 機器の仕様によっては上記操作、及び相手機器での操作ができない場合があります。
- ※ 相手側 *Bluetooth* 機器の仕様によってはワンセグの選局できない場合や、音声が届かない場合があります。ご使用の *Bluetooth* 機器の取扱説明書もあわせてご覧ください。
- ※ 相手側 *Bluetooth* 機器の仕様によっては音楽再生用の設定が必要になる場合があります。ご使用の *Bluetooth* 機器の取扱説明書もあわせてご覧ください。
- ※ 相手側 *Bluetooth* 機器の仕様によっては音楽再生用のアプリが自動で起動する場合や、一時停止 / 再生が出来ない場合があります。ご使用の *Bluetooth* 機器の取扱説明書もあわせてご覧ください。

ヘッドホンコードの使い方

付属のヘッドホンコードを使用して音楽再生が可能です。



ご注意

- ・ ヘッドホン側にストレート型プラグ、再生機器側に L 型プラグを接続してください。(図 6 参照)
- ・ プラグは奥までしっかり差し込んでください。挿入が不完全ですと、本体からの出力が小さいなど不具合の原因になります。
- ・ ヘッドホンコード使用中は *Bluetooth* 機能を使用できません。
- ・ 電源が入っている状態でヘッドホンコードを使用すると、電源が自動的に切れます。

7. 通話する

本機で通話するには、事前にご使用の *Bluetooth* 機器とハンズフリープロファイル HFP または HSP でペアリングする必要があります。

ペアリング操作方は P.10 をご参照ください。

※ HFP、HSP 両方のプロファイルに対応している場合は、HFP で接続してください。

- ① 本機の電源が切れている状態で、() ボタンを約 3 秒間長押しします。本機の電源が ON になり、LED ランプが青色に点滅します。
 - ② 相手機器の *Bluetooth* 機能を ON にします。ペアリングが完了していると自動で接続されます。
- ※ 自動的に接続しない場合や異なる *Bluetooth* 機器と接続される場合は、相手機器を操作して接続してください。

通話時の操作

相手側 *Bluetooth* 機器が AVRCP に対応しているときは本機側で以下の操作ができます。

● 1 回押し

(+) ボタン : 音量が上がります。

(-) ボタン : 音量が下がります。

(/) ボタン

● 着信時 1 回押し : 通話します。もう一度押すと通話を終了します。

● 着信時長押し : 着信を拒否します。

● ● 2 回押し : リダイヤルします。

音楽を聞いているときに着信があった場合も同じように操作します。

※ 音量を最大または最小にしたときは本機からビーと音が鳴ります。

※ 相手側 *Bluetooth* 機器での音量調整も可能です。

※ 相手側 *Bluetooth* 機器の仕様によっては上記操作、及び相手機器での操作ができない場合があります。

※ 相手側 *Bluetooth* 機器の仕様によっては通話用の設定が必要になる場合があります。ご使用の *Bluetooth* 機器の取扱説明書もあわせてご覧ください。

8. LED ランプについて

動作	LED インジケーター
<i>Bluetooth</i> 機器と接続していない状態	青色 LED が 3 秒ごとに 2 回点滅
ペアリングモード	赤色 LED と青色 LED が交互に点滅
<i>Bluetooth</i> 機器と接続している状態	青色 LED が 3 秒ごとに 1 回点滅
充電中	赤色 LED が点灯

9. 故障かな？と思ったら

症状	処置
電源が入らない	本機を充電してください。
充電ができない	パソコンの電源が入っているか確認してください。 パソコンが省電力モードではないことを確認してください。 付属のマイクロ USB が本機及びパソコンにしっかり接続されているか確認してください。
ペアリングができない	本機及び相手機器をなるべく近づけてからペアリングを行ってください。
<i>Bluetooth</i> 接続ができない	本機及び相手機器の電源が入っているか確認してください。 相手機器の <i>Bluetooth</i> 機能が ON になっているか確認してください。
音が出ない（音楽再生時）	本機及び相手機器の電源が入っているか確認してください。 相手機器と A2DP で <i>Bluetooth</i> 接続がされているか確認してください。 相手機器の音楽が再生されているか確認してください。 本機及び相手機器の音量が小さくないか確認してください。
音がひずむ（音楽再生時）	周囲に 2.4 GHz 帯の電磁波を発生する機器（電子レンジ、無線など）や遮蔽物がいないか確認してください。

ハンズフリー操作ができない	相手機器と HFP または HSP で <i>Bluetooth</i> 接続がされているか確認してください。
	相手機器と A2DP で <i>Bluetooth</i> 接続がされている場合、機器の仕様によっては切り換えが必要です。
通信距離が短い、音が途切れる	周囲に 2.4 GHz 帯の電磁波を発生する機器（電子レンジ、無線など）や遮蔽物がないか確認してください。
NFC を使って接続できない	相手機器が NFC を搭載しているか確認してください。
	相手機器の NFC 設定を有効にしてください。
	本機と相手機器のかざす位置が正しい位置にあるか確認してください。
	相手機器のケースやカバーをはずしてお試しください。

保証とアフターサービス

保証書（別添）について

保証書は、必ず「販売店名・購入日」などの記入を確かめて販売店から受け取っていただき、内容をよくお読みのうえ、大切に保管してください。

保証書に販売店名や購入日の記載がない場合は、本製品のご購入の際に受け取られた、購入日が明記されている購入証明書（レシート、納品書、受注メールなど）が必要となります。保証書とともに大切に保管してください。

保証期間は購入日から 1 年間です。

補修用性能部品の最低保有期間

この製品の補修用性能部品の最低保有期間は製造打ち切り後 6 年です。性能部品とは、その製品の機能を維持するために必要な部品です。

連絡していただきたい内容

- | | |
|----------------------|-------------------|
| ● ご住所： | ● 型番：SE-MJ771BT |
| ● お名前： | ● お買い上げ日 |
| ● お電話番号： | ● 故障の状況（できるだけ詳しく） |
| ● 製品名：ワイヤレスステレオヘッドホン | |

■ 保証期間中は：

修理に際しては、保証書をご提示ください。保証書に記載されている当社の保証規定に基づき修理いたします。

■ 保証期間が過ぎているときは：

修理すれば使用できる製品については、ご希望により有料で修理いたします。

商品についてのご相談窓口のご案内

※番号をよくお確かめの上でおかけいただきますようお願いいたします

商品の取り付け・組み合わせなどについては、お買い求めの販売店様へお問い合わせください。

家庭用オーディオ/ビジュアル商品についてのご相談窓口

- 商品のご購入や取り扱い、故障かどうかのご相談窓口およびカタログのご請求について

カスタマーサポートセンター

受付時間 月曜～金曜9:30～18:00、土曜9:30～12:00、13:00～17:00
(日曜・祝日・弊社休業日は除く)

- 電話 【固定電話から】 0120-944-222(無料)
【携帯電話・PHSから】 0570-037-620(ナビダイヤル・有料)
- ファックス 0570-037-602(ナビダイヤル・有料)
- インターネットホームページ <http://pioneer.jp/support/>
※商品についてよくあるお問い合わせなど

修理についてのご相談窓口

※番号をよくお確かめの上でおかけいただきますようお願いいたします

修理をご依頼される場合は、取扱説明書の『故障かな?と思ったら』を一度ご覧になり、故障かどうかご確認ください。それでも正常に動作しない場合は、①型名②ご購入日③故障症状を具体的に、ご連絡ください。

修理受付窓口

受付時間 月曜～金曜9:30～18:00、土曜9:30～12:00、13:00～17:00
(日曜・祝日・弊社休業日は除く)

- 電話 【固定電話から】 0120-5-81028(無料)
【携帯電話・PHSから】 0570-037-610(ナビダイヤル・有料)
- ファックス 0120-5-81029(無料)
- インターネットホームページ <http://pioneer.jp/support/purpose/repair/>
※インターネットによる修理のお申し込みを受け付けております

部品のご購入についてのご相談窓口

※番号をよくお確かめの上おかけいただきますようお願いいたします

● 部品（付属品、取扱説明書など）のご購入について

部品受注センター

受付時間 月曜～金曜9:30～18:00、土曜9:30～12:00、13:00～17:00
（日曜・祝日・弊社休業日は除く）■ 電話 【固定電話から】 0120-5-81095(無料)
【携帯電話・PHSから】 0570-057-140(ナビダイヤル・有料)

■ ファックス 0120-5-81096(無料)

■ インターネットホームページ <http://pioneer.jp/support/purpose/parts/flow/>
※FAXでご注文の際は上記ホームページの付属品購入の流れを参照のうえ、
付属品注文票をダウンロードしてご利用ください

<各窓口へお問い合わせ時のご注意>

「0120」で始まる電話番号は、携帯電話・PHS・一部のIP電話などからは、ご使用になれません。
ナビダイヤルは、携帯電話・PHSなどからご利用可能ですが、通話料がかかります。
また一部のIP電話などからは、ご使用になれません。
正確なご相談対応のために折り返しお電話をさせていただく場合がございますので発信者番号の通知にご協力いただきますようお願いいたします。

平成27年6月現在 記載内容は、予告なく変更させていただくことがありますので
予めご了承ください。

©2015 オンキヨー&パイオニアイノベーションズ株式会社 禁無断転載

Inquiries regarding this product. / Demandes de renseignements à propos de ce produit.

Discover the benefits of registering your product online at <http://www.pioneer.co.uk>
(or <http://www.pioneer.eu>).

Découvrez les nombreux avantages offerts en enregistrant votre produit en ligne maintenant sur
<http://www.pioneer.fr> (ou <http://www.pioneer.eu>).

Bitte nutzen Sie die Möglichkeit zur Registrierung Ihres Produktes unter
<http://www.pioneer.de> (oder <http://www.pioneer.eu>).

Registra il tuo prodotto su <http://www.pioneer.it> (o <http://www.pioneer.eu>)
e scopri subito quali vantaggi puoi ottenerne!

Ontdek nu de voordelen van online registratie! Registreer uw Pioneer product via
<http://www.pioneer.nl> - <http://www.pioneer.be> (of <http://www.pioneer.eu>).

Registre su producto en <http://www.pioneer.es> (o en <http://www.pioneer.eu>)
Descubra los beneficios de registrarse on-line:

Зарегистрируйте Ваше изделие на <http://www.pioneer-rus.ru> (или
<http://www.pioneer.eu>).

Ознакомьтесь с преимуществами регистрации в Интернет.

© 2015 Onkyo & Pioneer Innovations Corporation
All rights reserved.

© 2015 Onkyo & Pioneer Innovations Corporation
Tous droits de reproduction et de
traduction réservés.

Onkyo & Pioneer Innovations Corporation

2-3-12, Yaesu, Chuo-Ku, Tokyo 104-0028, Japan

オンキヨー&パイオニアイノベーションズ株式会社

〒104-0028 東京都中央区八重洲2丁目3番12号

Инновационная Корпорация О энд Пи

2-3-12, Яэсу, Чую-ку, г. Токио, 104-0028, ЯПОНИЯ

<Germany>

Hanns-Martin-Schleyer-Straße 35, 47877 Willich, Germany

Tel: +49(0)2154 913222

<UK>

Anteros Building, Odyssey Business Park, West End Road, South Ruislip, Middlesex,
HA4 6QQ United Kingdom

Tel: +44(0)208 836 3612

<France>

6, Avenue de Marais F - 95816 Argenteuil Cedex FRANCE

Tel :+33(0)969 368 050