



Getting Started

What's in the box



Box



EZ Button




EZ Pen x2



Pen tip x2



Screw Cap x2



Quick Manual

Quick buttons

- Show pre-defined application
- touch the button
- Execute pre-defined application
- press the button
- Save applications
- press&hold the button

LED Indicator

- Check the battery status in the LED indicator.
- Green : Full battery
- Red : Low battery
- Blue : Power On

D3

Charging port

- In order to recharge Insert the pen into the charging port with the charger hole facing downwards.

USB connector

- Connect USB connector to the USB port on both sides of IFTD.

Screw hole

- Use the screw hole to mount EZ Button to IFTD.

Wheel scroll & button

- Click the wheel to switch between pen and eraser functions.
- Use the scroll to modify the ink / eraser thickness or to page up & down.

Home button

- Click the home button to switch between ink, cursor or windows menu functions.

Charger hole

- Insert it into the charging port in EZ holder or EZ Button.
- Full charging time : MAX 2.5 hours
- Continuous uptime : More than 10 hours
- Continuous standby time : More than 6 days



2.5H

Pen tip

- Specially designed pen tip diffuses light reflection and maximizes touch experience.


D3

LED Indicator

- Check the battery status in the LED indicator.
- Blue : More than 50%
- Magenta : More than 20%
- Red : Below 20%


Sliding button

- Pen color selection
- 4 color (Red, Blue, White, Black)



How to install

Insert the EZ buttons into the USB ports on the sides of the display and fix the screws into the screw holes and close them with screws caps.



Discharge protection cap

Remove discharge protection cap before the first use.

How to recharge

In order to recharge insert the pen into the charging port with the charging hole facing downwards. The LED in the EZ Button turns on when charging starts.

D3

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

