

BR70 manual.

Bluetooth mode.

1. Bluetooth version: Bluetooth 4.2, support HSP, HFP, A2DP, AVRCP protocol, sound of ringtone status, Bluetooth device name is BR70.
2. Press the button on the button to start up, and the bluetooth light blue light will be switched on after power on, and the sound box will ring the bell.
3. The blue light to 100 ms flash into the matching condition, mobile search to confirm BR70 device name can be connected, if you need a password input (0000), the connection is successful after blue light, normally on speaker rings prompt music played in the process of blue light to 1000 ms slow flash. It has been paired with the mobile phone to turn on the bluetooth and then turn on the speaker automatically.

TF card mode.

1. When the speaker does not have the TF card device, the boot enters the bluetooth mode, and the insertion of the TF card speaker will automatically detect the mode of playing in the TF card. If the speaker has a tf-card device, it will enter the TF card mode directly after it is switched on.
2. During the playback, the blue light of the indicator light is flashing at 1000ms, and the blue light is temporarily suspended.

U disk mode

1. When the speaker is not inserted into the usb device, it will enter the bluetooth mode, and the usb flash box will be automatically detected into the usb flash drive mode. If the speaker has a usb flash drive device, it will enter the usb flash mode directly after it is switched on.
2. During the playback, the blue light of the indicator light is flashing at 1000ms, and the blue light is temporarily suspended.

Radio reception mode.

1. Press the power button to enter the receiving mode, and the radio frequency is 87.5~108.0MHZ.
2. Insert the USB charging cable or 3.5mm stereo audio cable as the external antenna.
3. The automatic search indicator light blue light will flash with 100ms, and the blue light will always be on.

LINE mode

1. Insert one end of the 3.5mm audio line into the opening of the audio box AUX, and the speaker will automatically detect the entering AUX mode, and the other end is 3.5mm plug to connect the phone or computer.
2. In AUX mode, the blue light of the indicator is slow flashing at 2000ms.

the charging

1. Plug the USB cable into the speaker box to connect the 5V charger or the computer to charge the speaker's built-in battery;
2. When charging, the "charging" indicator is red and green, which is full of red and green light;

PC function

1. Use the USB cable to connect the speaker to the computer, the speaker has the sound card function, can play the music on the computer.
2. When the speaker has a TF card device, the speaker is connected to the computer as a card reader.

Low power protection.

1. When the battery voltage of the speaker is less than 3.3v, it will send a low telegraph alarm bell, and the battery voltage is lower than 3.1v and the speaker automatically shuts off when it exceeds 15S.

Mode circulation: BT, USB, TF, FM, LINE.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.