



Robbi

USER MANUAL

Contents

Introduction	4
LED Indicators	5
What's Included	6
Wi-Fi Requirements	7
Mobile Device Requirements	7
Download the Momentum App	8
Setup	9
• Pairing	9
• Pairing additional Momentum Devices	11
Setting up Rules	11
• Adding a New Rule	11
• Mobile Alerts	12
Storage Options	13
• Momentum Capture Cloud Storage	13
• Micro-SD Card Storage	14
Your Dashboard	15
Camera Functions	16
• Watching Live Video	16
• Taking Photos	17

• Recording Videos	17
• Audio Functions	17
Viewing Recorded Photos and Videos	19
Saving and Deleting recordings	20
Device Settings	21
Deleting Devices	21
Siren Activation	22
Restoring Forgotten Passwords	22
Resetting the Camera	23
Troubleshooting	24
About Momentum	24

© 2016 Momentum

Momentum is a registered trademark in the United States. Apple and iPhone are registered trademarks of Apple Inc. Google, Google Play, and Android are trademarks of Google LLC. All other brands and product names are or may be trademarks of their respective owners.


Note: Screen shots and procedures described in this manual are subject to change without notice. The latest Momentum User Guide is always available on our website at <http://www.momentumcam.com>.

Introduction

The Momentum **Robbi**™ is an indoor 1080P HD Smart Home Security Camera with wireless monitoring capabilities that can be accessed from anywhere where you have an internet connection. It's great for indoor surveillance for your home, office, shop, warehouse, or other locations. All you need is a:

1. Wireless internet connection, and
2. Mobile device (Android or iOS)
 - See page #7 for device requirements.

Use your smartphone and/or tablet to use and manage the camera and app's functions remotely.



LED Indicators

Robbi displays an LED indicator light that lets you know what it is doing.

Solid Red Light: Camera is booting up.

Slow Blinking Red Light: Disconnected from Wi-Fi.

Double Blinking Blue Light: Ready to connect to Wi-Fi.

Blinking Blue Light: Robbi is connected to Wi-Fi.

Solid Blue Light: User is currently live streaming.



What's Included

Robbi Camera



AC Power Adaptor



USB Cable



Mounting Sticker



Wall Anchors x 2



Screws x 2



Wi-Fi Requirements

Robbi requires a 2.4GHz router (802.11b/g/n) for Wi-Fi connectivity. This is a standard home Wi-Fi router.

You will need your Wi-Fi name and password when pairing your mobile device and camera.

Note: If you are using a 2.4GHz + 5GHz dual band router, create separate SSID names for each band on your Wi-Fi router settings page. This will make it easier for you to select the 2.4GHz band for camera setup.

Mobile Device Requirements

The Momentum app requires a smart phone or tablet device that runs on Android or iOS. Please see the in-app description for device compatibility for the most up-to-date info.

Download the Momentum App

Download and install the Momentum app on your mobile device.

Search for **Momentum** on the Google Play Store for Android devices, or on the Apple App Store for iOS devices. You may also scan the QR code below from your mobile device to route you directly to the app.

Make sure the app logo you download matches the one shown below.



momentum



Create an Account

If you don't already have a Momentum account, you will need to create one. To create a new account, follow the in-app instructions.

Setup

To begin using your Momentum device you will first need to pair it to your Momentum account and then connect it to your Wi-Fi network.

Pairing

IMPORTANT: Make sure your mobile device is **connected to the same Wi-Fi network** as the one you will be connecting the camera to. (This is required just for the pairing process; feel free to disconnect your mobile device from the Wi-Fi network after pairing is complete if you wish to do so.)

1) Power on the Robbi camera.

Once your Robbi has been powered on, it should already be put into pairing mode. There will also be a sound played to notify you that it's ready to connect.

- If it's not in pairing mode, you will need to hold the reset button for 10 seconds. You should hear a recording play that the is ready to connect.

2) Open the app and select Robbi.

From the Momentum app, select **Pair device**, then select **Robbi**.

3) Connect to Robbi's Wi-Fi access point.

When prompted in the app, go to your mobile device's Wi-Fi settings. You should see a Wi-Fi network option for "**Robbi**". Tap the "**Robbi**" network to connect, then return to the Momentum app again.

(Note: Newer Android versions may require you to turn on location services.)

4) Enter Wi-Fi credentials.

Your Wi-Fi network will automatically be detected. Enter in the password (if any) for the Wi-Fi network.

5) Name your device.

Select from the provided list of names or create a custom name for your new camera. Once you've finished naming your device, your setup is complete!

Pairing additional Momentum Devices

To pair additional Momentum devices, select **Pair Device** in the app's menu and repeat steps 1 – 5 that were used in pairing your initial Momentum device.

Setting up Rules

Your Robbi camera will record video when rules have been set through the Momentum App. **Rules** allow your device to activate and monitor the area while you are not watching the live stream.

Adding a New Rule

Select the device you want to create a rule for, then add the days of the week and times of the days you want the rule to be set in place. Your camera will then automatically record a video when motion or sound is detected.

Note: Scheduled times cannot carry over past midnight. (i.e. cannot schedule 9PM-1AM. Must schedule two different times: 9PM-11:59PM; 12AM-1AM)

Mobile Alerts

Once you have created a **Rule** set to your chosen parameters, you will receive a notification alert to your mobile device if an event is triggered.

If you'd like to stop receiving alerts, you can delete the Rule or turn it off from your mobile device's notification settings for the Momentum App.

You may also view all your previous alerts by tapping the **Activity** tile on your Dashboard.

Storage Options

Robbi can save your recorded videos or pictures through the **Momentum Capture Cloud Storage** subscription plan or with your own **micro-SD card** inserted into the device. The micro-SD card slot can be found on the side of the camera device. (see pg. 4).

Momentum Capture Cloud Storage

After you initially pair a Momentum device to your Momentum account, you will be provided FREE cloud recordings that last for 24hrs. Recordings can be found in the **Activity** page. You may also upgrade to a higher tier paid storage plan directly from the app **Subscriptions** tab or from momentumcam.com.

Micro-SD Card Storage

You also have the option to use your own micro-SD card (up to 128GB) instead for back-up storage.

Insert the micro-SD card into Robbi's micro-SD slot on the side of the camera. The camera will automatically record events and camera photos you take directly into the micro-SD card as back-up storage.



Once the memory capacity has been reached on the card, the new recording will loop over and begin to overwrite the earliest saved recordings.

To access the back-up micro-SD card recordings, go to the camera's settings and select "**View Camera Backup**".



Your Dashboard

Your dashboard is your app's home screen where you can view and access your paired devices. You can rearrange the **Tiles** on your dashboard by tapping the **Pencil** icon in the top right corner of the app. You can also make some device tiles larger or smaller when editing your dashboard. Be sure to tap the **Save Dashboard** button at the bottom when you are finished editing.




Camera Functions

Robbi has several functions you can control through the Momentum app.

Watching Live Video

To view live video stream, first select the camera you would like to view. Rotate your mobile device to view in either portrait mode or landscape mode.

In **portrait mode** you can use your fingers to pan around the video feed. **Landscape mode** will display the video in full screen mode. You may use your fingers to pinch to zoom in on the video as well.




Taking Photos

Tap the **Photo** icon to save a screenshot while watching live video.

Recording Videos

Tap the **Record Video** icon to start recording. The video will record based on a 20 second clip.




Audio Functions

You can engage in two-way conversations while you're in Robbi's live video stream option. Note that the audio will only go through one source (camera or app) at a time.

To speak through the app to Robbi's speakers, tap on the **Microphone** icon. You must tap on the icon again to de-select it to begin hearing Robbi's side again.


To only listen through Robbi's audio, make sure the **Microphone** icon is de-selected.



Microphone Button

Viewing Recorded Photos and Videos

Tap the **Activity** tile to view recorded videos, captured photos, or alerts for a specific day. You can also access the activity list from the live camera view.



When you select a video in your activity list, it will begin playing back automatically. To rewind or fast forward, tap the video to reveal the video playback controls.

For back-up micro-SD card recordings, you may access them from the camera settings and selecting the “**View Camera Backup**” button (*see pg.14*).

Saving and Deleting Recordings

Recorded footage will be automatically saved onto the cloud for a predetermined time (dependent on which plan the camera is on).

If you have inserted your own micro-SD card and set up a rule for recordings, footage of those recordings will be also be saved on the micro-SD card. When the card's storage becomes full, it will automatically loop back over to record over your earliest recordings.

However, if you'd like to save your cloud or micro-SD card recordings to your mobile device's local storage, you can do so while you're viewing the specific recording. Press the 'download' button at the bottom right corner to save a copy of the footage onto your mobile device's local storage.

You may also delete the recording permanently off your cloud storage or micro-SD card swiping left on the recording on the respective activity list page.

Device Settings

Under the Menu tab, you will find **My Devices**. Select your device and go to the **Settings** option. Here you may change your device's name, adjust the camera's image-quality, motion/sound detection levels, toggle the night vision, edit motion zones, and set the siren settings.


Deleting Devices

If you'd like to remove a device from your account, tap the **Menu** and go to **My Devices**. Select the specific device, select **Settings**, and tap **Remove Device from Account** at the bottom of the screen.


Siren Activation

Your Robbi has a built-in siren that is loud enough to scare away any perpetrators.

You can activate the siren from the **Siren Tile** or the **live view screen**.



Siren Tile



Live View Screen

Restoring Forgotten Passwords

If you've forgotten your login password, tap on the **Forgot Password** button at the sign in page. You will receive an email with instructions to guide you through the rest of the way.

Resetting the Camera

If your camera is having connection issues, try these steps to correct the issue.

Power cycle the Camera

1. Unplug the camera, wait 10 seconds, then plug it back in. If it still does not fix the issue, trying resetting the camera.

Reset the Camera

1. To reset your Momentum device, hold the **Reset** button on the back of the camera for about 10 seconds. During the reset sequence, the LED indicator light on the front of the camera will first display a solid red, then double blinking blue.
2. You will then need to re-pair the camera again. Follow the same initial pairing process (see pg. 9).

Troubleshooting

For further assistance, please go to

<https://www.support.momentumcam.com>.

About Momentum

Momentum provides an easy-to-setup home security camera that connects to your smart phone or tablet giving you real-time video streaming and two-way voice communication – anywhere, anytime. Momentum subscribers also have access to IOT cloud-based storage for camera-captured videos from a user-friendly mobile app. Whether you want to check on your babysitter, are wondering what your pets are doing, or are leaving for vacation, you'll always have an eye in your home with Momentum.

For more information, please visit

www.momentumcam.com or contact us at

help@momentumcam.com.

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Apollo Tech USA, Inc.

8608 Utica Ave. #220,

Rancho Cucamonga, CA 91730

Customer Service: +1 888 818 0436

E-mail: help@momentumcam.com

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.