

6 in



INSTRUCTIONS:

- Press the power button to turn it on/off, the LED protected indicator will turn red if it is working properly.
- Place your phone onto the top charging surface of the surge protector and align the device with the center of the charging surface or the device will not charge. Remove credit cards or any card with a magnetic strip to prevent damage to the cards before charging.
- The charging stand allows for wireless charging up to 15W. Charge time will vary by device.
- The wireless charging is compatible with newer devices as well as wireless charging-enabled devices; consult your devices user guide to ensure compatibility.

Model: SPC46 Input: 125VAC 15A 60Hz 1875W Output: USB-C: 5V≐3A, 9V≐2.22A, 12V≐1.67A USB-A: 5V≐2.4A Wireless Charger: 15W Total output: 35W Max FCC ID: 2AO23-SPC46 Type 3 SPD **VPR: 900V (L-N)** US\$50,000 guarantee on equipment Made in Vietnam This product contains a surge protector device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Intertek
5008028 CONFORMS TO UL STD. **817** and 1449

FRONT

4.15 in

6 in



FCC RF exposure statement

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.

Important safety instructions

WARNING Read instructions before use. When using this product, basic precautions should always be followed, including the following:

- DANGER: Electrical cords can be hazardous
- CAUTION: To reduce the risk of electric shock, use in dry indoor locations only
- CAUTION: Risk of electric shock - do not plug into another relocatable power tap or an extension cord
- CAUTION: Do not install this device if there is not at least 10 meters (30 feet) or more of wire between the electrical outlet and the electrical service panel
- CAUTION: This device features an internal protection that will disconnect the surge protective component but will maintain power to the load
 - now unprotected. If this situation is undesirable for the application, follow the manufacturer's instructions for replacing the device
- Misuse can result in fire or death by electrical shock
- Keep children and pets away from cord
- Inspect thoroughly before each use. Do not use if damaged
- Do not mount or support cord set or strings in a manner that can cut or damage wire insulation
- Do not drive, drag, place objects over cords, walk on cord, or unplug by pulling on cord. Always unplug when not in use. Grasp plug to remove from outlet
- Do not run through doorways, holes in ceilings, walls, floors, remove, bend, modify any metal prongs or pins of cord, use excessive force to make connections, or connect a three-prong plug to a two-hole cord. Please be sure to insert plug into outlet correctly
- The interrupting rating of any required external circuit breaker: 15A
- Not for use with: • aquariums or other water-related products • generators and power inverters • medical lift-support products

SAVE THESE INSTRUCTIONS

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@gemsfindyours.com



We welcome any questions you may have at
Target.com/comments or 1-800-910-6874.

BACK

4.06 in