
















 Smart Socket Any problems please follow Gosund on  and consult the service staff -1-	►What's in the Box Smart Socket User Manual ►At a Glance  1. Flame Resistant Material 2. Socket Panel 3. ON/OFF Button 4. Indicator Light 5. Power Plug -2-	NOTE: Press the ON/OFF button to restore the factory setting if you want to erase the plug's current settings. ►Indicator Light Status Blue light blinks every 0.5 second-Easy Mode connection Blue light blinks every 2 seconds- AP Mode connection Red light- Power is ON No light- Power is OFF ►Parameters Input: 100-240V~, 50/60Hz -3-	Output: 10A Max Rated Power: 1200W/120V Wi-Fi Frequency: 2.4GHz ►Install the “Gosund” App 1. Search for Gosund App on App store/Google Play Store, or just scan the QR code below to download.(For iPhone, you can use build-in camera to scan the QR code. For Android, you may need barcode scanner to do that. Please confirm the App icon before downloading.)  -4-	PS: You can also add this smart plug to smart life app directly if you already have it on your phone, it is compatible and works the same way. ►Connect with Your Cellphone Requirements: 2.4GHz Wi-Fi condition at home For 2.4Ghz Wi-Fi You'll Need to Know: 1.If you only have 5GHz Wi-Fi router,you will not be able to complete the connection. 2. If you are using a dual Wi-Fi router and it broadcast 2 Wi-Fi signals, make sure that your phone was connected with the 2.4GHz Wi-Fi signal, it should be the Wi-Fi signal that next to “_5G” . -5-	 3. If you are using a dual Wi-Fi router but it broadcast only 1 Wi-Fi signal, you will have to manage your Wi-Fi router and change the settings to have 2.4GHz Wi-Fi. -6-	 A: For Easy Mode Connection- Blue indicator Light Blink Rapidly (Twice a second). ---> Confirm that the smart plug is well installed ---> Open Gosund app ---> Choose the “+” symbol, -7-	---> “Socket (Wi-Fi)”  ---> Confirm the light status on your plug and follow the App guide. (If you don't see blue light quickly blinking,press On/Off button to reset.) ---> Set a unique name for this smart plug, choose the room location. -8-	
	View Help Confirm Indicator rapidly blink Add Device  -9-	B: AP Mode(Indicator light blinks once every 2 seconds) If the Easy mode connection failed, please remove and install the smart plug into your power outlet again. When you make sure the indicator light is quickly blink again for about 7seconds to plug to AP mode. Once you see the indicator light slowly blink(every 7 seconds), you can start to try the AP mode connection. ---> First go back to the Add Device “+” interface, choose the AP Mode on the upper right corner. -10-	Add Device Ap Mode --->Long press on/off button until the indicator light flashes slowly; --->Make sure the indicator light is flashing slowly and confirm it in App; --->Choose your 2.4G Wi-Fi and enter the password and confirm it in App; -11-	--->Tap “Connect now” and choose Wi-Fi hotspot named “SmartLife-xxx”, then go back to Gosund application; --->Wait till successful configuration and then tap “Completed”.  -12-	►Getting to Know Gosund App  Set schedule Set device names Set timer -13-	Note: edit the default names in this interface, for better management. ►Create Scenes/Groups You can create certain scenes and groups on Gosund App, it allows you to control different smart devices in different rooms at the same time. -14-	No Scenes, please add. Add smart  -15-	►Device Sharing If you want to give others the permission to control your smart plug, you can authorize that by device sharing function. Go to the Gosund app --->Choose the device you want to share --->Choose Edit Button --->Choose shared devices --->Add sharing--->Enter his/her Gosund account --->Search and complete. -16-

►How To Connect with Amazon Alexa Requirements: 1.Amazon Alexa Device and Alexa App 2.The Smart Plug connected with Gosund App 3.Gosund App user ID and password. Add Gosund as a “Skill” for Alexa Open Alexa app and choose Skills & Games --> Search for Gosund -->ENABLE TO USE -->Enter the Gosund account	-->Authorize to use -->Choose Gosund. And then, the devices you added on will sync to Alexa App. You can also ask Alexa to discover new devices for you in this moment. 	 How to ask Alexa to turn on/off Smart Plug First you need to set exact name for the plug on Gosund app. If not, Alexa may tells you: “Sorry, I can’t find the device	named xxx...” You can say to Alexa “Alexa, turn on/off bathroom plug”, this command will help you to do the work.  Things you can do with Alexa * Voice Control the smart plug * Remote Control the smart plug via Alexa App.	* Add the smart plug to certain groups on Alexa App For other questions about Alexa, please find out with Amazon Alexa support page, or contact us for help directly by email. Tips for using Alexa Voice Control Please make sure the device name you set for the smart plug is unique and recognizable for Alexa voice assistant. You should make sure all the smart devices names at your home are non-repetitive and recognizable for Alexa. Voice assistant system needs the exact	command to do the work. ►How To Connect with Google Home After you connected the smart plugs with Gosund app successfully, you can start to link them to Google Home app: Open Google Home app and find “Set up device” -->Click “Works with Google” -->Search Gosund -->Enter your Gosund account -->Authorize to use.	After that you will see the smart plug in the home page of Google Home as “Linked to you”,but you still haven’t set the device name and assign a home or a room for it. 		 Now click the device that “Linked to you” or open “Works with Google” again to manage your linked devices, follow the steps below and set up the device	
names, rooms and home for the smart plug, you won’t be able to voice control it before you complete that. 	► Trouble Shooting Q: Why my phone connection failed ? A: * You should try both Easy Mode and AP Mode, read page 6-page 14, make sure to follow the guide and try again.	 ► Trouble Shooting Q: Why my phone connection failed ? A: * You should try both Easy Mode and AP Mode, read page 6-page 14, make sure to follow the guide and try again.	* Confirm your home Wi-Fi is 2.4GHz and you entered the correct password during the connection. * Remove&Install the smart plug to start again, see what happens. Contact the after sales service for further help if you still have problems with the connection after following the steps above. Q: Why can’t I voice control it with my Alexa/Google? A: * Make sure you set up smart plug successfully on Gosund app, and they are working fine.	* Make sure you put correct account when you link Gosund as a skill on Alexa/Google App, and you can find it on your skills. * Make sure your Alexa/Google device is working fine. * Check the device names that you set for this smart plug, it should be non-repetitive and recognizable for voice assistant. Also, please make sure your native language is available for Alexa. If you still having trouble to voice control our smart plug after followed all	instructions, do not hesitate to contact us for help. Q: Do I need to set up the device again if I changed my router? A: Yes! you must set up the smart plug again if there is any change of the current Wi-Fi status, either you changed your router or your moved the device to a new house. However, you don’t need to worry if you are just moving it inside your room, with the same Wi-Fi. Q: Why does it turns on/off or comes offline surprisingly ?	A: Check your Wi-Fi status and make sure the electricity is fine. Check if you’ve set timer for it. If everything looks alright, just reset the smart plug on your app again and see what happens. Email to after-sales services if this problem still exists. ►Safety Information This device is for Indoor&Dry condition use only. Make sure the plug electricity is correct for the appliances that you attempt to use with. Do not try to	disassemble this device by yourself, be aware of product damage and safety risks. Keep away from hot, humidity and other extreme environment. This device meets UL94 V-0 flammability standard. ►Warranty 90 days money-back guarantee: If you’re not satisfied with this purchase, you can choose to refund this order within 90 days. 12 months limited warranty: * Device was used in proper technical working condition.	* Covers unartificial failures and defections on this device. Risk of Damage: Not suitable for appliances that exceed 10A Current, be careful. Do not cover if the device was found artificial disassembled. ►Contact Us Friendly reminder: Different App versions may lead to differences in the interfaces, but the description of the function should be the same.	For any inquiries or comments concerning our products, please send email to: service@gosund.com. We will try our best to help you. Manufacturer: Shenzhen Gosund Technology Co., Ltd Website: www.gosund.com Email Support: service@gosund.com.  402-000-0304 V1.0

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

EN

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.

2. This device must accept any interference, including interference that may cause undesired operation of the device.

FR

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;

2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.