


Function Overview

Home Page

After connected successfully, the Base Station will be listed on the home page. And you can see the preview of the first camera you connected to the Base Station.



Devices:

 : Tap to add a new device.

/: Switch between cameras if you have connected two or more cameras to the Base Station. The camera in green is selected and will be previewd on the home page.

Note: The images of the **Live Video** interface and **Playback** interface correspond to the camera previewed on the home page.

 : Tap to enter the cloud interface of the camera previewed on the home page.

 : Tap to enter the **Base Station Settings**.

Events:

Check events about motion detection and watch the videos recorded when the events happened.

Cloud Services:


Subscribe to cloud services for your cameras as needed.



Manage your account, check instructions for Alexa, clear the cache, get more help and check information about the app.

Live Video

Tap the preview of the camera to watch live video.



- ① Back to the home page.
- ② **Camera Settings.**
- ③ Battery status of the camera. If the battery icon turns red, please charge the camera in time.
- ④ Toggle between HD and FHD; HD is recommended for smoother streaming.
- ⑤ Full screen.
- ⑥ Tap and hold to talk with people near the camera.
- ⑦ Tap to start recording the live video; tap again to end and save it to your phone.
- ⑧ Tap to capture a photo and save it to your phone.
- ⑨ Turn on/off the live audio from the camera.
- ⑩ Tap to check events.
- ⑪ Tap to playback the videos recorded in cloud or memory card.

Video Recording and Playback

There are two options to store videos: by cloud and by a memory card. If you select to store videos by cloud, you can subscribe to a cloud plan as needed, which contains the options of 3/7/30 days rolling storage. If by a memory card, please purchase it by yourself.

Tip:


This system doesn't support full day recording. With motion detection enabled (by default), the Base Station will only record videos when the camera detects motion caused by animals or humans.

By Cloud

Step 1:


Tap **Cloud Services** on the home page to subscribe to a cloud plan for the camera. If you have connected two or more cameras, you need to pay for a cloud plan for each camera.

The Base Station will record videos for 10s when the camera detects motion.




Step 2(optional):

Go to **Camera Settings > Detection Settings** to set a detecting schedule for the camera. Then the camera will only detect motions and record videos at the certain time period, and will enter sleep mode at other times.



Step 3:

Tap  **Playback** on the live video and select  to watch videos recorded in cloud.




- ① Back to live video
- ② Calendar
- ③ Timeline by vertical or horizontal
- ④ Playback recorded videos from cloud/memory card
- ⑤ Timeline
- ⑥ Video playback at the speed of x1, x2, x4
- ⑦ Turn on/off audio
- ⑧ Screenshot
- ⑨ Enter the Events interface
- ⑩ Play/pause

By a Memory Card

Step 1:

Install a memory card(up to 128G) to the Base Station before powering it on, then tap  on the home page to enter the **Base Station Settings**.

Tap **Local Storage** > **Format memory card** to format your card before the first use.



Step 2:

Select how long to record videos when the camera detects motion. You can select from 10s, 20s and 30s and it is 10s by default.

Step 3(optional):

Go to **Camera Settings** > **Detection Settings** to set a detecting schedule for the camera. Then the camera will only detect motions and record videos at the certain time period, and will enter sleep mode at other times.

Step 4:

Tap  **Playback** on the live video and select  to watch the videos recorded in the card.


Notes:

- ① If you have both installed a memory card and subscribed to a cloud plan, the videos will be recorded in the memory card and cloud at the same time.
- ② For videos recorded in the card, you can also watch them on your computer through the VLC media player.
- ③ Recording videos by cloud is recommended for better user experience and more comprehensive functions.

Alarm and Notifications

Alarm Settings of Camera

Tap the preview of the camera on the home page, then tap  on the top right corner to enter the **Camera Settings**.



① About Motion Detection

Go to **Detection Settings**, then you can enable/disable motion detection. If you disable the motion detection, the system will not be able to record videos and send push notifications.

2 About Alarm Sound

Go to **Detection Settings** and switch on the **Alarm Sound**, the camera will give out sound alarm when it detects motion.

3 About Floodlight Alerts

Switch on **Floodlights**, the floodlights will automatically turn on when the camera detects motion at night, which will help you monitor in the dark and get clear colorful videos.

You can refer to the form below to get your desired image effect.

Image Color Option Image Color Floodlights	Auto	Black & White	Colored
Enabled	Colorful by day; black & white at night(but colorful when motion detected)	Black & white all the time	Colorful all the time
Disabled	Colorful by day; black & white at night	Black & white all the time	Colorful all the time(not clear in the dark)

Alarm Settings of Base Station

About Buzzer

Tap  on the home page to enter the **Base Station Settings**.

Turn on Buzzer, the Base Station will give out sound alarm when the camera detects motion.

Notifications

Tap the preview of the camera on the home page, then tap  on the top right corner to enter the **Camera Settings**.

Switch on the **Notifications**, the HeimSmart app will send push notifications to you when it detects motion.

Note:

Please ensure that the motion detection is not disabled.

Device Sharing

This function allows your family members to access the camera. And there is no limit to the number of account sharing.

Step 1:

Instruct your family members to download and install the HeimSmart app, then register an account.

Step 2:

Tap  on the home page to enter the **Base Station Settings**. Go to **Share > +**, enter your family's account to share your device with your family.


Work with Alexa

Your camera is able to work with Alexa. Please log into HeimSmart app, go to home page and tap **Me > Alexa** to get the detailed instructions.


Install the Camera

This wireless security camera system comes with a camera mount and screw kit. Please install the camera as follows.


- 1 Fix the base of the camera mount with the screw kit.



- 2 Screw the camera to the mount.



- 3 Adjust the camera orientation.



FAQ

Q1. Does this model support Google Home/Assistant?

* No, it doesn't support yet.

Q2. Can I use the camera without the Base Station?

* No, the camera and the Base Station must work together.

Q3. The HeimSmart app can not find the Base Station.

* Ensure that you have connected the Base Station to the router through the Ethernet cable.

* Ensure that your phone is connected to the same router's network as your Base Station.

* Press and hold the **Reset/Pair Button** on the Base Station for 10s until you hear a beep to reset it, then try again.

Q4. How many cameras can I connect to a Base Station?

- * 4 cameras can be connected to one Base Station. And you can connect multiple Base Stations to one **HeimSmart** account.

Q5. Can I share it with my friends?

- * Yes. Please go to **Base Station Settings > Share** to share it with your friends.

Q6. I can not receive push notifications.

- * Make sure you have allowed HeimSmart APP to send push notification in the phone's settings.
- * Make sure you have enabled the **Notifications** in the settings of HeimSmart App.
- * Make sure you have enabled motion detection.

Important

1. Do not over charge the battery.
2. Do not put the battery into a fire, or heat the battery. Keep the battery away from fire. Do not store the battery in high temperature environment.
3. Keep the battery away from any sharp objects that could puncture into the battery to avoid risks of explosion and fire.
4. Don't use the battery if it emits an odor, deformation, leakage or any other abnormality.
5. Non-rechargeable batteries are not to be recharged.
6. Batteries are to be inserted with the correct polarity (+ and –).
7. If the battery leakage accidentally gets in your eyes, do not rub your eyes but immediately wash them with clean running water, and then seek medical assistance.
8. Do not dispose of the battery as ordinary municipal waste. Please refer to local regulations on waste disposal of electronic products.



BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY

Specifications

Frequency Range	2412~2484MHz
Transmit Power(EIRP)	< 19dBm

FCC CAUTION

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED WARNING

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance. The minimum distance from body to use the device is 20cm.

L'appareil est conforme aux directives d'exposition aux RF, les utilisateurs peuvent obtenir des informations canadiennes sur l'exposition aux RF et la conformité. La distance minimale du corps pour utiliser l'appareil est de 20 cm.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

 The symbol indicates DC voltage



RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

This product can be used across EU member states.

The device is low power device, it can meet the requirement or the RF exposure.

EU Compliance Statement: Shenzhen VanTop Technology & Innovation Co., Ltd. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of the Directive 2014/53/EU.

A copy of the EU Declaration of Conformity is available online at <https://doc.vantop.com>.

CUSTOMER SUPPORT

North America support@heimvision.com

United Kingdom support.uk@heimvision.com

Deutschland support.de@heimvision.com

France support.fr@heimvision.com

España support.es@heimvision.com

Italia support.it@heimvision.com

日本 support.jp@heimvision.com



@HeimVisionOfficial



@heimvision_official



www.heimvision.com