

1

Manual


2

Package Information

After removing the package, please check if the camera is in good condition and the accessories are complete.




Camera × 1



USB cable&Power adapter × 1



Screw accessory pack × 1




Plotting sheet × 1




Manual × 1

3

Camera Component




4



5

Installation instructions


- Before installing, please make sure the camera has completed device addition on the app.
- Choose an open position and directly position the camera.



6

Quick configuration

- Connecting the IP camera to power socket with a usb cable.





- Make sure your phone is connecting to a 2.4G WiFi network. Then scan the QR code and download the blurams app which is for free.



7


- Register and log into the blurams account.
- Following the app instruction to add the camera.



8

- Live View.


Enter into the video interface on the blurams App, where you can live view the videos or choose the setting options such as voice command, two-way audio, snapshot and video recording.




9

- Parameters Setting.

Tap setting options to enter the setting interface, where various custom setting are available.



Tap to enter



10

FAQs

- Measures against camera-network connection failure:**
 - The camera does not support 5G WiFi network temporarily. Please make sure the WiFi network around the camera is in good condition.
 - Re-plug the power supply to assure the reliable connection.
 - Reconfigure the camera.
 - Customer service E-mail: support@blurams.com.

- Indicator light connotation:**

Green Light	Online
Green Light Blinking	Connecting
Red Light	Starting
Red Light Blinking	Waiting for scan

- Operating temperature:** -10 ~40°C.

11

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

FCC ID: 2ASAQ-A31

12