

Wireless earphones User Manual 	NOTES! 1. To make safety, we strongly recommend you to read the manual and operate strictly according to requirements 2. Please use standard charger to charge the earphone in case of causing battery damaged 3. Repeat charging or discharging the earphone will cause battery performance reduction. It is normal for rechargeable battery 4. Please keep away from fire when using the earphone 5. Please do not make the ports blocked, such as charging port, LED and earphone etc. 6. Please don't use the earphone at high volume or for a long time to avoid affecting the user's hearing 7. Please don't disassemble the earphone for any reason in case of damaging the product 8. Please don't clean the earphone with oil or other corrosive cleaning agents. 9. Please don't use the earphone in potentially dangerous places.	Overview & Introduction Bluetooth earbuds 1 2 3 4 Charging Case 6 7 5 1 Touch keys 2 Indicator light 3 Earphone charging ports 4 Speaker 5 Charging case charge port 6 Change Logo 7 LED light of charging case ACCESSORIES Bluetooth earbuds*2 User manual * 1 Charging case * 1 USB cable * 1 FCC ID:2AVJD-K520B	QUICK PAIRING First Step Press the charging case cover opening button, take out L/R earbuds and wear L/R properly. You will hear "di" prompt sound in 1-3 seconds, indicating that the L/R earbuds have paired successfully. Second Step Open mobile phone's bluetooth setting and search "K520" from the Bluetooth menu of mobile phone to connect pairing successfully. Note: the earbuds will connect to the last paired device automatically when they are turned on again next time. Touch Control Play/Pause When music, click L or R one time Next track When music, click R two times Previous track When music, click L two times Answer/Hang up When incoming call/phone talking, click L or R onetime Reject call When incoming call, click L or R two times Voice assistant When connection, keep click on L or R for 3 seconds Left click 3 times to increase volume Right click 3 times to decrease the volume	Charging Instruction 1. Charge the Earbuds Open the charging case cover, put R earbuds into charging case properly, the charging case indicator flashes once. Put L earbuds into charging case properly and charging case indicator will also flash once, then breathing light cycle is on. The indicator light goes off after the earbuds are fully charged. 2. Charge the Charging Case The charging case indicator light flashes, indicating low power. Please make sure to use safety standard 5V/2A power adapter to charge the earphone. During charging, the indicator light is breathing on and then long-on after fully charged. Specifications Model No.: K520 Bluetooth Version: 5.3+EDR Bluetooth Protocol: HFP/HSP/A2DP/AVRCP Earphone battery: 25mA Charging box battery: 230mA Music/Talking Time: > 5 hours Standby Time: > 100 hours Charging Time: 1 hour Charging Times: Charging case charge earphone > 3 times Notes! The product parameters will be different depending on the model, use mode, environment, etc	FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the Consult the dealer or an experienced radio/TV technician for help. RF warning statement The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
--	---	---	--	---	--

50*70mm