

RLBT-16 CD Boombox Buttons definition




To turn-on the unit, long-press the unit while it is off. And long-press to turn off the unit while it is on; Short-press to change the MODE between Bluetooth-AUX- CD-FM-USB;



Under CD mode, short-press for Play/Pause function, double-press for Play/Stop, long-press for changing the playing mode (OFF->Rep One->Rep All -> Rep Folder -> Random); Under FM Radio mode, short-press to Auto-Search and save Programs, long-press for mute/unmute.

Under USB mode, short-press for Play/Pause function, long-press for changing the playing mode (Order->Rep One->Random->Folder->All);

Under Bluetooth mode, short-press for Play/Pause function, long-press for Disconnect and re-connect the device.



Press V+ or V- to reduce / increase the sound volume;



Under CD mode, short-press to previous song and start playing, long-press for fast rewind.

Under FM Radio mode, Long-press to Auto Search down to previous Program and start playing, short-press to previous stored program;

Under USB mode, short-press to previous song and start playing, long-press to previous folder;

Under Bluetooth mode, short-press to previous song and start playing;



Under CD mode, short-press to next song and start playing, long-press for fast forward.

Under FM radio mode, Long-press to Auto Search down to next Program and start playing, short-press to next stored program.

Under USB mode, short-press to next song and start playing, long-press to next folder;

Under Bluetooth mode, short-press to next song and start playing;

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.