

★ sureshot
slim PRO
know the distance



GETTING STARTED

Thank you for choosing MGI Sureshot SlimPRO Laser.

Before using your MGI Sureshot SlimPRO Laser, it is strongly recommended that you register your device for warranty purposes at **mgigolf.com**

QUICK START INSTRUCTIONS

Here are a few instructions to get you started with your new MGI Sureshot SlimPRO Laser rangefinder.
For a full Product Manual please go to mgigolf.com/pages/mgi-user-manuals



POWER BUTTON

Press once to turn on LCD display
Press again to measure distance

MODE BUTTON

Press and hold for
10 seconds to toggle
between Metres/Yards

Quick press to cycle between:

- Default Mode
 - Scan Mode
 - Pin Loc Mode
- Double press:
- Slope Function



ADJUSTABLE EYEPIECE



CHARGING/ USB PORT

POWER ON

Please ensure your device is fully charged using the USB cable provided. Press the Power button once to activate the internal display, the external case blue light will illuminate indicating the laser is ready to use.



METRES / YARDS

Press and hold the Mode button for 10 seconds to change between metres and yards.

MODES

Quick Press the Mode button to change between Default Mode, Scan and Pin Loc Mode. To activate the Slope function, double-press the Mode button. Double-press again to turn this function off.

CLEANING

Gently blow away any dust or debris on the lenses or use the lens cloth provided. To remove dirt or fingerprints, use the lens cloth and rub in a circular motion. Use of a coarse cloth or unnecessary rubbing may scratch the lens surface and cause permanent damage. For a more thorough cleaning, photographic lens tissue and photographic-type lens cleaning fluid or isopropyl alcohol may be used. Always apply the fluid to the cloth, never directly on the lens. Your laser rangefinder comes with a hard case, lens cloth, battery, carabiner and Quick Start Guide. Always store your SlimPRO laser in the case provided when not in use.

For further information on operating your laser rangefinder, please view the Product Manual on our website

mgigolf.com/pages/mgi-user-manuals

NEED HELP?

Our friendly team is available on live chat via our website or email at support@mgigolf.com. It is recommended you contact us first rather than returning to the place of purchase for the fastest response to your enquiry.



For further information please visit our website
mgigolf.com

MGI GOLF GLOBAL CUSTOMER SUPPORT

E globalservice@mgigolf.com

MGI GOLF AUSTRALIA

MGI HEAD OFFICE

11 Maurice Court Nunawading 3131
Victoria Australia

T +613 8872 6700 **E** sales@mgigolf.com

SERVICE customerservice@mgigolf.com

MGI GOLF USA

T 1800 617 2990 **E** salesusa@mgigolf.com

SERVICE serviceusa@mgigolf.com

Follow us on



Limited Warranty

Sureshot™ Pty Ltd ("SS") warrants that product delivered in this package will be free from manufacturing defects for two (2) year following the date of purchase from SS or its authorised reseller.

Absolute attention has been taken to ensure this Quick Start Guide is correct at time of printing. Specifications, images and statistics may change at any time. Visit mgigolf.com for the most current model information. Sureshot Pty Ltd is a division of MGI. Made in China. MGIG_2572 09/24

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.