






Installation Guide

Version 1.0

WHAT'S INCLUDED			
Latch and strike	Exterior Assembly	Interior Assembly	Screws
			Step 2
			Step 3
			Step 4
			Step 5
			Step 6
 Phillips headscrew driver Note: No drill needed			



1

Adjust the backset of latch (if needed)

A

Hold the latch in front of the door hole, with the latch face flush against the door edge.

B

If the latch holes are centered in the door hole, no adjustment is required. Proceed to step 2. If the latch holes are NOT centered, adjust latch. See "Latch Adjustment."

C

Latch adjustment (only if needed)

2

Install latch

A

B

Note:

The square hole must be horizontal

5

Install 4 AA batteries and battery cover

A

inside

B

inside

C

inside

6

Install the door handles

A

B

C

7

Insert the key and test the installation

Install our lock on top (only if needed)

Install our lock on top

If you have a deadbolt lock on top, please move the deadbolt lock to the bottom and install our lock on top to avoid installation issues.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.