

FUSION® Apollo 770 Quick Start Manual



ENGLISH

FUSION®
FUSIONENTERTAINMENT.COM

Getting Started

⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Stereo Controls



①	Dial	- Turn to adjust the volume. - When adjusting the volume, press to switch between zones. - When adjusting the volume, press and hold for at least one second to adjust the subwoofer levels. - On a screen with tabs, press and hold for at least one second to switch the tab. - Turn to move through the menus or adjust a setting. - When in a menu, press to select the highlighted option.
②	Source Icon	Press to change the source (page 2).
③	≡	Select to open a menu for the current source. Not available on all sources.

⚙	Select to open the stereo settings menu.
⏻	- Press to turn on the stereo. - Press to mute the stereo. - Press and hold to turn off the stereo.

Adjusting the Volume

- Turn the dial to adjust the volume.
- If necessary, press the dial to switch between zones.

TIP: To control all zones at the same time, you can press the dial until GLOBAL is highlighted, or use the touchscreen to adjust the GLOBAL zone.

Selecting a Source

- Select the source icon.

The source icon is in the lower-left corner of the stereo screen, and shows the source that is currently selected.

- Select a source.

Playback Controls

The on-screen playback controls may change depending on the source selected.

⏸	Select to pause media playback.
▶	Select to play media or resume media playback.
⏮	- Select to skip to the previous track, when using an applicable source. - AM, FM, or SiriusXM source: - Select to tune to the previous station or preset. - Hold for faster tuning (manual mode only). - DAB source: Select to return to the previous DAB station in the ensemble. When you reach the beginning of the current ensemble, the stereo automatically changes to the last available station in the previous ensemble.

⏮	- Select to skip to the next track, when using an applicable source. - AM or FM, or SiriusXM source: - Select to tune to the next station or preset. - Hold for faster tuning (manual mode only). - DAB source: Select to advance to the next DAB station in the ensemble. When you reach the end of the current ensemble, the stereo automatically changes to the first available station in the next ensemble.
M A ★	On the AM, FM, or DAB source, select to cycle through the tuning modes (auto or manual) and presets (when two or more presets are saved). Press and hold to save the current station as a preset.
+	On the Aux or SPDIF source, select to increase the gain for the connected source.
—	On the Aux or SPDIF source, select to decrease the gain for the connected source.

Stereo Screen

The information displayed on the stereo screen varies depending on the source selected. The on-screen playback controls may change depending on the source selected (page 2). This example shows the stereo playing a track from USB device connected to the USB port.



①	Source
②	Album art (if available from a compatible source)
③	Track details (if available)

④	Elapsed time, track duration, and the current track number out of the total number of tracks in the playlist (if available)
⑤	Select to change the source (page 2).

Media Player Connection

⚠ CAUTION

Always disconnect your media player from the stereo when not in use and do not leave it in your vessel. This helps reduce the risk of theft and damage from extreme temperatures.

Do not remove the media player or use your stereo in a distracting manner while operating the vessel. Check and obey all marine laws in association with use.

The stereo accepts a variety of media players, including smartphones and other mobile devices. You can connect a compatible media player using a Bluetooth® wireless connection or a USB connection to the USB port.

NOTE: If you connect a supported media player to the USB port, you must either disable Bluetooth on the media player, or unpair the Bluetooth connection from the stereo to avoid possible media-playback issues.

USB Device Compatibility

You can use a USB flash drive or the USB cable included with your media player to connect a media player or mobile device to the USB port.

The stereo is compatible with Android™ devices that support MTP mode.

The stereo is compatible with media players and other USB mass storage devices, including USB flash drives. Music on USB drives must meet these conditions:

- The USB mass storage device must be formatted using the FAT32 or NTFS file system.
- The music files must be formatted as MP3, AAC (.m4a), FLAC, or WAV files.

Connecting a USB Device

You can connect a USB device to the USB port on the stereo.

- 1 Locate the USB port on the back of the stereo.
- 2 Connect the USB device to the USB port.
- 3 Select the USB source.

Connecting a Compatible Bluetooth Device

You can play media from a compatible Bluetooth device using the Bluetooth wireless connection.

You can control the music playback with the media app on a Bluetooth device or using the FUSION-Link™ remote control app (page 6).

- 1 Select the **BT** source.
- 2 Select  > **DISCOVERABLE** to make the stereo visible to your compatible Bluetooth device.
- 3 Enable Bluetooth on your compatible Bluetooth device.
- 4 Bring the compatible Bluetooth device within 10 m (33 ft.) of the stereo.
- 5 On your compatible Bluetooth device, search for Bluetooth devices.
- 6 On your compatible Bluetooth device, select the stereo from the list of detected devices.
- 7 On your compatible Bluetooth device, follow the on-screen instructions to pair and connect to the discovered stereo.
When pairing, your compatible Bluetooth device may ask you to confirm a code on the stereo. The stereo does not display a code, but it does connect correctly when you confirm the message on the Bluetooth device.
- 8 If your compatible Bluetooth device does not immediately connect to the stereo, repeat steps 1 through 7.

The DISCOVERABLE setting is disabled automatically after two minutes.

Bluetooth Range Information

The stereo and Bluetooth wireless devices have a range of 10 m (33 ft.). For optimal performance, the Bluetooth wireless device should also have a clear line of sight to the stereo.

Connecting to a Garmin® Watch

For more information about the watch, see the watch manual at www.garmin.com/manuals.

- 1 Following the instructions in the watch manual, install the FUSION-Link Lite™ app from the Connect IQ™ store onto the watch.
- 2 On the stereo, select the **BT** source.
- 3 Select  > **DISCOVERABLE**.
The stereo remains discoverable for two minutes.
- 4 Bring the watch within 3 m (10 ft.) of the stereo.
NOTE: Stay 10 m (33 ft.) away from other ANT® devices while pairing.
- 5 Open the FUSION-Link Lite app on the watch.
The first time you open the app on the watch, the watch automatically pairs with and connects to the stereo. If you need to pair to another stereo, in the FUSION-Link Lite app, select **Settings > Pair new**.
- 6 Control the audio playback using the FUSION-Link Lite app on the watch.
After the devices are paired, they connect automatically when they are turned on, within range, and the app is open on the watch.

Playing Media

Setting the Tuner Region

You must select the region you are in to receive AM and FM stations properly.

If you are connected to a compatible SiriusXM® tuner and antenna, and have a subscription (USA only), you must select the region you are in to receive SiriusXM stations properly.

NOTE: SiriusXM is not available in all regions.

If you are connected to a compatible DAB module and antenna (not included), you must select the region you are in to receive DAB stations properly.

NOTE: DAB stations are not available in all regions.

- 1 Select  >  > **TUNER REGION**.

- 2 Select the region you are in.

Changing the Radio Station

- 1 Select an applicable source, such as **FM**.
- 2 Select **M/A** repeatedly to move through the tuning modes, and select an option:
 - Select **Auto** to scan and stop on the next available station.
 - Select **Manual** to select a station manually.
 - Select **Preset** to select a saved station preset.
- 3 Select **◀▶** or **▶▶** to tune to the station.

Scanning for DAB Stations

Before you can scan for DAB stations, you must connect a compatible DAB module and antenna (not included) to the stereo. Because DAB signals are broadcast in select countries only, you must also set the tuner region to a location where DAB signals are broadcast.

- 1 Select the **DAB** source.
- 2 Select **▶▶** to scan for available DAB stations.

When scanning is complete, the first available station in the first ensemble found begins playing.

NOTE: After the first scan is complete, you can select **▶▶** again to re-scan for DAB stations. When the re-scan is complete, the system starts playing the first station in the ensemble you were listening to when you started the re-scan.

Changing DAB Stations

- 1 Select the **DAB** source.
- 2 If necessary, select **▶▶** to scan for local DAB stations.
- 3 Select **◀▶** or **▶▶** to change the station.


When you reach the end of the current ensemble, the stereo automatically changes to the first available station in the next ensemble.

FUSION PartyBus™ Networking

The FUSION PartyBus networking feature allows you to connect multiple compatible stereos and zone stereos together on a network, using a combination of wired or wireless connections.

A FUSION PartyBus device connected to the network can stream sources from and control media playback on another FUSION PartyBus device connected to the network.

You can connect up to eight FUSION PartyBus devices on a network.



In the image above, an Apollo 770 stereo (1) connects to a wireless router (2) and to two Apollo SRX400 zone stereos (3). You can connect a FUSION PartyBus zone stereo to a single speaker zone (4). You can connect a FUSION PartyBus stereo to multiple speaker zones (5) to cover a larger area.

FUSION PartyBus devices connected to the network can stream media from and control media playback on other devices on the network, but cannot control the volume of other devices on the network. You can adjust the volume of speakers or speaker zones connected to the stereo only.

Streaming from a FUSION PartyBus Device on the Network

Before you can stream from a device on the network, you must set up and configure your FUSION PartyBus devices according to the installation instructions.

1 Select the source icon.

The source icon is in the lower-left corner of the stereo screen, and shows the source that is currently playing.

2 Select **PARTYBUS**

The device shows a list of available FUSION PartyBus devices on the network.

3 Select the device you want to stream from.

The stereo begins streaming the same source as the connected FUSION PartyBus device, and a green border appears around the device screen. All media playback functions affect both devices.

Stopping Streaming from a FUSION PartyBus Device on the Network

If you are streaming from a FUSION PartyBus device on the network, you must disconnect from the device before you can play local sources on the stereo.

1 Select the source icon.

The source icon is in the lower-left corner of the stereo screen, and shows the source that is currently selected.

2 Select **PARTYBUS > LEAVE PARTYBUS**.

DSP Settings

This device features digital signal processing (DSP). You can configure the DSP settings to adjust the speakers so they sound the best in their installed locations.

All DSP settings are configured using the FUSION-Link remote control app (page 6). See the owner's manual for more information.

More Information

FUSION-Link Remote Control App

You can use the FUSION-Link remote control app on your compatible Apple® or Android device to adjust the stereo volume, change the source, control playback, select and manage radio presets, and adjust some stereo settings. .

The app communicates with the stereo using the Bluetooth connection for the mobile device. You must connect your compatible device to the stereo using Bluetooth to use the app.

If you are using a FUSION PartyBus device on a network with a Wi-Fi® access point, the app can communicate with the device using the network for greater range.

For information about the FUSION-Link remote control app for compatible Apple or Android devices, go to the Apple App Store™ or the Google Play™ store.

Getting the Owner's Manual

You can get the latest owner's manual and translations of manuals from the web.

1 Go to www.fusionentertainment.com/marine.

2 Select your product.

3 Select **Manuals & Downloads**.

4 Select a manual.

Registering Your Apollo 770

Help us better support you by completing our online registration today.

- Go to www.fusionentertainment.com.

- Keep the original sales receipt, or a photocopy, in a safe place.

物質宣言

部件名称	有毒有害物质或元素					
	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
印刷电路板组件	X	0	0	0	0	0
屏幕/背光	X	0	0	0	0	0
金属零件	X	0	0	0	0	0
电缆 电缆组件 连接器	X	0	0	0	0	0

本表格依据 SJ/T11364 的规定编制。

O: 代表此种部件的所有均质材料中所含的该种有害物质均低于
(GB/T26572) 规定的限量

X: 代表此种部件所用的均质材料中, 至少有一类材料其所含的有害物
质高于

(GB/T26572) 规定的限量

*該產品說明書應提供在環保使用期限和特殊標記的部分詳細講解產品的
擔保使用條件。



DRAFT

FUSION SUPPORT

New Zealand	09 369 2900
Australia	1300 736 012
Europe	+44 (0) 370 850 1244
USA	623 580 9000
Pacific	+64 9 369 2900



Garmin®, ANT®, FUSION®, and the Fusion logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Apollo™, Connect IQ™, FUSION-Link™, FUSION-Link Lite™, and FUSION PartyBus™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

Apple® and App Store™ are trademarks of Apple Inc. Android™ and Google Play™ are trademarks of Google Inc. Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. NMEA 2000®, and the NMEA 2000 logo are registered trademarks of the National Marine Electronics Association. SiriusXM® is a registered trademark of SiriusXM Radio Inc. Wi-Fi® is a registered mark of Wi-Fi Alliance Corporation. Other trademarks and trade names are those of their respective owners.

FUSION®

FUSIONENTERTAINMENT.COM

190-02382-90_01
March 2018
Printed in Taiwan

