

AU802C User's Manual

1. Installation: Connect AP to PC with Cross Over Ethernet cable. Connect 5V 1.6A power adapter to the AP. You can see all LEDs are turn on.
2. Configuration: Setting Ethernet card IP address with 192.168.1.X, subnet mask with 255.255.255.0, restart machine if asked to do so.
3. AP setting: Open a internet explore, such as Netscape or Internet explore, enter URL <http://192.168.1.240> ,Then you can see a pop up window with user name and password. Enter nothing and click OK to continue. Then you enter into setting web page. Here you can set AP's parameter, go to wireless icon, set SSID and wireless channel. For 802.11g AP, channel should be 2.4G channel 1 to channel 14.
4. Connect with a Client: In order to be associated with the AP, one client should have same SSID, and select Access Point as communication mode. Also Set client IP Address and subnet mask as 192.168.1.X, subnet mask with 255.255.255.0. Client can automatically search for a near by AP to get connected.

Regulatory Compliance Notices Class B Equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Actiontec Electronics, Inc may void the user's authority to operate the equipment.

Declaration of conformity for products marked with the FCC logo – United States only

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry of Canada. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

"IMPORTANT NOTE: To comply with FCC RF exposure compliance requirements the antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter."

For questions regarding your product, or the FCC declaration, contact:

Actiontec Electronics, Inc
760 North Mary Ave,
Sunnyvale, CA 94086
United States