

CLiK64-TR User Instructions

1. Press the button on the key tag transmitter for at least **one second** to transmit the signal code. A red indicator light will flash for the duration of the transmission. Pressing and holding the button down only transmits one pulse. This reduces unintentional transmissions and conserves battery life.
2. Release and press the button for one second again to send another transmission.
3. If the light on the transmitter does not light up when you press and hold any button, replace the battery.

CLiK64-TR1



CLiK64-TR2



CLiK64-TR4



CLiK64-TR Battery Replacement

1. Carefully pry open the case with a flat edge tool or screwdriver from the key ring corner.



2. Make sure the case is laid flat on the table upside down.
3. Push the coin shaped battery out of its holder and replace it with a CR2032 battery being careful to place the "+" positive side on top.



4. DO NOT install the batteries backwards. The device will be damaged.
5. Snap close the case
6. Test the transmitter and look for the red LED light to flash when a button is pressed for one second.

FCC Regulatory Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the Federal Communication Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by doing one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

RF Exposure Warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED Regulatory Statements

This device complies with ISED Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme avec ISED Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-3 (B)/NMB-3(B)

RF Exposure Information

This equipment complies with ISED RSS-102 radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme avec ISED RSS-102 des limites d'exposition aux rayonnements définies pour un environnement non contrôlé. Cet émetteur ne doit pas être colocalisé ou fonctionner en association avec une autre antenne ou émetteur.

Active Secure Inc.
2828 Kingsway Drive, Unit 6
Oakville, Ontario L6J 7M2