

L5

User Guide

Contents

Welcome.....	2
1. Package Contents:.....	3
2. Keypad Layout and Display Indicator Lamps.....	4
3. Preparing to Use the Product:	4
4. Charging the Device:.....	4
5. About this Device.....	5
6. Reset to Factory Defaults.....	5
7. Powering the Device On/Off.....	5
8. Connecting to the Device.....	6
9. Setup of the Device.....	7
10. Managing the Device	8
11. Example of Connecting a tablet to the Device	11
12. Indicator Lamps Overview and Definitions	11
13. Side Keys.....	12
14. Product Specifications.....	13

Accessories are available at www.umxmobile.com

Congratulations on the purchase of your new Hotspot!



This User Guide is to welcome and familiarize you with the features of this device.

L5 User Manual

This manual describes how to set up and use the device. Please read it carefully before you use the product. Please also keep this manual in a proper place.

Please confirm the contents of the package.


Please keep the product guaranty certificate in a safe place.

1. Package Contents:

1 - L5 Hotspot devices

1 - 5v, 1000mA Wall Charger

1 - MicroUSB Charging Cable



Battery Charger - 1



USB Cable - 1



2. Keypad Layout and Display Indicator Lamps



3. Preparing to Use the Product:

The Li-ion battery in the device is not fully charged. Please charge the device before using.

4. Charging the Device:

- a. Connect the USB end of the cable to the charger or a personal computer.
- b. Connect the micro USB end of the cable to the device.
- c. Plug the charger to the AC power supply for home use.

when charging, the battery status LED lights up and dims down similar to sleeping mode.

We think the fading of the LED's is very important, if you could achieve this it would be fantastic.

Is it possible the LED lights up in the colour to which the battery is already charged?

So when below 30% charged it is blinking red.

When below 60% charged it is blinking yellow.

When below 100% charged it is blinking green.

When fully charged the LED stops blinking and remains green.

5. About this Device

This product acts as a Wi-Fi access point for portable devices like a notebook/netbook/tablet PC, Ipad, Android devices, Windows devices, etc. to provide Internet access.

It can support up to 7 simultaneous Wi-Fi connections from portable devices*.


*A single connected device will experience optimal speeds.

Performance will be reduced if multiple devices access data through the hotspot simultaneously. Actual speed, availability and coverage will vary based on device, usage and network availability.

6. Reset to Factory Defaults

When the device is powered-on, use sharp goods pressing reset key for 3 seconds will reset the device to the factory defaults, such as SSID, security setting, administrator setting. The user must redo the setup procedure on the device in order to use the Internet service.

7. Powering the Device On/Off



- a. Turn on the power, press and hold the power button for 5 seconds.

Indicator Lights :

System initiation : Press and hold the power button for 5 seconds. When boot the LED's will light up successively and dim down afterwards. This movement will continue until device is sending out a Wi-Fi signal.

Battery State: Keep battery lamp on with current status , battery light is green.

Signal Strength State: keep battery lamp as the current status. The Signal light will Turn on that it one by one from right to left.

Wi-Fi Sleep Mode: When the L5 is on, press and hold the power button for 2 seconds that will being Sleep Mode. The Wi-Fi will be not discovered. When you want to connet the Wi-Fi, you should press and hold the power button for 2 seconds again.

- b. Turn off the power, press and hold the power button for 5 seconds.

System shutdown: ALL the Lamps which the lamp will turn off one by one from SleepMode lamp to Battery lamp.

8. Connecting to the Device

Here is an example to connect to a L5 with a PC.


- Press Power Key for longer than 5 seconds to turn on a L5.
- Scan available Wi-Fi access points at a Windows PC by clicking the network icon at the right bottom corner.
- Connect PC with the L5 device with a typical name (SSID) as L5-AP.



9. Setup of the Device


A newly purchased L5 requires the customer to set up the device for use after powering on the device and connecting to it.

- Launch a web browser, such as Internet Explorer, Chrome, Safari or Firefox, and type 192.168.1.1/index.asp in the address bar.
- The window below shows up



- The default Login credentials are:
password : 123456


The will turn to UMIMAX MXL-655 Web Server Home page.




10. Managing the Device

Connect to the device in the procedure outlined in step 8.

A. Login into the website will turn to Home page



B. Change and View the Wi-Fi Setting



C. Viewing the LAN page and change it

The screenshot shows the LAN configuration page of the UNIMAX MXL-655 Web Server. The page has a blue header with the title "UNIMAX MXL-655 Web Server" and navigation links: Home, WiFi, LAN (selected), Update, Advance, and Logout. The main content area is divided into two sections: "LAN Setting" and "DHCP Server".

LAN Setting

IP address: 192.168.1.1 Subnet mask: 255.255.255.0

DHCP Server

DHCP IP range

from: 192.168.1.20 to: 192.168.1.40

Apply

D. Updating the L5's Internal Web pages

The screenshot shows the Update page of the UNIMAX MXL-655 Web Server. The page has a blue header with the title "UNIMAX MXL-655 Web Server" and navigation links: Home, WiFi, LAN, Update (selected), Advance, and Logout. The main content area is divided into three sections: "Update Profile", "Update PRL", and "Update Firmware".

Update Profile

This operation, also called CIDC(Client Initialized Device Configuration) should only be performed when requested by support staff.

Update Profile

Update PRL

The PRL(Preferred Roaming List) is updated automatically, but you can perform a manual update.


Update PRL

Update Firmware

This updates the device firmware.

Update Firmware

E. Change and Viewing the Advanced settings



The screenshot shows the 'Advance' tab of the UNIMAX MXL-655 Web Server interface. The browser address bar shows '192.168.1.1/index.asp'. The navigation bar includes 'Home', 'WiFi', 'LAN', 'Update', 'Advance' (selected), and 'Logout'. The main content area has a 'System Setting' section with two input fields for 'New password' and 'Verify new password', followed by an 'Apply' button. Below this, there are two sections: 'Factory Reset' with a description and a 'Factory Reset' button, and 'Clear Programming' with a description and a 'Renew Device' button.

UNIMAX MXL-655 Web Server

Home WiFi LAN Update **Advance** Logout

System Setting

New password:

Verify new password:

Apply


Factory Reset
This operation, also called Reverse Logistics, will display provisioning information and reset the modem to the factory default values. The MSL is needed to perform a reset.

Factory Reset

Clear Programming
Use this to clear all account information. You will need to re-activate in order to connect to the mobile network. The MSL is not required for this operation.

Renew Device

F. Successful page if Device success to Configure Any of the Settings Changes



The screenshot shows the 'WiFi' tab of the UNIMAX MXL-655 Web Server interface. The browser address bar shows '192.168.1.1/index.asp'. The navigation bar includes 'Home', 'WiFi' (selected), 'LAN', 'Update', 'Advance', and 'Logout'. The main content area displays a success message: 'The change of Configuration is saved successfully. Please reboot the device to enable the changes.' Below the message are three buttons: 'Back to Home', 'Back to the last page', and 'Reboot'.

UNIMAX MXL-655 Web Server

Home **WiFi** LAN Update Advance Logout


The change of Configuration is saved successfully.
Please reboot the device to enable the changes.

Back to Home

Back to the last page

Reboot

G. Failure Page if Device Fails to Configure Any of the Settings Changes



11. Example of Connecting a tablet to the Device

- a. Turn on the Tablet.
- b. Tap settings.
- c. Tap Wi-Fi from the setting menu.
- d. Find the SSID of the L5 from the AP list and tap it.
- e. Enter the security key (default or user modified) in the key input window.
- f. Tap "join" from the soft keyboard when finishing the key input.

In the traffic dependent mode (default), L5 will connect to the operator's 4G network if it detects the data traffic from a Wi-Fi client (e.g., a portable device).

12. Indicator Lamps Overview and Definitions

- a. Wi-Fi Sleep Mode Lamp
 - On: Wi-Fi is in sleep mode.
 - Off: Wi-Fi is turned on.
- b. Signal Strength Lamp
 - Three white lamp: signal strength is strong.

Two white lamp: signal strength is better.

One white lamp: signal is weak .

No one lamp: no signal, or network obstacle.

c. Battery Lamp

Green: battery is enough (100-60%)

Yellow: battery is low (60-30%)

Red: need to be charged (30-0%)

13. Side Keys

A. Power Key - Turns the device on/off



B. Wi-Fi on/Sleep Mode - press and hold power button for 2 seconds



C. Reset button - press and hold reset button for 3 seconds



14. Product Specifications



Size: 75X75X13.2 mm

Weight: about 80g (including battery)

Communication spec: CDMA 2000 1X EVDO Rev. A \LTE B25\B26\B41

Frequency bands: 800MHz/1900MHz/2500MHZ

Wi-Fi spec: IEEE802.11b/g/n

Battery for continuous use: about 4 hours.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value.

This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this is **1.303W/Kg**(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on

FCC ID: P46-MXL655 Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at

<http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **10mm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.