

TARGUS®

**5-Button Rechargeable
Hover Mouse**



TARGUS®

Making Your Mobile Life Easier.®

Visit our Web site at: www.targus.com

Features and specifications are subject to change without notice.


© 2005 Targus Group International, Inc. and Targus Inc.

AMW06US/400-0212-001A

USER'S GUIDE

Making Your Mobile Life Easier.®

BRUSSELS HANNOVER BARCELONA TOKYO MILAN AMSTERDAM SINGAPORE LONDON PARIS NEW YORK LOS ANGELES TORONTO HONG KONG SYDNEY



PMS Black
15%



PMS Black
100%

TARGUS 5-BUTTON RECHARGEABLE HOVER MOUSE

Introduction

Congratulations on your purchase of a Targus Ergo Rechargeable Mouse. This ergonomically designed mouse uses a radio frequency (RF) link that enables you to use the mouse anywhere within four feet of its receiver. No line-of-sight between the mouse and its receiver is required.

This user's guide describes how to connect the mouse receiver to your computer, install default software drivers and set up the radio link.

In addition to this user's guide, this package contains:

- Mouse
- Receiver
- 2 AAA rechargeable batteries
- USB extension seat
- USB charge cable

System Requirements

Hardware

- PC with a Pentium® processor or equivalent
- USB interface

Operating System

- Windows® Me/2000/XP




NOTE: THE EXTRA BUTTONS AND THE SCROLLING WHEEL ONLY WORK WITH THE OPERATING SYSTEMS LISTED ABOVE. IF YOU USE THE MOUSE WITH A DIFFERENT OPERATING SYSTEM, IT WILL LOSE ITS ENHANCED FEATURES AND FUNCTION AS A STANDARD, TWO-BUTTON MOUSE.

Connecting the Receiver and Using the Mouse

To connect the mouse receiver, plug it into an available USB port on your computer.

Installing the Batteries

- 1 Remove the battery cover from the top of the mouse by pressing the hinge located on the center of the top cover and sliding the cover off.





NOTE: THE BATTERY COVER IS ALSO THE TOP COVER OF THE MOUSE.

- 2 2 AAA NiMH rechargeable batteries are included. Insert the supplied batteries, making sure that the positive (+) and negative (-) ends of each battery match the polarity indicators inside the battery housing.



WARNINGS: WHEN REPLACING THE BATTERIES, YOU MUST USE HEAVY-DUTY NiMH BATTERIES. NEVER USE ALKALINE IF YOU INTEND TO USE THE RECHARGING FEATURE.

AVOID MIXING NEW AND USED BATTERIES IN A DEVICE.

- 3 Slide the battery cover back into position until it “clicks” firmly into place.
- 4 Turn on the mouse by clicking any mouse button.

The optical sensor, located on the bottom of the mouse, glows red.


Charging the Mouse

For best results, you should charge the mouse at least 4 hours before using it. You can do this via the supplied USB charge cable. To do this:


- 1 Connect the supplied charging cable’s USB connector into an available USB port on your computer.

Targus 5-Button Rechargeable Hover Mouse

- 2 Connect the other end to the mouse; the charger connector is located on the front tip of the mouse..



- 3 Alternatively, you can connect the receiver to the supplied extension seat and plug the extension seat cable to the USB port on your computer.



NOTE: To CONTINUOUSLY CHARGE THE MOUSE VIA THE USB CHARGE CABLE, YOUR COMPUTER MUST BE ON AND AWAKE. FOR BEST RESULTS, TURN OFF YOUR COMPUTER'S POWER MANAGEMENT FEATURE WHILE CHARGING THE MOUSE.

Establishing a Communications Link


The mouse has 256 identification codes that allow the mouse and its receiver to operate without interference from other radio frequency devices.

After your computer detects the USB receiver and the driver software is installed, you must establish a communications link between the mouse and its receiver **BEFORE** you can use the mouse. To establish this link, you need to set the identification code so that the mouse works properly.

Make sure that your computer is turned on and has detected the USB receiver before you establish a communications link.


- 1 Press and release the connection button on the receiver.

The USB connector rotates 90 degrees to facilitate easy connection to your computer.



Targus 5-Button Rechargeable Hover Mouse

The receiver's red status light blinks when the receiver is activated.



BOTTOM OF MOUSE

- 2 Press and release the connection button located on the bottom of the mouse.

You are now ready to use the mouse.

Operating Hints

For optimal performance and RF reception:

- Do not separate the mouse pad from the mouse. The pad is permanently attached to the mouse.
- Place the receiver at least 8 inches (20 cm) away from all electrical devices, such as your monitor, speakers or external storage devices.

If necessary, use the supplied extension seat to keep the receiver away from the computer. Plug the receiver into the extension seat, and the extension cable to the computer.

- Avoid using the mouse on a metal surface. Metals, such as iron, aluminum or copper, shield the radio frequency transmission and may slow down the mouse's response time or cause the mouse to fail temporarily.
- The mouse will enter a suspend mode at the same time your computer does. To activate the mouse, move the mouse or click on any mouse button.
- If your computer has a metal case that contains aluminum or magnesium, use the mouse to the side. The display panel may interfere with the radio frequency signal if you use the mouse directly in front of the computer.
- Never use the mouse on a glass or mirrored surface as these surfaces will cause the mouse to fail temporarily.
- To maximize battery life, use the mouse on a white, or light colored surface. Dark surfaces cause the mouse's light emitter diode (LED) light to glow brighter, which causes the battery to discharge more rapidly.

Comfortable Usage

Research suggests that physical discomfort and injury to nerves, tendons, and muscles may be related to repetitive motion, an improperly set up work area, incorrect body posture, and poor work habits.

To reduce the risk of injury, follow these precautions:

- Stand, stretch, and move around several times every hour.
- Switch hands while performing tasks. Use shortcut keys to avoid repetitive or awkward mouse movements.

- Relax your shoulders and keep your elbows at your sides. Adjust the keyboard's position so that you don't have to stretch to reach it.
- Adjust your position so that you don't have to bend your wrists to type; avoid placing your wrists on a sharp edge.

If you feel discomfort or numbness in your hands, wrists, arms, shoulders, neck, or back while typing, consult a qualified medical professional.

Specifications

Dimensions	Mouse:	7 x 4.5 x 2.2 inches (178 x 114 x 56 mm)
	Receiver:	
	Extended:	3.9 x 1.1 x 0.95 inches (99 x 28 x 24 mm)
	Folded:	2.5 x 1.1 x 1.1 inches 63 x 28 x 28 mm
Weight	Mouse:	4.4 ounces (125 grams)
	Receiver:	0.9 ounces (25 grams)

Troubleshooting

What do I do if the mouse does not work?

- Make sure that the polarity of the batteries is correct. The positive (+) and negative (-) ends of each battery must match the positive (+) and negative (-) connections in the battery housing.
- Check that the receiver's USB connector is firmly attached to the USB port on your computer.

- Verify that the device drivers are installed.
- Make sure you have established a radio link between the mouse and its receiver. See “Establishing a Communications Link” on page 7.

When I use the mouse, other wireless devices work more slowly or fail temporarily – what should I do?

The mouse may cause interference with any cordless, radio-based device that operates at 27 MHz, such as a telephone, baby monitor, or toy. To reduce interference, move the mouse’s receiver and the base unit of the affected device as far away from each other as possible.

What do I do if the response time of the mouse is slow or the mouse intermittently stops working?

- Increase the distance between the mouse’s receiver and the rest of your computer equipment.
- Increase the distance between the mouse’s receiver and the base units of other wireless devices.
- Turn off any wireless devices and their base units that are near the mouse’s receiver.
- If you are using the mouse on a metal surface, move it and the receiver to a non-metal surface. Metals, such as iron, aluminum or copper, shield the radio frequency transmission and may slow down the mouse’s response time or cause the mouse to fail temporarily.

I can’t use the mouse while another RF mouse is in use – what should I do?

Reset the identification code. See “Establishing a Communications Link” on page 7.

Technical Support

For technical questions, please visit:

Internet: <http://www.targus.com/support>

Product Registration

Targus recommends that you register your Targus accessory shortly after purchasing it. To register your Targus accessory, go to:

<http://www.targus.com/registration.asp>

You will need to provide your full name, email address, phone number, and company information (if applicable).

Warranty

Targus warrants this product to be free from defects in materials and workmanship for one year. If your Targus accessory is found to be defective within that time, we will promptly repair or replace it. This warranty does not cover accidental damage, wear and tear, or consequential or incidental loss. Under no conditions is Targus liable for loss of, or damage to a computer; nor loss of, or damage to, programs, records, or data; nor any consequential or incidental damages, even if Targus has been informed of their possibility. This warranty does not affect your statutory rights.

Regulatory Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Statement

Tested to Comply

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna;
- Increase the separation between the equipment and receiver;
- Move the computer away from the receiver;
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

This manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Pentium is a registered trademark of Intel Corporation. Windows is a registered trademark of Microsoft Corporation. All other trademarks are the property of their respective owners. Features and specifications are subject to change without notice. © 2005, Targus Group International, Inc. and Targus, Inc., Anaheim, CA 92806 USA.