


The background is a dark, abstract digital space. It features a network of glowing blue and purple lines that crisscross the frame. Several translucent, brightly colored rectangular shapes in shades of green, yellow, orange, and red are scattered throughout, some appearing to float or move. Numerous small, bright white and blue light points are distributed across the scene, creating a sense of depth and digital activity. The overall aesthetic is futuristic and high-tech.

WinBook 10" Pad

Quick Start Guide

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation

RF Exposure Information (SAR)

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the EUT transmitting at the specified power level in different channels.

The highest SAR value for the device as reported to the FCC is 1.42 W/kg when placed next to the body.

CAUTION


Risk of explosion if battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions.

Package contents


If any of the items is missing or damaged, please contact your dealer immediately:

- One Tablet
- One AC adapter
- One USB cable
- This guide

Tablet layout




No.	Name	No.	Name
1	Front facing camera	5	Micro SD card slot
2	Touchscreen	6	Headphone plug
3	Windows button	7	Mini HDMI port
4	USB 3.0 port	8	Micro USB 2.0 port



No.	Name	No.	Name
1	Power Button	4	Rear facing camera
2	Volume up/down	5	Speaker
3	Microphone	6	Pogo pin connector

Charging your tablet

If your tablet is just being unpacked from the box, you need to charge the tablet first. It will take around 4 to 5 hours to be fully charged.




1. Plug the USB head of the cable into the adapter.
2. Plug the micro-USB head of the cable into the micro-USB port on your tablet.
3. Plug the adapter into a wall-socket.

Powering ON/OFF your tablet


To power on your tablet

Press and hold the power button down until the screen turn on.



To power off your tablet

Press and hold the power button for at least four seconds, and you will see an instruction appears in the middle of the screen, which is as shown below.



Slide your finger on the screen downward, and the system will power off itself.

Inserting a storage card

Your tablet supports micro-SD cards with storage space ranging from 128M to 32G. You can insert the micro SD card and pull it out without powering down the tablet. To do so, follow the steps below.



Install your Micro SD Card

1. Hold your tablet with front side up.
2. Insert your micro SD card in the direction as shown.

Remove your Micro SD Card

1. Push and release the micro SD card. This will unlock the card.
2. Pull out the micro SD card.

Specifications

Processor	● Intel Bay Trail-T Z3735D ● Quad core (4C/4T) ● 1.33 GHz (Burst to 1.83GHz) ● 2MB L2 Cache
Memory	● DDR3L-RS 1333 ● Default 1 GB
Storage	● Single eMMC up to v4.5.1 ● Default 16GB (Max 64G)
Wireless	● Wi-Fi 802.11 b/g/n +BT4.0
Touchscreen	● 10.1-inch 1280 x 800 LCD ● Support 5-points multi-touch
Cameras	● Front HD camera: 2.0 M ● Rear HD camera: 2.0 M
Battery	● 1Cell, 1S2P ● Li-polymer ● 7600 mAh
Input/Output	● 1 x micro-USB 2.0 port (Type B) ● 1 x USB 3.0 port (Type A) ● 1 x Mic/head phone jack combo ● 1 x mini-HDMI 1.3a ● 1 x micro-SD card slot (128M-32G) ● 1 x Digital MIC ● 1 x Pogo Pin connector (5-pin)

Speaker & Mic	● Build-in Speaker x 2 ● Internal Digital MIC x 1
AC-Adapter	● DC Output: 5V/2A/10 Watt ● Input Voltage: 100 ~ 240VAC ● Input Frequency: 47 ~ 63Hz
Dimension (mm)	● 268.4 (W) x 179 (H) x 10.75 (D)
Weight	● < 650 g (w/o adapter)