

FDSSL-G140

User Manual

2025/02/05

Remote Layout



Five Function Buttons:

1. Unlock
2. Lock
3. Remote Start
4. Trunk
5. Panic

Programming Instructions

1. Press and Hold Unlock & Remote Start until LED blinks
2. Release buttons
3. Enter code with buttons 1 & 3 (Unlock & Remote Start)
 - a. Example: Code 13, press Unlock once, then Remote Start three times
 - b. Example: Code 42, press Unlock four times, then Remote Start two times
4. To exit programming mode, press Lock until LED blinks

Operation



Make sure you are within range of the vehicle before using the remote.

Remote Keyless Entry Mode

- Press Lock to lock all doors.
- Press Unlock to unlock the driver's door.
- Press the Remote Start button 2 times in 1 second to start the engine.
 - The LED will blink to indicate success or failure.
- Press the Trunk button 2 times in 1 second to open the trunk.
- Press the Panic button to sound the vehicle's Panic Alarm.
 - Press the Panic button again to stop the Panic Alarm

Passive Keyless Entry Mode

- With the remote on your person, pull a door handle to unlock that door handle.
- With the remote on your person, press the Start button to start the engine.

Note: The exact behavior in response to each button press may vary depending on the vehicle. Consult the vehicle manual for more information.

Battery Replacement

If the battery needs to be replaced:

1. Remove the emergency key by pressing the button on the key blade.
2. Use a thin coin or screwdriver to remove the battery cover.
3. Insert a screwdriver or thin object to remove the battery.
4. Replace the battery with a CR2450 cell with the “+” side facing up.
5. Replace the battery cover and the emergency key.

FCC Regulatory Statement

Model: FDSSL-G140

FCC ID: X32-FDSSG140

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this device not expressly approved by iKeyless, LLC could void the user's authority to operate the equipment.

IC Regulatory Statement

Model: FDSSL-G140

IC: 8797A-FDSSG140

CAN ICES-3 (B)/NMB-3(B)

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.