

PHOTOGRAPHS OF THE TEST CONFIGURATION

Set UUT as Client mode (Radar injected into Master)

