User Manual

Mobile Phone

FCCID: 2ADYY-Y4

TECNO MOBILE LIMITED

ROOMS 05-15, 13A/F., SOUTH TOWER, WORLD FINANCE CENTRE, HARBOUR CITY,
17 CANTON ROAD, TSIM SHA TSUI,
KOWLOON, HONG KONG

Please read these instructions for use and have a good look at the illustration before using.

Warning :

This device complies with Part 15 of the FCC Rules. Operation is subject tothe following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses andcan radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

RF Exposure Information:

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device Types Mobile Phone (FCC ID: 2ADYY-Y4) has also been tested against this SAR limit.

This device was tested for typical body worn operations with the back of the handset kept 10mm from the body.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Note: The SAR values meet the limit of FCC.

Please refer to the FCC database(https://apps.fcc.gov/oetcf/eas/reports/Generic Search.cfm) to search for FCC ID: 2ADYY-Y4 to get detailed information about RF Exposure(SAR).

Note:

the FCC ID lable inside the battery compartment, than the device must be marketed without battery inserted.

content

- Send MMS ..... - 4 -
- Choose SMS notification ..... - 5 -
- To view the sender information..... - 5 -
- Delete information ..... - 6 -
- Sort the information ..... - 6 -
- Favorites Introduction ..... - 7 -
- Contacts Search..... - 8 -
- Import contact information methods..... - 8 -
- Contact information stored call records ..... ……- 8 -
- Delete email account Enter the Program Group screen
- Email Sync Frequency setting……- 11 -
- Desktop features……- 11 -
- Wallpapers Method……- 12 -
- Application Folder……- 12 -
- Change the folder name……- 13 -
- Add contacts to your desktop……- 13 -
- Add Bookmarks to the desktop……..- 13 -
- Add a playlist to your desktop &Add Music to your desktop……- 14 -
- Delete the contents of the desktop……..- 15 -
- Bluetooth Function……- 15 -
- WIFI Features……- 15 -
- Airplane mode Function……- 16 -
- The screen lock and unlock……- 16 -
- Restore to factory default……...- 17 -
- Language Settings……..- 17 -
- Input method Settings……- 18 -
- Android phone data cable links……..- 18 -
- Introduce cross-screen display……...- 18 -
- Browser Features……- 19 -

- How to use Hotknot?.....- 19 -

Q/A - 20 -

1. How to turn off the software running in the background too much..... - 20 -
2. How to quickly set up Email ..... - 20 -
3. How do I view the capacity of phone memory case ..... - 20 -
4. How to save electricity TUNES Y4..... - 20 -
5. How TUNES Y4 lock screen, to prevent others from using..... - 21 -
6. Why does not the USB data cable links your computer..... - 21 -
7. How to install a program on a non-Android Market ..... - 21 -
8. In browsing the web or other applications, how to switch to other applications- 21 -
9. How to enter the silent mode quickly ..... - 21 -
10. How to forward SMS / MMS..... - 22 -
11. how to paste and copy text..... - 22 -
12. In the phone program group is installed too many applications, how to solve- 22 -
13. Contacts are sorted, can change ..... - 22 -
14. Contacts whether to support the group ..... - 22 -
15. contacts and SMS storage capacity limits the number of..... - 22 -
16. How to set the phone storage, personalized ring tones..... - 22 -
17. How to sync the phone contacts to the original TUNES Y4..... - 22 -
18. How to use the TUNES Y4 access Wifi (WLAN) ..... - 23 -
19. How to Find Contact..... - 23 -
20 How do I delete the downloaded software..... - 23 -
21. How to view mobile phone version information..... - 23 -
22. How do I copy SIM card contact information..... - 23 -
23 why the message has a different time and date display..... - 23 -
24. TUNES Y4 whether to support the Java ..... - 23 -
25. How to open developer options..... - 24 -

Basic terms

Root：Super Android system is the administrator user account, which has the authority to control the whole system, and only has the privileges to the original system can be refreshed for the revision of the various systems;

APK：Android application types, with the cab and the Windows Mobile platform, like exe files, the user can be installed directly;

Eclari：The name of one of the Android platform, version, and the corresponding version number is 4.4.2, TUNES Y4 use this version;

Webkit：Core Android platform, browser, and now Apple's Safari, Google's Chrome and FireFox are using this kernel as a web page rendering mechanism;

GPhone：To use Google Android mobile phone operating system developed collectively, TECNO, etc.;

ActiveSync：Push email solution to support Microsoft proprietary technology, pre-primary mailbox servers at Microsoft (Exchange server) to provide support, and now Google's Gmail also provided support

G-Sensor：Is the acceleration sensors for mobile phones can provide the direction of gravity sensors, which begin with the letter G represents the gravity, the latter Snesor meant to represent the sensor

- **How Introduction**
- **Introduction phone keys**

Menu button: Click on the program and display the corresponding menu item, the user can choose the corresponding sub-menu functions;

Home button: Click on the background into the current application and enter the main interface; Note that using this key will not really exit the application, the application will continue to run in the background;

Back button: Click to fall back to the previous step of application.

- **Introduction widgets**

1. Add the widget to the home screen: the widget interface, long press a widget, drag the widget to the main screen, which can add the widget to the home screen.
2. Change the position of widgets: in the main interface--Long pressing a widget, sliding the widget can change the position of it in the main screen
3. Delete widgets: in the main interface--Long pressing a widget, the button of deletion will appear on the mid- the bottom of the home screen. of the main screen. Slide the widget to cover the button. When they are red, let go of them. Then the widget is deleted



- ***Send MMS***

New message--click " + " - >select the desired additional content;

New message--click the menu button--click the “add subject”



- ***Choose SMS notification***
  Information into the interface, click the menu button and select "setting -" notification Settings "-" beep ". Then select want the bell (notification must mark)



- ***To view the sender information***
  Access information screen, click "select the message -" the sender's head "-"click  ", check out the sender information (see the sender information before, we must add the sender to the contact person).



- ***Delete information***

  Access to the information screen -- Select the message -- "Long pressing the Information, there appears shortcut key - select "Delete "function



- ***Sort the information***

Access to the information screen-- Click on the upper right corner of the sort button - in the interface selection you want to be the sort of way, and then for ordering information





- **Contact Features**

Contacts groups, contacts and favorites feature;

In details description

By the first number, then sort the way English characters （A-Z）



- ***Favorites Introduction***

  Including the recent contacts, users to call in the contact information, part of the overall fabric Top of the contact information for the user collection, lower often call into the system default contact information;



- ***Contacts Search***

  Enter the contact interface -- click button

  Search is supported by the first letter and the entire search string



- ***Import contact information methods***

  using Bluetooth to achieve data synchronization

  TUNES Y4 phone and the original binding, using Bluetooth to achieve synchronization of contacts;

- Call history record

One by one to delete call records.

Enter the call log interface -- Click the menu button -- Select “delete” function -- Choose the desired call records- click ok button



- ***Contact information stored call records***

  Enter the call log screen -- "Select the Save call log -- select "Add to Contacts "function

Or directly into the call log entry, -click button -select "Add to Contacts "function



- **Paste the text / copy Features**

Into the input field -- input string, long press and enter the region, there appears shortcut keys -- select all " cut all " ,"copy all", "paste all"



- **E-mail Features**

Before logging in the e-mail, you should register an e-mail account firstly. Enter the menu interface -- Select "Email" application -- Enter an e-mail account and password

If the system automatically recognizes the mailbox information, it will automatically configure; if the system does not recognize, it will require users to type IMAP mailbox, or POP3, enter the appropriate configuration information.





Gmail For example:
E-mail Address: fulai89@gmail.com
Password:12345678
Configure multiple email accounts
Enter the Program Group screen -- Select "Email" application -- Click the menu button -- select “setting” function -- select "add account" function



- ***Delete email account***
  Enter the Program Group screen – Select "Email" application – Click the menu button -- select “setting” function -- select account -- select "remove account" function



- **Email Sync Frequency setting**

Enter the Program Group screen -- "Select "Email" application - Click the menu button -- select “setting” function -- select account -- select “Sync Frequency" function



- **Desktop features**

The common application will be added into the desktop interface.

Open the phone home screen - -choose the need to add the application and long press, drag the application icon to the top - - the application will be placed to the idle interface



- Wallpapers

  Methods 1、In the desktop interface -- click the menu button -- Select “Wallpapers” function

Methods 2、Enter the main interface, from the main interface to select "TECNO which Wallpaper"
Methods 3、Enter setup interface - select "Display" - choose "which", respectively, according to "Lock Screen which Wallpaper" and "Home Screen which Wallpaper"



- Application Folder

  In idle screen long press an icon, then drag the icon to another icon, and form a folder.Click on the folder, the folder of the program will display fully extended.

- Change the folder name

  Open the folder on the desktop -- "click Input box -- Rename Folder

- Add contacts to your desktop.

  Open the tools widget - long press contacts widget drag the idle interface, the system will automatically pop up contact interface - choose need to add contacts.





- **Add Bookmarks to the desktop**

The widget space - long-press bookmarks widget, drag the widget to idle interface, through the idle interface shortcut icon can be convenient to get to the Internet, etc.

- **Add a playlist to your desktop &Add Music to your desktop**

1、 In the widgets space -- long pressing the music widget -- Select the music widgets to desktop

2、 In the widget space - long press music playlist widget, drag to the main interface, pop-up Playlists interface - select what you want to add a list of music to the main interface



- Delete the contents of the desktop

  Long press desktop need to delete the content - drag down to the trashcan

  - content has been deleted



- **Bluetooth Function**

Enter the desktop interface -- Select "Settings" -- Select "Bluetooth" function



- **WIFI Features**

Select "Settings" -- "Select “Wi-Fi" -- Select "add network" -- select the desired access APN.



- **Airplane mode Function**

1. Open the drop-down status bar - choose "Switch" - click on the "Airplane mode" - can open flight mode.
2. Or from setting function to choose wifi: from the main interface Settings to enter - click "More..."- check the "Airpplane mode", which has been open flight mode.
3. Or long press the power button - select the “the airplane Mode” function







- **The screen lock and unlock**

From set into: Settings—select "security"—click "Screen lock" — choose to apply your lock Screen.



- **Restore to factory default**

Select "Settings"-Select "Backup & reset "-select "Factory data reset"-click “Reset phone”

Storage Settings

Select "Settings"-"Select "storage and Menory"

- ***Language Settings***

  Select the "Settings" - "language and input" - "select" language ", choose to use in their own language



- Input method Settings

  Enter the "Settings", click "language and input" - choose to use the input method in setting it up - click on the icon on the right side



- **Android phone data cable links**

Select "Settings", select "developers options", check the "USB debugging"
Check the USB debugging the product can be installed on your computer



- **Introduce cross-screen display**

Select the "Settings" - "display" - check the "automatic rotary screen" -Mobile phone can automatically switch according to somehow screen put namely screen





- **Browser Features**

Visit the website
Browser -- Click in the URL input area -- Enter the URL of web browser--click "go" in the keyboard.





Download Web page images or other objects
Browser -- browse the web, long press the picture. There appear shortcut keys, then choose "save Image "function

- **How to use Hotknot?**

Note:
1、mobile phone must bring hotknot function
2、Hotknot now can transfer contacts, calendar, websites, images, video, music, APK, etc
3、mobile phones must screen and screen against, control the contact area of 1/3 to 1/2

4、the mobile phone when using hotknot function transfer files, please connect the charger or USB cable.
5、Do not connect to any AP before Hotknot transmission, please do not transfer wifi in complex environment, do not near the damp, heavy metal for Hotknot transmission.

Q/A

1. How to turn off the software running in the background too much

Download Advanced Task Manager and select “install”, it can help you achieve, automatic end of the program services, to switch between programs, display memory information, exclusion list, an end of all widgets, fast uninstall program and other functions, free up memory space, reduce the CPU's operation long pressure, increase speed and extend the purpose of standby time.

2. How to quickly set up Email

In the Android system, it can automatically set the POP3 or IMAP e-mail most accounts, the e-mail application, directly enter the e-mail address and password. If not automatically fit in the mailbox, the mailbox will be required by user Server information. See details in front of the "E-mail” Features section.

3. How do I view the capacity of phone memory case

Select the "Settings" -- Select Storage -- select phone memory" -- We will see the current phone memory capacity information phone

4. How to save electricity TUNES Y4

First, reducing the screen brightness can be used in peacetime by

reducing the brightness to reduce battery consumption, in the "Settings " in the "sound and display" found on "brightness", and then sliding scale in respect of the brightness can be set Android phones;
Close GPS global positioning, in the "Settings" and select "location services" -uncheck the following "Enable GPS satellite set" can be;
Usually if you do not use the Wi-Fi, Bluetooth headset can be improved by turning off these options to the standby time, turn off the WLAN search can save about 30% to 40% of standby time;
Usually close calls and text messages to remind vibration;

5. How TUNES Y4 lock screen, to prevent others from using

In the "Settings", select " Security "and then select "screen lock""pattern", to set individual unlock pattern, to prevent strangers use or purpose of ensuring privacy of confidential documents.

6. Why does not the USB data cable links your computer

Confirmed in the phone's "Settings"-""Developer options"-" in the "USB debugging" functionality check; also installed the correct USB driver

7. How to install a program on a non-Android Market

Select "Settings"-"" Security ", the"unknown source "function check

8. In browsing the web or other applications, how to switch to other applications

If you need to open when browsing other applications, you can long press the Home key to achieving long task switch, long press return directly to the desktop (note that the system default task only last 6 months)

9. How to enter the silent mode quickly

In addition to continuing foreign long press the volume down key,and directly Into the status bar select the silent mode.

10. How to forward SMS / MMS

Long press and Information applications in the information content of an item in the list, until the pop-up shortcut menu, select "Forward" can be realized.

11. how to paste and copy text

Into the input field -- "input string, long press and enter the region, there shortcut keys -- select al " cut all " ,"copy all", "paste all"

12. In the phone program group is installed too many applications, how to solve

In the desktop space – sliding the application to another application – click the application to open New Folder

13. Contacts are sorted, can change

Sort of way platform, the first number, then letters, then the Chinese way of sorting; the user can not set their own sort

14. Contacts whether to support the group

Enter contacts - > select group, you can create groups, then will contact man to join the corresponding group

15. contacts and SMS storage capacity limits the number of

Platform reason, contacts and SMS storage for no clear limit value, depending on the size of the current mobile phone memory space

16. How to set the phone storage, personalized ring tones

In the storage, are established "ringtones" (ringtones) "alarms" (alarm tone) "notifications" (SMS notification tone), the ring tones into a different folder, the phone can be automatically identified.

17. How to sync the phone contacts to the original TUNES Y4

Using Bluetooth can make the two cell-phone sync contacts;

18. How to use the TUNES Y4 access Wifi (WLAN)

Wifi signal at the scene to ensure that the premise of the specific see "Wifi function "

19. How to Find Contact

Into the contact interface, select the "Search" menu, you can search for contacts, you can use the first letter of query letters;

20 How do I delete the downloaded software

"Settings" - ""Manage app"-"Select the application to be deleted

21. How to view mobile phone version information

"Settings" - "" About phone "mobile phone version information can be obtained, including the Android version, Linux version, software version, hardware version, etc.

22. How do I copy SIM card contact information

Into the Contacts application, click the menu button, select "Import Contacts", then you can see the SIM card contacts, if only to import one, you can click an item. If all the import needs to long press the menu key, select Import to import all.

23 why the message has a different time and date display

Message displayed on the principle that the display of the day time and date have shown that non-day

24. TUNES Y4 whether to support the Java

Platform reason, TUNES Y4 does not support Java, if you need to install third-party Java applications, you need to install the Java runtime environment TUNES Y4.

25. How to open developer options

Enter the Settings -- about phone -- click the Build number four times, system will be generated developer options