Dear users，

Thank you for using our M71GY2

Before using this product, please read the instructions carefully.

This "manual" intends to introduce you the basic characteristics of this product, in order to help you use it the best way. This manual describes the product's features and information in details, as well as recommendations and attentions to help you fully understand the technical characteristics of the product.

In the package, you will find "warranty card", which discusses relevant provisions and product maintenance, as well as some value added services that we provide to users. Please read it carefully in order to avoid some discomforts. The product has better features and high performance. It will greatly improve your online satisfaction and continually enjoy its features.

Special note:

All the information in this manual is correct at the time of publication. However, as we continue to update and improve the product, the software in your device may be described as slightly different in appearance and functions.

(We reserve the right to improve the products. Specifications and designs are subject to change without prior notice!)

Content

Prompt 3
Technical parameters 4
Appearance Preview 4
1. Appearance Introduction 5
2. Charge 6
First experience 6
1. Boot the MID 6
2. Shutdown 7
3. Lock-screen and power-saving mode 8
4. Main interface description 8
5. Custom Screen 9
6. Connection of USB cable. 11
System setting 13
Internet Function 13
1. Network connection 13
2. Internet 14
Software Management 14
1. Explorer 15
2. Software installation 15
Applications 15
1. Music Playing 16
2. Picture browsing 17
3. E-mail 18
4. Apk Installer 19

Important Notices

... Do not disassemble the product by yourself. Do not use alcohol, thinner or benzene to clean the surface of the product, if there is any problem, please go to the nearest authorized service center.

... The product should be charged up to 12 hours in the first three charging time.

... Do not place the product in a place with high temperature, humidity or dust. Do not put the product in a vehicle with windows closed especially in summer.

... Avoid dropping or make strong impact to the product, do not let the touch screen be shaken violently, otherwise, it may cause damage to the touch screen or display incorrectly.

... Please select the appropriate volume. It should not be too high when using earphones, if you feel tinnitus, please turn down the volume or stop using the product.

... Please charge the product in the following cases:

A. The battery icon shows no power.

B. The system automatically shuts down or when you reboot, it shuts down again. (Low battery triggers the system to automatically shut down)

C. No response when pressing keys.

Note: Please use only the authorized adaptor to charge the machine. Do not use any unauthorized chargers, otherwise the machine may be burned.

... Please do not suddenly disconnect the machine when it is formatting or uploading and downloading is in progress, otherwise it may cause a program error.

... If improperly shutdown, the machine will scan and repair the disk when powered on, the interface may stay a long time in the progress.

... For memory loss caused by unauthorized repair or other mishandling reasons, the company is not responsible. Please properly use the product by following this manual.

... Do not use the product in places where the use of electronic device is prohibited such as aircraft and hospital.

... Please do not use the product when driving or walking in a street, otherwise, it may cause a car accident.

... This machine is not water resistant.

Technical parameters

Machine	CPU	RK3026 Duad core ,Cortex A9@ 1.3GHz
	Operating system	Android 4.2.2
	Browser	Google Browser
	Hard disk	4GB NAND Flash
	Memory	512MB DDR3
	Screen	7" TFT Touch Panel
	Resolution	800x480 Pixels
	Input method	Soft-keyboard on touch panel
	Earphone	3.5mm
	USB cable	Micro USB
	Battery	Li-polymer Rechargeable Battery 2800mAh 3.7V
	Size	191mm×109mm×9.9mm
	Weight	0.28kg
	Voltage	AC 110～240V 50/60Hz; DC 5V/2A
	Working temperature	-10℃～+40℃
	Music formats	OGG、AAC、FLAC、MP2、WAV、M4A、WMA、etc…
	Video formats	RM、RMVB、AVI、3GP、MP4、MOV、FLV、ASP、MPG、VOB、 MKV
	Picture formats	JPEG，BMP，PNG，GIF
	E-mail	Email, Gmail(Optional)
	Maps	Google map, Navigation map(Optional)
	Network access	WiFi (802.11 b/g/n)

General Information, Operations and Features

1. Features and Specifications

This chapter describes the appearance of the machine, including buttons and ports; it will guide you to understand the features and accessories.



(1) Power switch key (2) Earphone slot (3) USB slot (4) DC slot
(5) Volume key （6）Touch screen

Tablet Features and Usages

Note: (1) The LCD is a capacitive touch screen; you can use your finger in touching and dragging operations. Do not use pen, pencil or other sharp objects to click on the screen to avoid scratches.

(2) Please keep the speakers clean to prevent dirt that may block the hole and affect the sound.

(3) The back of the MID has antenna, please, do not cover with metal objects to avoid weak signal.

2. Charging

This product uses 5V/2A standard voltage. Only use the charger in the package, other unauthorized chargers may cause some failures and may burn the unit.

Do not use the charger in a humid environment. If your hands and feet are wet, please do not touch the charger.

When charging the product, please maintain good ventilation. Do not cover the machine with paper or other items resulting to a reduced cooling effect.

The MID can perform a variety of operating modes: (1) Clicking. (2) Holding. (3) Sliding. (4) Dragging. (5) Rotating.

Keys action definition: (1) Short press: the time is about 1 second. (2) Long press: the time is longer than 3 seconds.

360 degree rotation: The interface or images automatically move horizontally or vertically when the MID is being rotated.

Machine Operations and Features

1. Power On

1-1. To boot or power on, press the power switch key at the side of the machine. The LCD screen will initialize with the power-on animation and tone, a few seconds later, it will enter into the Lock screen interface, shown as below.

1-2. Hold lock button and drag to the right to unlock.



2. Shutdown

When the MID is running, long press the power switch key, the system will display the shutdown screen.

Click the "Power off" option and press “ok”.





* * * When battery is running low, the system will automatically shut down.

3. Lock-screen and power-saving mode

When the machine is on, short press the power switch key to place into a lock-screen or power saving mode.

To open, short press the power switch key. Hold and drag the lock icon to the right to unlock and bring back the unit to normal operation.



4. Main interface description



Text search icon	Click to enter into the Text search menu. Input a key word and search.
voice search icon	Click to enter into the voice search menu. Directly speak near to the microphone when saying the key word.
APPS icon	Click to enter into the applications menu.
Shortcut icon	Easy access of preferred menu which are used frequently.
Back key	In pop-up menu, press it to cancel operation. In the other menu, press it to back the front menu.
Home key	In any menu, press it to return back to the main interface.
Apps having been opened	Click to display all APPS programs that have been opened. Click each of the application to view.
Notice/Fast setting column	Click to display more information: USB, WIFI, Date etc. Click each item to enter into its setting menu.

In the main interface, the system displays 5 preset menus. You can add/delete other icons from the main menu.

5. Screen Customization and Adding of shortcut

In the main interface, click button to open Application menu. Press and hold desired menu to add to the main interface. You can drag or move it to your desired homescreen area.

Delete shortcut/widgets

In the main interface, press and hold the shortcut icon or widget until the appears on top of the screen. Drag the item to be deleted to icon until it turns red , release, and the chosen item will be deleted.

*** In the main interface, user can press and drag any shortcut icon or widgets to desired places to achieve personalized arrangement.

6. Connection of USB cable

When the MID is connected to computer with a USB cable, icon will be displayed onscreen.

Upon clicking of , it will display the following interface.



Click

to synchronize the operation of the MID and the computer. You can now copy or transfer files from TF card or MID memory to the computer or vice versa.

System setting

In the setting interface, user can customize some settings and view some important technical data.

Press 

in the main interface to enter into settings menu.

“APPS”

In the apps settings interface, user can see all installed applications. You can select and view. Apps may be uninstalled or deleted.





Internet Function

1. Network connection

The MID provides internet access through built-in Wi-Fi or 3G set-up (Internet over GPRS).

Click 

, MID will pop-up settings menu.



1-1WI-FI

1-1-1 Slide the “Wi-fi” switch button

to open the Wi-Fi.

1-1-2 Click “Wi-Fi” to enter into the Wi-Fi setting menu.

1-1-3 The system will automatically search and add the nearby networks that may be connected with. It displays the names of networks searched.





(2-3) Choose a wireless network. Oftentimes, a password is needed to connect. Type the password and click 

. Else, you cannot connect to wi-fi.

If the connection is successful, the network icon will be displayed on the top right corner of the screen. Full icon-bar means excellent connection.

Special note:

The machine will recognize the previous Wi-Fi connection, thus, it will automatically sense and connect to router which has been connected before. The machine saves the previous ones, unless it was manually disconnected, and it automatically connects once the unit is powered-on within the range of such routers.

Internet Function

2. Internet

2-1 Once wi-fi or data connected, click 

icon. The machine will display the previous websites. Or you may type a new website, search and connect.



2-2 Click the input bar, keyboard will pop-up, input a new Web site and open.

2-3 Click 
icon (see the red frame) , the machine will display the operation function menu.



Software Management

The product supports third-party applications on android platform, most applications can be obtained and downloaded from the Internet.

1.Explorer

Click 

in Application Program Interface to enter into explorer. You can browse, play, copy, delete, move, rename or edit some operations both from the machine or TF card memories.



2. Apps installation

2-1 Click the apps to be installed from the machine or TF card, MID will open the installer interface.



2-2 Click "Install", MID will show the progress bar. After installation, it will display "Application" already installed.

2-3 "Click "Finish" to exit.

2-4 Click the icon to open the software.

Applications

1. Music Playing

1-1 Click

on the “Application Program Interface” to enter into the playlist.

1-2 Click a music file to open the player and play it.



1-3 Background play

When playing a music, you may click to go back to the main interface. The machine,then, turns into a background play mode.

1-3-1 Click in the main interface to display its menu.



1-3-2 Select the music player to go back to the player menu.

Applications

2. Picture browsing

2-1 Click 

In ” Application Program Interface” to enter into picture browsing interface. These are the pictures and videos stored in the machine and TF card.

2-2 Select a picture to browse.

2-3 Select a video file to play.



Applications

3. E-mail

Click 

in" Application Program Interface" to enter into E-mail settings, input the email address and password, you can send and receive email messages.



4.Apk Installer

Click 

"Apkinstaller" choose "Install", then select the "Internal Memory" can be installed need software.





Click on the "Manage" for application, Launch, Export, Uninstall, Cancel the operation.





FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types MID (FCC ID: ZL9M71GY2) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the properly worn on the body is 0.4651W/kg. This device was tested for typical body-worn operations with the back of the outer housing kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's body and the back of the outer housing. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.