






# Quick Installation Guide

Indoor/Outdoor Wi-Fi Access Point  
iUAP-AC-M&Pro-6-M




1. Connect one side of a grounding cord to the GND terminal of the AP using the grounding screw.
2. Remove the ground wire notch of the port cover and pass the ground wire, then place back the port cover.
3. Connect the other side of the grounding cord to the grounding terminal connected to the earth or building.



### Method 2: Add the AP with Unique Cloud Code

1. Get the **Unique Cloud Code** from IP-COM ProFi App or IP-COM ProFi Cloud.
2. Refer to **Use Web Browser** to log in to the web UI of the AP, enable Cloud Maintenance and paste the **Unique Cloud Code**.
3. Add the AP to the project through **Device-joining Alert** on IP-COM ProFi App or IP-COM ProFi Cloud.

- Before operating, read and follow these precautions to prevent injury:
  - Device operating temperature: -30°C (-22°F) to +22°C (-12°F) (IAP-AC-IN); -30°C (-22°F) to +40°C (104°F) (IAP-DC-IN); Power adapter operating temperature: 0°C (32°F) to +70°C (158°F).
  - The device can be powered by safety extra-low voltages. The power adapter is for indoor use only and the only.
  - The IP is suitable for mounting at a height of 2-6 meters.
  - Do not use the device in a place where wireless devices are not allowed.
  - Use a power adapter or PoE power supply device with the required specifications.
  - Do not use the power adapter or PoE power supply device if it is damaged.
  - If the device operates power adapter supply, the main plug is used as the device power supply. The power adapter is not required. The power socket shall be installed near the device and easily accessible.
  - The device is waterproof, but avoid prolonged water immersion for safety and durability.
  - Keep the device away from fire, high electric field, high magnetic field, and inflammable and explosive items.
  - If such phenomena as smoke, abnormal sound or smell appear when you use the device, immediately stop using it and disconnect its power supply, unplug all connected cables, and contact the after-sales service personnel.
  - Do not use the device in a place where there are activities without authorization violates the warranty, and might cause safety hazards.
  - Refer all servicing to qualified service personnel.
- Disconnect the power source during servicing.
- For the latest safety information, see [Safety and Regulatory Information](#) on the [www.ip-com.cn](#) website.




 **Note**  
For initial setup or after a reset, set new login and Wi-Fi passwords for privacy and security (The longer the password, the stronger the protection). The character limit and composition rules for passwords are subject to software user interface prompts.

| Indicator status           | Description                                                                                                                                                                                         |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Blinking white (IUAP-AC-M) | The AP is starting up.                                                                                                                                                                              |
| Solid white (Pro-6-M)      | The AP is waiting to be managed by a controller (such as iW-COM ProFi Software Controller, iW-COM ProFi AP or iW-COM ProFi Cloud), an AP controller (AC), or a router with AP management function). |
| Blinking white (Pro-6-M)   | The AP is managed by a controller and is working properly.                                                                                                                                          |
| Solid blue                 | The AP <b>Locate</b> feature was activated in the ProFi Software Controller, iW-COM ProFi app or iW-COM ProFi Cloud.                                                                                |
| Fast blinking blue         | The Wi-Fi of the AP is disabled.                                                                                                                                                                    |
| Slowly blinking blue       | The AP is busy (for example, upgrading firmware). Do not cut off the power.                                                                                                                         |
| Alternating white/blue     |                                                                                                                                                                                                     |

**Q4: How to reset the AP?**  
**A4:** When the AP is idle, hold down the reset button (Reset) for about 8 seconds. Wait for about 1 minute until the AP is reset successfully.

**NOTE:** (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.



Copyright ©2025 IP-COM Networks Co., Ltd. All rights reserved.  
This documentation (including pictures, images, and product specifications, etc.) is for reference only.  
To improve internal design, operational function, and/or reliability, IP-COM reserves the right to make  
changes to the products described in this document without obligation to notify any person or  
organization of such revisions or changes.