

ShenZhen Chainway Information Technology Co., Ltd

# Mobile Data Terminal

---

## MC62 User Manual



# Content

|                                             |    |
|---------------------------------------------|----|
| Content .....                               | 1  |
| Statement .....                             | 3  |
| Chapter 1 Product intro .....               | 4  |
| 1.1 Intro .....                             | 4  |
| 1.2 Precaution before using battery .....   | 5  |
| 1.3 Notes .....                             | 6  |
| Chapter 2 Installation instructions .....   | 7  |
| 2.1 Appearance .....                        | 7  |
| 2.2 Install Micro SD and SIM cards .....    | 8  |
| 2.3 Battery charge .....                    | 9  |
| 2.4 Buttons and function area display ..... | 10 |
| Chapter 3 Call function .....               | 11 |
| 3.1 Calling numbers .....                   | 11 |
| 3.2 Contacts .....                          | 11 |
| 3.3 5G Function .....                       | 11 |
| 3.4 SMS and MMS .....                       | 11 |
| Chapter 4 Barcode reader-writer .....       | 12 |
| Chapter 5 RFID reader .....                 | 13 |
| 5.1 NFC .....                               | 13 |
| Chapter 6 Other functions .....             | 14 |
| 6.1 PING tool .....                         | 14 |
| 6.2 Bluetooth .....                         | 15 |
| 6.3 GPS .....                               | 16 |
| 6.4 Volume setup .....                      | 17 |
| 6.5 Sensor .....                            | 18 |

|                                       |    |
|---------------------------------------|----|
| 6.6 Keyboard .....                    | 19 |
| 6.8 Network .....                     | 20 |
| 6.8 Keyboard emulator .....           | 21 |
| Chapter 7 Device characteristic ..... | 23 |

# Statement

2013 by ShenZhen Chainway Information Technology Co., Ltd. All rights reserved.

No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, without permission written from Chainway. This includes electronic or mechanical means, such as photocopying, recording, or information storage and retrieval systems. The material in this manual is subject to change without notice.

The software is provided strictly on an “as is” basis. All software, including firmware, furnished to the user is on a licensed basis. Chainway grants to the user a non-transferable and non-exclusive license to use each software or firmware program delivered hereunder (licensed program). Except as noted below, such license may not be assigned, sublicensed, or otherwise transferred by the user without prior written consent of Chainway. No right to copy a licensed program in whole or in part is granted, except as permitted under copyright law. The user shall not modify, merge, or incorporate any form or portion of a licensed program with other program material, create a derivative work from a licensed program, or use a licensed program in a network without written permission from Chainway.

Chainway reserves the right to make changes to any software or product to improve reliability, function, or design.

Chainway does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any Chainway intellectual property rights. An implied license only exists for equipment, circuits, and subsystems contained in Chainway products.

# Chapter 1 Product intro

## 1.1 Intro

Chainway MC62 is a lightweight and portable high-performance mobile computer. With Android 13, octa-core processor, 4-inch touchscreen and 5000mAh removable battery, the excellent configuration delivers highly efficient operation. It supports barcode scanning, NFC, 13MP camera, multiple wireless connections, and features IP67 protection rating, 1.5 meters drop resistance. The mobile computer is thus widely applicable in various fields including warehousing, logistics, retail, finance, transportation, and manufacturing, helping users significantly improve work efficiency.

## 1.2 Precaution before using battery

- Do not leave battery unused for long time, no matter it is in device or inventory. If battery has been used for 6 months already, it should be checked for charging function or it should be disposed correctly.
- The lifespan of Li-ion battery is around 2 to 3 years, it can be circularly charged for 300 to 500 times. (One full battery charge period means completely charged and completely discharged.)
- When Li-ion battery is not in use, it will continue to discharge slowly. Therefore, battery charging status should be checked frequently and take reference of the related battery charging information on the manuals.
- Observe and record the information of a new unused and non-fully charged battery. On the basis of operating time of new battery and compare with a battery that has been used for long time. According to product configuration and application program, the operating time of battery would be different.
- Check battery charging status at regular intervals.
- When battery operating time drops below about 80%, charging time will be increased remarkably.
- If a battery is stored or otherwise unused for an extended period, be sure to follow the storage instructions in this document. If you do not follow the instructions, and the battery has no charge remaining when you check it, consider it to be damaged. Do not attempt to recharge it or to use it. Replace it with a new battery.
- Store the battery at temperatures between 5 °C and 20 °C (41 °F and 68 °F).

## 1.3 Notes

**Note:**

Using the incorrect type battery has danger of explosion.  
Please dispose the used battery according to instructions.

**Note:**

Due to the used enclosure material, the product shall only be connected to a USB Interface of version 2.0 or higher. The connection to so called power USB is prohibited.

**Note:**

The adapter shall be installed near the equipment and shall be easily accessible.

**Note:**

The suitable temperature for the product and accessories is -20°C to 50°C.

**Note:**

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

# Chapter 2 Installation instructions

## 2.1 Appearance



## 2.2 Install Micro SD and SIM cards

The cards sockets are showing as follows:



## **2.3 Battery charge**

By using USB Type-C contact, the original adaptor should be used for charging the device. Make sure not to use other adaptors to charge the device.

## 2.4 Buttons and function area display



| Designation      | Comments                    |
|------------------|-----------------------------|
| SCAN Button      | Keyboard SCAN button        |
| Direction Button | Operate direction of cursor |
| Keyboard         | Type numbers and characters |
| Power Button     | Power ON/OFF                |
| SCAN Button      | Side scan buttons           |

# Chapter 3 Call function

## 3.1 Calling numbers

1. Click icon  .
2. Click number key to input phone numbers.
3. Click icon  to call.
4. Click icon  to end call.

## 3.2 Contacts

1. Click contacts to open contacts list.
2. Click icon  to add new contacts.

## 3.3 5G Function


1. Open Settings
2. Select Network and Internet
3. Select SIM card
4. Enable 5G

## 3.4 SMS and MMS

1. Click  to open message window.
2. Click  to input message receiver and contents.
3. Click  to send out messages.

# Chapter 4 Barcode reader-writer

1. In App Center, to open 2D barcode scan test.
2. Press “SCAN” button or click scan key to start scanning, the parameter “Auto interval” can be adjusted.



 Caution: Please scan codes in correct way otherwise the scanning will be failed.

2D code:



Correct




Incorrect

# Chapter 5 RFID reader

## 5.1 NFC


Click App Center, open “NFC” to read and write tag information.



# Chapter 6 Other functions


## 6.1 PING tool

1. Open “PING” in App Center.
2. Setup PING parameter and select external/internal address.




## 6.2 Bluetooth

1. Open “BT Printer” in App Center.
2. In the list of detected devices, click the device that you want to pair.
3. Select printer and click “Print” to start printing contents.




## 6.3 GPS

1. Click “GPS” in App Center to open GPS test.
2. Setup GPS parameters to access GPS information.




## 6.4 Volume setup

1. Click “Volume” in App Center.
2. Setup volume by requirements.




## 6.5 Sensor

1. Click “Sensor” in App Center.
2. Setup the sensor by requirements.




## 6.6 Keyboard

1. Click “Keyboard” in App Center.
2. Setup and test the main value of the device.



## 6.8 Network

1. Click “Network” in App Center.
2. Test WIFI/Mobile signal by requirements.



## 6.8 Keyboard emulator

The keyboard emulator can be used in multiple operating background and output formats directly. And it includes Prefix/Suffix/Enter/TAB.

Please check Keyboard emulator manual for more details.

Note:

For each model, keycode of side button would be different, user needs to use keyboard in appcenter to check keycode and bind in Barcode2D.

19:52

100%

keyboardemulator v7.4.0.6

Function

AppSettings

2DSettings

Test

Enable Scanner

ON

| Barcode                                       | KeyCode        |                |
|-----------------------------------------------|----------------|----------------|
| <input checked="" type="checkbox"/> Barcode2D | <div>291</div> | <div>293</div> |
|                                               | <div>294</div> | <div>296</div> |

| UHF                          | KeyCode        |                |
|------------------------------|----------------|----------------|
| <input type="checkbox"/> UHF | <div>291</div> | <div>294</div> |

# Chapter 7 Device characteristic

## Physical characteristics

|                       |                                                                                             |
|-----------------------|---------------------------------------------------------------------------------------------|
| <b>Size</b>           | 163.5 x 67.0 x 17.1mm/6.44 x 2.64 x 0.67in                                                  |
| <b>Weight</b>         | 256g / 9.03oz (device with battery)                                                         |
| <b>Keypad</b>         | Multi-touch panel, gloves and wet hands supported                                           |
| <b>Display</b>        | 4-inch, 480 x 800                                                                           |
| <b>Touch panel</b>    | Multi-touch panel, gloves and wet hands supported                                           |
| <b>Sensor</b>         | Gravity sensor, distance sensor, light sensor; Gyroscope (optional), geomagnetic (optional) |
| <b>Battery</b>        | 5000mAh removable battery, support quick charge                                             |
| <b>Notification</b>   | Sound, LED indicator, vibrator                                                              |
| <b>Expansion Slot</b> | 1 slot for SIM card, 1 slot for SIM or TF card                                              |
| <b>Interfaces</b>     | USB Type-C, USB 2.0, OTG                                                                    |

## Performance

|                                |                                          |
|--------------------------------|------------------------------------------|
| <b>CPU</b>                     | Octa-core, 2.0 GHz                       |
| <b>OS</b>                      | Android 13                               |
| <b>RAM</b>                     | 3GB                                      |
| <b>Communication Interface</b> | USB Type-C, USB 2.0, OTG                 |
| <b>ROM</b>                     | 32GB                                     |
| <b>Max. expansion</b>          | Supports up to 128 GB Micro SD (TF) card |

### User environment

|                             |                                                                                       |
|-----------------------------|---------------------------------------------------------------------------------------|
| <b>Operating temp.</b>      | -20°C to 50°C                                                                         |
| <b>Charging temp.</b>       | -20°C to 40°C                                                                         |
| <b>Storage Temp.</b>        | -40°C to 70°C                                                                         |
| <b>Humidity</b>             | 5%RH - 95%RH non condensing                                                           |
| <b>Sealing</b>              | IP65, IEC sealing standard                                                            |
| <b>Drop specification</b>   | Multiple 1.5 m / 4.9 ft. drops to the concrete across the operating temperature range |
| <b>Tumble Specification</b> | 1000 x 0.5m / 1.64ft. falls at room temperature                                       |
| <b>Sealing</b>              | IP67 per IEC sealing specifications                                                   |
| <b>ESD</b>                  | ±15 KV air discharge, ±8 KV conductive discharge                                      |

### Communication

|                  |                                                                                                                                                     |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>WWAN</b>      | <b>2G:</b> GSM (850 / 1900MHz)<br><b>3G:</b> WCDMA (B2 / B4 / B5)<br><b>4G:</b> FDD-LTE (B2 / B4 / B5 /B7 / B12 / B17)<br>TDD-LTE (B38 / B40 / B41) |
| <b>Vo-LTE</b>    | Support                                                                                                                                             |
| <b>WLAN</b>      | IEEE802.11 a/b/g/n/ac, 2.4G/5G dual-band, 5G PA                                                                                                     |
| <b>Bluetooth</b> | Bluetooth 5.0                                                                                                                                       |

### Data collection

|                         |                                               |
|-------------------------|-----------------------------------------------|
| <b>Barcode scanning</b> | Zebra: SE4710; CB300; CM60                    |
| <b>Camera</b>           | Rear: 13MP Autofocus with flash<br>Front: 5MP |
| <b>RFID</b>             | NFC 13.56Mhz                                  |

### Developing Environment

|                 |                               |
|-----------------|-------------------------------|
| <b>SDK</b>      | Chainway software develop kit |
| <b>Language</b> | Java                          |
| <b>Develop</b>  | Eclipse/Android Studio        |

# Appendix

## FCC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC SAR statements:

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types MC62 ( FCC ID: 2AC6AMC62 ) has also been tested against this SAR limit.

This device was tested for typical body - worn operations with the back of the handset kept 10mm from the body.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be Avoided.