

T-Mobile

Welcome

Start Guide

T-Mobile



alcatel

CJBXXXXXXXXAA



TABLE OF CONTENTS

Watch

| | | | |
|----------------------------------|----|--|----|
| Overview..... | 1 | Backlight..... | 13 |
| What's in the box..... | 4 | Sound..... | 13 |
| Getting Started..... | 5 | Data Roaming..... | 14 |
| Home screen..... | 5 | Bluetooth..... | 14 |
| Powering..... | 5 | System updates..... | 14 |
| Charging..... | 5 | About watch..... | 15 |
| Changing band..... | 7 | Operation Systems..... | 15 |
| Settings list..... | 9 | Safety and use..... | 16 |
| 📞 Call(s)..... | 9 | Safety..... | 16 |
| 📧 Messages(s)..... | 9 | Battery..... | 21 |
| 📅 To do list..... | 10 | Charger..... | 22 |
| 🕒 Time..... | 10 | Ingress Protection (IP) Rating..... | 22 |
| 🚶 Active..... | 10 | When using your device, note that..... | 23 |
| ☁ Weather..... | 10 | Resistance to solid objects such as dust..... | 25 |
| 🎵 Music (big part for user)..... | 11 | Resistance to water..... | 25 |
| Settings..... | 12 | Allergens..... | 26 |
| Airplane mode..... | 12 | Radio waves..... | 26 |
| Changing your watch face..... | 12 | Privacy..... | 28 |



TABLE OF CONTENTS

| | |
|----------------------------------|----|
| Data privacy..... | 29 |
| Licenses..... | 31 |
| Warranty..... | 31 |
| Disclaimer | 35 |
| Recycling | 36 |
| APPROVED FIRMWARE VERSIONS | 38 |
| EMERGENCY CALL | 39 |
| ADDITIONAL INFORMATION | 40 |

MOVETIME APP



| | |
|---|----|
| Application..... | 41 |
| Download and install Movetime app..... | 41 |
| Creating an account | 42 |
| Pairing | 44 |
| App main screen | 50 |
| Members management..... | 52 |
| Adding a member manually | 52 |
| Adding a member via QR code scanning | 53 |
| Messaging..... | 54 |
| Voice message..... | 54 |
| Text message..... | 56 |
| Settings..... | 57 |
| Safe zone | 57 |
| Steps..... | 58 |
| Manage watch | 59 |
| Mute time..... | 60 |
| Upgrade..... | 61 |

OVERVIEW





What's in the box



GETTING STARTED

Home screen

Press the **Power key** to instantly access the Home screen.




Powering

Press the **Power Key** for 3 seconds to power on/off your watch.


Press the **Power key** for 8 seconds to restart your watch.

Charging

1. Ensure that the pins in the charging dock are aligned with the pins in the back cover of your watch.



2. Connect the USB port with a computer or charger, to begin charging.



3. After fully charging your watch, unplug the USB port from the electric socket or computer.

Changing band

The watch comes with two bands. In order to replace the band, follow the steps below:


1. Remove the band

Disconnect the band by pulling the silver knots to the right and the band will be released from the watch.




2. Attach the new band

Align the silver knots to one side of the band holders and push the silver knots to the opposite side. When the second silver knot is aligned with the band holder, release the silver knot.



SETTINGS LIST

Press the **Home key** to enter the app list. Press the **Volume up/down key** to select the app.



Call(s)

The Call app enables you to make and answer phone calls using your watch. Up to ten contacts can be stored in your watch. When there is an incoming call, press the **Home key** to answer the phone or press the **Power key** to reject the call. Press the **Volume up/down key** to mute the call.

Messages(s)

The messages app allows you to send and receive messages from your contacts using your watch. The watch can store up to 30 messages.

Once you exceed 30 messages, the oldest message will be automatically deleted.

To do list

The To-do list app allows you to schedule your tasks and events. It is synchronized with a calendar account in the MOVETIME app. The watch can display up to 10 events.

Time

The Time icon allows you to set up an alarm, stopwatch and timer.

Active

Active counts the number of steps you take. You can set your goal in the app and turn on the step counter during your workout. The Active feature only works when the watch is powered on.

Weather

Weather provides a forecast for the next 12 hours and for the following 4 days. The current temperature is displayed at the bottom left of the screen. You can press up/down to switch

between today's forecast and the forecast for the next 4 days.

Music

The music app allows you to play music stored in your watch.

Transfer music

You can copy MP3 music files to the watch via USB.

1. Connect your watch to computer through USB charging dock.
2. Select the musics from your computer. Right Touch and choose "Copy/send to your watch".

Play music

1. Press the **Home key** to enter the app list.
2. Press the **Volume up/down key** to select **Music**.
3. Press **Home key** to play.

To adjust the volume, press the **Volume up/down key**.

SETTINGS

Settings allows you to configure your watch face, backlight, sound, data roaming, Bluetooth, firmware, language, factory settings, etc.. Use the up/down key to navigate through the settings menu.

On the Home screen, press the **Volume up key** to enter settings.

Airplane mode

1. On the Home screen, press the **Volume up key** to enter settings.
2. Slide up/down, and press the **Home key** to enter Airplane mode settings.
3. To turn on/off the airplane mode, press the **Home key**.

Changing your watch face

1. On the Home screen, press the **Volume up key** to enter settings.
2. Slide up/down, and press the **Home key** to enter watch face settings.

3. Press the **Volume up/down key** to select a new watch face, and press the **Home key** to save.

Backlight

1. On the Home screen, press the **Volume up key** to enter settings.
2. Slide up/down, and press the **Home key** to enter backlight settings.
3. Press the **Volume up/down key** to set the backlight as 8s, 5s, 3s or off. Stay 3s to automatically save. The default is 3s.

Sound

1. On the Home screen, press the **Volume up key** to enter settings.
2. Slide up/down, and press the **Home key** to enter sound settings.
3. Press the **Volume up/down key** to adjust the volume. Press **Home key** to turn on/off the vibration.

Data Roaming

1. On the Home screen, press the **Volume up key** to enter settings.
2. Slide up/down, and press the **Home key** to turn on/off the data roaming. When you use it at the first time, a warm prompt will be display, to explain the data roaming. Press the **Home key** to go on, and press the **Power key** to go back.

Bluetooth

1. On the Home screen, press the **Volume up key** to enter settings.
2. Slide up/down, press **Home key** to turn on/off the Bluetooth.
3. Pair the device and watch by press **Home key**. If you watch linked with your device before, it will attempt to link with this device again once you turn on the Bluetooth.

System updates

1. On the Home screen, press the **Volume up key** to enter settings.

-
2. Slide up/down, and press the **Home key** to download the updates.

About watch

1. On the Home screen, press the **Volume up key** to enter settings.
2. Slide up/down, and press the **Home key** to display the watch info. (Network, Model number, Serial number...etc.)

OPERATION SYSTEMS

- Android 4.3 and above
- iOS7 and above

SAFETY AND USE

We recommend that you read this chapter carefully before using your device. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

Safety

You are advised to switch off watch from time to time to optimize its performance.

Switch MOVETIME Connected Watch off before boarding an aircraft.

Switch MOVETIME Connected Watch off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile devices can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch MOVETIME Connected Watch off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, chemical plant, or in any potentially explosive atmosphere.

When MOVETIME Connected Watch is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid, insulin pump, etc.

Please note that MOVETIME Connected Watch is a unibody device, the battery is not removable. Do not attempt to disassemble MOVETIME Connected Watch. If you disassemble your device the warranty will not apply. Disassembling the device may damage the battery and may cause leakage of substances that could create an allergic reaction.

Always handle your MOVETIME Connected Watch with care and keep it in a clean and dust-free place.

Do not allow MOVETIME Connected Watch to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The manufacturer's recommended operating temperature range is -10°C to $+50^{\circ}\text{C}$.

At over 55°C the legibility of the device's display may be impaired, though this is temporary and not serious.

Do not open, dismantle or attempt to repair your MOVETIME Connected Watch yourself.

Do not drop, throw, or bend your MOVETIME Connected Watch.

Do not use MOVETIME Connected Watch if the glass made screen, is damaged, cracked, or broken to avoid any injury.

Do not paint it.

Use only batteries, battery chargers, and accessories which are recommended by TCL Communication Ltd. and its affiliates and are compatible with your device model. TCL Communication Ltd. and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Pay attention to any warnings.

Do not attempt to open or disassemble MOVETIME Connected Watch. Under inappropriate operation, the device and battery can be damaged and be hazardous to the human body and the environment.

Do not clean MOVETIME Connected Watch with corrosive cleaning products.

Do not place MOVETIME Connected Watch in dishwashers, washing machines, or dryers.

Do not place MOVETIME Connected Watch on or in heating devices, such as microwave ovens, stoves, or radiators.

Do not expose MOVETIME Connected Watch to extreme temperatures. The recommended temperature ranges from **-20°C to 55°C**.

Do not place MOVETIME Connected Watch close to fire.

Do not dispose of MOVETIME Connected Watch in a fire. This may cause the device to explode.

Prevent the USB connector from contacting water to avoid rust.

Do not crush, drop, or puncture your MOVETIME Connected Watch.

You are not recommended to wear MOVETIME Connected Watch on the frequently-used hand.

Do not disassemble or open crush, bend or deform, puncture or shred

Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse

or expose to water or other liquids, expose to fire, explosion or other hazard.

Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.

Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.

Only authorized service providers shall replace battery. (If the battery is non-user replaceable).

Promptly dispose of used batteries in accordance with local regulations

Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.

Improper battery use may result in a fire, explosion or other hazard.

For those host devices that utilize a USB port as a charging source, the host device's user manual shall include a statement that the phone shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

Battery

Please note your MOVETIME Connected Watch is a unibody device, the battery is not removable. Observe the following precautions:

- Do not attempt to open the back cover.
- Do not attempt to eject, replace, or open battery.
- Do not puncture the back cover of your device.
- Do not burn or dispose of your device in household garbage or store it at temperature above 60°C.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Charger

Following air regulation, the battery of your product is not fully charged. Please charge it first.

Main powered chargers will operate within the temperature range of: 0°C to 45°C.

The chargers designed for MOVETIME Connected Watch meet with the standard for safety of information technology equipment and office equipment use. They are also compliant to the ecodesign directive 2009/125/EC. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

Characteristics of power supply (depending on the country):

Battery: Lithium 490 mAh

Ingress Protection (IP) Rating

Your device has been tested in a controlled environment and certified to be water- and dust-resistant in specific situations (meets requirements of classification IP67 as described by the international standard IEC 60529 - Degrees

of Protection provided by Enclosures [IP Code]; test conditions: 15 - 35 °C, 86 - 106 kPa, 1 metre, 30 minutes). Despite this classification, your device is not impervious to water damage in any situation.

You may, for example, wear and use the device during exercise (exposure to sweat is OK), in the rain, and while washing your hands with fresh water. But submerging your device is not recommended and the device is only protected against low pressure water stream. Therefore, it's not recommended to wear your device while swimming or taking a shower.

When using your device, note that

If the device is exposed to moisture, dry it thoroughly with a clean, soft cloth. If the device is exposed to any liquid other than fresh water, such as salt water, liquid chemicals, vinegar, alcohol, and liquid detergent, rinse the device with fresh water immediately and dry it thoroughly with a clean, soft cloth. Failure to rinse the device in fresh water and dry it as instructed may cause it to suffer from operability or cosmetic issues.

Dry your device before charging.

Do not submerge the device.

Do not expose the device to pressurized water or high velocity water, such as water running from a tap, ocean waves, or waterfalls.

Do not wear your device in the sauna or steam room.

Even if your device is resistant to dust and water, you should avoid exposing it to environments with excessive dust, sand and mud or to moist environments with extreme high or low temperatures.

Your warranty does not cover damage or defects caused by abuse or improper use of your device (including use in environments where the relevant IP rating limitations are exceeded).

The first digit in the two-digit IP rating indicates the level of protection against solid objects, such as dust. The second digit indicates how resistant the device is to water, as explained in the table below:

Resistance to solid objects such as dust

- 0: No special protection
- 1: Protected against solid objects larger than 50mm in diameter
- 2: Protected against solid objects larger than 12mm in diameter
- 3: Protected against solid objects larger than 2.5mm in diameter
- 4: Protected against solid objects larger than 1mm in diameter
- 5: Protected against dust; limited ingress (no harmful deposit)
- 6: Totally protected against dust

Resistance to water

- 0: No special protection
- 1: Protected against dripping water
- 2: Protected against dripping water when device is tilted up to 15 degrees
- 3: Protected against spraying water
- 4: Protected against splashing water

- 5: Protected against low pressure jets of water from all directions
- 6: Protected against temporary flooding of water
- 7: Protected against the effects of immersion in up to 1 metre of water for 30 minutes

Allergens

TCL Communication Ltd. avoids using known allergens in our products. From time to time, trace amounts of an allergen may be added during manufacture of a device or device component that could cause discomfort for some individuals. This approach is common for many types of products. We recommend that you monitor any products that may be in prolonged contact with your skin, and remove them if you experience skin irritation.

Radio waves

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service (e.g. FM broadcast), they bear the following statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

For other devices, they bear the following statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: **2ACCJAT01**

PRIVACY

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your device regarding taking photographs and recording sounds with your device. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of

other people or any of their personal attributes, and duplicate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorisation be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your device (including the operator) disclaim any liability which may result from the improper use of the device.

Data privacy

Please note by using MOVETIME Connected Watch some of your personal data may be shared with the main device (smartphone). It is under your own responsibility to protect your own personal data, not to share it with any unauthorized devices or third party devices connected to yours. Be sure to remove or clear all personal information before you recycle, return, or give away your product. Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your product's performance and/or have access to private information including account details, call data, location details and network resources.

Note that any data shared with TCL Communication Ltd. is stored in accordance with applicable data protection legislation. For these purposes TCL Communication Ltd. implements and maintains appropriate technical and organizational measures to protect all personal data, for example against unauthorized or unlawful processing and accidental loss or destruction of or damage to such personal data whereby the measures shall provide a level of security that is appropriate having regard to

- the technical possibilities available,
- the costs for implementing the measures,
- the risks involved with the processing of the personal data, and
- the sensitivity of the personal data processed.

You can access, review, and edit your personal information at any time by logging into your user account, visiting your user profile or by contacting us directly through privacy@tcl.com. Should you require us to edit or delete your personal data, we may ask you to provide us with evidence of your identity before we can act on your request.

LICENSES



® The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCL Communication Ltd. and its affiliates is under license. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. Other trademarks and trade names are those of their respective owners.

Alcatel SM06 Bluetooth Declaration ID D0XXXXX

WARRANTY

TCL Communications Ltd. warrants to the original retail purchaser of this wireless device that should this product or part thereof during normal consumer usage and condition be proven to be defective in material or workmanship that results in product failure within the first twelve (12) months from the date of purchase as shown on your original sales receipt from an authorized sales agent. Such defect(s) will be repaired

or replaced (with new or rebuilt parts) at the company's option without charge for parts or labor directly related to the defect(s). Batteries, power adapters, and other accessories sold as in box items are also warranted against defects and workmanship that results in product failure within the first twelve (12) month period from the date of purchase. This warranty extends to products purchased and sold within the United States.

The limited warranty for your wireless device will be voided if any of the following conditions occur:

- Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your device is used;
- Connection to any equipment not supplied or not recommended by TCL Communications Ltd.;
- Modification or repair performed by individuals not authorized by TCL Communications Ltd. or its affiliates;
- Changes to the device operating system by the user or third party applications;

-
- Removal or altering of the wireless device's event labels or serial numbers (IMEI);
 - Damage from exposure to water or other liquids, moisture, humidity, excessive temperatures or extreme environmental conditions, sand, excess dust and any condition outside the operating guidelines;
 - Rooted devices;
 - Damage as result of physical abuse regardless of cause.

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your jurisdiction. In no event shall TCL Communications Ltd. or any of its affiliates be liable for incidental or consequential damages of any nature whatsoever, including but not limited to commercial loss, to the full extent those damages can be disclaimed by law. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

How to obtain Support: Contact the customer care center by calling (855-368-0829) or going to (<http://www.alcatelonetouch.us>). We have placed many self-help tools that may help you to isolate the problem and eliminate the need to send your wireless device in for service. In the case that your wireless device is no longer covered by this limited warranty due to time or condition, you may utilize our out of warranty repair options.

How to obtain Hardware Service within the terms of this warranty: Create a user profile (alcatel.finetw.com) and then create an RMA for the defective device. Ship the device with a copy of the original proof of purchase (e.g. original copy of the dated bill of sale, invoice) with the owner's return address (No PO Boxes accepted), wireless carrier's name, alternate daytime phone number, and email address with a complete problem description. Only ship the device. Do not ship the SIM card, memory cards, or any other accessories such as the power adapter. You must properly package and ship the wireless device to the repair center. TCL Communications Ltd. is not responsible for devices that do not arrive at the service center or are damaged in transit. Insurance is recommended with proof

of delivery. Upon receipt, the service center will verify the warranty conditions, repair, and return your device to the address provided in the RMA.

DISCLAIMER

TCL communication Ltd. will not be liable for any damages of any kind arising out of or relating to the use or the inability to use the software or any third party application, its content or functionality, including but not limited to damages caused by or related to errors, omissions, interruptions, defects, delay in operation or transmission, computer virus, failure to connect, network charges, in-app purchases, and all other direct, indirect, special, incidental, exemplary, or consequential damages even if TCL communication Ltd. Has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusions or limitations may not apply to you. Notwithstanding the foregoing, TCL communication Ltd. Total liability to you for all losses, damages, causes of action, including but not limited to those based on contract, tort, or

otherwise, arising out of your use of the software or third party applications on this device, or any other provision of this EULA, shall not exceed the amount you paid specifically for the MOVETIME application or any such third party application that was included with this device. The foregoing limitations, exclusions, and disclaimers shall apply to the maximum extent permitted by applicable law, even if any remedy fails its essential purpose.

There may be certain differences between the user manual description and the MOVETIME connected watch's operation, depending on the software release of your device or specific operator services.

Recycling

Please don't dispose of products or electrical accessories (such as chargers, or batteries) with your household waste.

Warning: Do not dispose batteries or mobile devices in a fire place since they might explode.

These items should be disposed of in accordance with the national collection and recycling

schemes operated by your local or regional authority.

You may return unwanted **Alcatel** products and electrical accessories to any **Alcatel** Approved Service Center in your region. Packaging and product parts should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

Device and battery as a unibody device must be disposed of in accordance with locally applicable environmental regulations.



This symbol on your device, the battery, and the accessories indicates that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centers with specific bins for these items of equipment.
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points.

In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

APPROVED FIRMWARE VERSIONS

This device will only operate with firmware versions that have been approved for use by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device, it will not function.

EMERGENCY CALL

Although all phones are equipped with 9-1-1 emergency calling capabilities, this phone may or may not permit its location to be approximated during a 9-1-1 call.*

*Availability of this feature depends on upgrades to the (a) wireless network and (b) 9-1-1 calling system that are required to be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/ limitations, interconnecting carrier problems, your phone, buildings/ tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped, or refused. The phone's approximate location is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services

personnel. You should not rely solely on a mobile device for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions, and Privacy Policy for additional service restrictions and details.

ADDITIONAL INFORMATION

Use of some content or features may require qualifying service or access to a Wi-Fi connection.

Wi-Fi: Devices using wireless connections may be vulnerable to unauthorized attempts to access data on the device. Plan data allotment applies to use by connected devices sharing Wi-Fi. Use of connected devices subject to T-Mobile's Terms and Conditions.

Device, screen and accessory images simulated. Coverage not available in some areas. See Terms and Conditions (including arbitration provision) at T-Mobile.com, for rate plan information, charges for features and services, and restrictions and details, including important limitations on availability and reliability of 9-1-1 emergency service when using Wi-Fi calling.

APPLICATION

Download and install Movetime app

For Android

- Search for "Movetime" in the Google Play store.

For iOS


- Search for "Movetime" in the App Store.

QR code



Creating an account

1. If you are a first time user, touch on **Register** to create your MoveTime account.



2. Enter an Email account and set your password. A valid code will be sent to your Email account, input the code and touch "Next".

Register

Input your Email

Input your password

Input valid code

Next

Cancel Next

Note: The email account that you registered will be used to recover your password as well.

Pairing

1. Obtain the IMEI number.

IMEI number can be obtained from

- From the Kids watch box.
 - By pressing the Volume Up/Down and SOS button at the same time.
2. Input the IMEI number and press confirm.

Add Watch

Input watch's SN(IMEI) Number


SN(IMEI) number Confirm

OR

Scan QR code

Cancel Next

3. You will receive a code on your watch. Save the code and enter on the text box below and press confirm.



QR code can also be used to all members on the watch. To add members using the QR code:


- Save and share QR picture.
- Directly share QR numbers to other members.




4. Select your identity.




5. Enter your child's personal information.



6. If the MoveTime and phone have been successfully paired, the parent's application main screen will now appear on your phone with a map indicating the MoveTime's location.



App main screen



-   Show or hide the shortcut menu.
-  Touch to refresh your MoveTime's location.
-  Touch to view and setup electronic fences.
-  Touch to calculate the itinerary to your kid's watch.
-  Touch to see your kid's step counting.



Battery level indicator: Touch to change the Power Saving settings.



Touch to call your kid's watch.



Touch to access the voice messages exchanged with your kid's watch.


MEMBERS MANAGEMENT

Members can be setup in the parent's application in 2 ways: manually or via the scanning of a QR code.

Adding a member manually


Touch the Address Book entry and then in the  of one of the available contacts. Fill in Member's identity, phone number and photo and save your changes.

Members added manually can call and be called by the MoveTime. They'll also be notified by SMS in case of SOS alert initiated by the kid.



Adding a member via QR code scanning

Touch the Address Book entry and then in the  of one of the available contacts to get the QR code.




MESSAGING

Voice message


Touch the setting icon to select to send the voice message to the kid or to all the family members. The voice message is sent to the kid only by default.

- Unread messages are indicated with a red dot.
- Touch in one of the messages to listen to it.
- Touch and hold the button in the bottom of the screen to send a voice message of up to 15 seconds to your MoveTime.
- Press and hold 2s to clear the message.



Text message

1. Preset SMS in the app for kids to use in the watch and touch save. Up to 10 SMS can be saved in the Movetime App. The maximum wordage of Pre-SMS is 70.
2. OK, yes, on my way, I am busy now, I will call you back later are available by default.




SETTINGS

Safe zone

Touch **##** on the main screen to access the Safe Zone menu.


You can setup geographical areas called safe zones (ex: home, school, grandma's...) normally visited by your child.

Once setup, you'll receive notifications in your parent's application everytime your kid enters or leaves a safe zone.




Steps

Touch to set a goal. Steps and distance are counted and saved after setting. Date statistics saves data from the current month. Month statistics saves data from the latest 12 months.




Manage watch

1. Touch the area on the right to enter the map page. Slide left to select Delete the watch.
2. Touch the profile picture to view the kids' information.
3. Touch the + to add new watch.



Mute time

You can set the MoveTime to mute or toggle vibrate mode along with setting up schedules. Note that children can decide to unmute by adjusting the volume on their MoveTime, however vibrate mode can only be controlled via the App.



Upgrade

Enter to check if a new software version is available for your watch and Movetime App.

Touch the icon on the boom of screen, check and install the new firmware version (If any)

