


Introduction

Aqara Water Leak Sensor is used to detect water leaking and flooding. It is able to give real-time alarm through App and control other smart hardware products via gateway devices, such as Mijia Multifunction Gateway.

* This product must be connected to a gateway device in order to function.



Basic information

Model: SJCGQ11LM

Dimensions: 50*50*15 mm

Wireless connection: ZigBee

Working temperature: - 10°C- +55°C

Working humidity: 0%- 100% RH

Device supported: Android 4.4/iOS 8.0 and above

Download App

Search for “Mijia” in App Store or scan the barcode to download Mijia App. Connect the Sensor to a gateway device, and then add it according to the instruction in “Add Device”.


Add device

Start the App, select the gateway to be connected, and click “Add Sub-device” in the Device Interface; then follow the instructions of the App until it prompts that the gateway is successfully connected.

* If adding failed, please move the gateway device closer to the Sensor and try again.

Installation

Verification of valid distance: after the Sensor is successfully added, press the Reset button at the selected installation position, the gateway will prompt which means that there is valid communication between the Sensor and the gateway.



Method : place the Sensor on a required plane directly without using the paster;



- *The surface of the plane must be clean
- *Do not install on metal surface

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

IC NOTICE TO CANADIAN USERS

This device complies with Industry Canada license - exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. This device complies with RSS - 247 of Industry Canada. Operation is subject to the condition that this device does not cause harmful interference. This Class B digital apparatus complies with Canadian ICES - 003 (Cet appareil numérique de la Classe B conforme à la norme NMB - 003 du Canada).

This equipment complies with FCC & IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites FCC & IC d'exposition aux radiations définies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps. Cet émetteur ne doit pas être situé ou opérant en conjonction avec une autre antenne ou émetteur.