

IC card reader (CL-M706)

Features

1. For card authorization, issuing, recharge, cancellation
2. Support ISO / IEC 14443 series of contactless IC card;
3. Read/write distance: 0 ~ 50mm;
4. With a standard RS232 interface;

Technical Specification

Item: IC card reader

Dimension: 200x152x52mm

Material: Metal, industrial plastics

Voltage: DC 5V

Read/write time: ≤ 0.3 seconds

Read distance: 0mm ~ 50mm

Read/write mode: wireless magnetic Sensor

Frequency: 13.56MHz

Power consumption: ≤ 3 W

Working temperature: $-10^{\circ}\text{C} \sim +60^{\circ}\text{C}$

Communication interface: USB



User Manual

1. Insert one side USB cable into reader USB port.
2. Insert another side USB cable into PC USB port.
3. Place card on issuing card area.
4. Open the PC-end application software to operate.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.