

TinyGateway PoE

Short User Manual

Introduction

TinyGateway PoE (referred to also as TinyGateway or gateway or product) is a low-power and low-cost gateway, based on ESP32-S3 processor (for Ethernet connectivity) and on nRF52832 SoC (for BLE or Wirepas communication).

TinyGateway PoE is available in two versions:

- **BLE**: scanner and advertiser device of Bluetooth Low Energy packets;
- **Wirepas**: sink node for Wirepas Mesh 2.4GHz networks.

TinyGateway is provided in the following models:

- **Indoor**: compact light-weight plastic enclosure suitable for indoor wall or ceiling installation. Dual power-supply: 5VDC USB (through USB-C connector) or 44-57VDC (through PoE RJ45 connector).
- **Outdoor**: compact robust UV-protected PS enclosure with IP65 rating. Power-supply is provided through PoE RJ45 connector, with voltage range 44V to 57VDC.

Before you start using a TinyGateway PoE, verify that it is undamaged and carefully read the instructions in this user manual, particularly the indications in the "Safety" section.

BlueUp S.r.l. disclaims any and all liability if the devices are used in modes and environments incompatible for keeping the product intact, safe and in operation.

Technical characteristics

Hardware

Platform:	Espressif Systems ESP32S3WROOM-1
Processor:	ESP32-S3 series, Xtensa® dual-core 32-bit LX7 microprocessor, up to 240MHz
Connectivity:	Ethernet (802.3af), Bluetooth Low Energy (v4.x/v5.x) or Wirepas 5.x

Electrical specifications

Indoor version

Connector:	USB: USB-C connector PoE: RJ45 connector
Voltage:	5 Vdc (USB) or 44 to 57 Vdc (PoE)

Outdoor version

Connector:	IP rated RJ45 connector
Voltage:	44 to 57 Vdc

Mechanical and environmental specifications

Size:	Indoor version: 124 x 100 x 35 mm; Outdoor version: 185 x 185 x 65 mm
Mounting options:	Indoor version: 2x M3.5 screws (not included); Outdoor version: pole mounting kit included
IP protection:	Indoor version: IP40; Outdoor version: IP65
Operating temperature:	-40°C to +65°C
Humidity:	10-90% non condensing

Procedures

Refer to the full User Manual available on BlueUp support website for a detailed description on the procedures for gateway installation, power supply and configuration:

BLE: <https://support.blueupbeacons.com/portal/en/kb/articles/tinygateway-poe-ble-user-manual>

Wirepas: <https://support.blueupbeacons.com/portal/en/kb/articles/tinygateway-poe-wirepas-user-manual>

Installation and Power supply

TinyGateway PoE can be installed on any flat surface (wall or ceiling), where the power supply cables can reach the gateway. The gateway can be installed using the screws, as described below.

USB-C connector (Indoor version)

1. Install the gateway on the wall using the screws for the holes in the lateral flanges (2x M3.5 screws, not included).
2. Connect the gateway to the LAN using standard Ethernet cable.
3. Power-up TinyGateway PoE using a standard USB-C cable, with continuous voltage 5V (5VDC).

PoE connector (Indoor version)

Ensure that your LAN is already provided with a PoE Switch or connect a PoE switch to your LAN network.

1. Install the gateway on the wall using the screws for the holes in the lateral flanges (2x M3.5 screws, not included).
2. Connect the gateway to the PoE-enabled LAN with standard Ethernet cable.

PoE connector (Outdoor version)

Ensure that your LAN is already provided with a PoE Switch or connect a PoE switch to your LAN network.

1. Install the TinyGateway on a pole (mounting kit provided) or on the wall using the holes for M6 screws on the back panel.
2. Connect the gateway to the PoE-enabled LAN with standard Ethernet cable.

First start

1. Power-on the gateway.
2. Retrieve the IP address assigned to the gateway by the local DHCP server.
3. Access the Web interface at

URL: `http://<Gateway IP address>`

Password: blueup

4. Configure Ethernet connection with your desired values.

Gateway Configuration

1. Connect to the gateway IP address.
2. BLE version: configure the gateway as receiver (scanner), transmitter (beacon) or both.
Wirepas version: configure the gateway as Wirepas Sink.
3. Configure the network communication with your desired settings (MQTT, HTTP, TCP or UDP, depending on the version).

Safety

These information are an integral and essential part of the product and must be delivered to the user. Read them carefully as they contain important information regarding the installation, use and maintenance.

Warnings

TinyGateway PoE must be intended for use for which it was designed. Any other use is considered improper and therefore dangerous.

Before you start using TinyGateway PoE, verify that it is undamaged.

DO NOT use TinyGateway PoE in potentially explosive atmospheres. The presence of flammable gas or fumes is a serious safety hazard.

Make sure that TinyGateway PoE standard (indoor version) is always kept in a dry environment.

The company BlueUp S.r.l. disclaims any liability for damages caused by an inadequate use of the device and the failure to observe the information provided herein.

Waste disposal



In implementing the Directives 2011/65/EU and 2012/19/EC on the restriction of the use of hazardous substances in electrical and electronic equipment and the disposal of waste.

The crossed bin symbol on the appliance or its packaging indicates that at the end of the product's life, it must be collected separately from other waste. The user must, therefore, take the remote control to an authorized disposal center for collection of electronic and electrical waste, or return it to the dealer when purchasing a new similar appliance, on a one to one basis. Appropriate separate collection for the subsequent forwarding of the product sent for recycling, treatment and environmentally compatible disposal helps to prevent negative environmental and health effects and promotes the reuse and/or recycling of materials making up the equipment. Illegal dumping of the product by the user entails the application of administrative sanctions in the current provisions of law.

For more information about the collection systems, contact your local authorities.

In implementing Directive 2006/66/EC on the reduced use of hazardous substances in batteries and the disposal of the same.

The crossed bin symbol on the appliance or its packaging indicates that the batteries must not be disposed of with the rest of the household waste, as they may contain substances that are potentially harmful to the environment and health. Remove the old battery from the device and turn it in at the appropriate collection points.

Disclaimer

This manual is intended to provide a brief summary of our knowledge and some guidance regarding the use of the device and its accessories. The information contained herein has been provided by sources that BlueUp S.r.l. considers to be dependable and is accurate to the best knowledge of the company. This sheet is not intended to be an inclusive document on worldwide hazard communication regulations. The information is provided in good faith. Each user of this material needs to evaluate the conditions of use and define the appropriate protective mechanisms to prevent the exposure of persons, property damage or release to the environment.

BlueUp S.r.l. assumes no responsibility for injury to the recipient or third persons, or for any damages resulting from misuse of the device and its parts.

Warranty

For warranty conditions, refer to BlueUp “General Terms and Conditions of Sale” available at the following internet address: www.blueupbeacons.com

Conformity

US (FCC)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC ID: 2ALP7TNP01

EU (CE) / UK (UKCA)

Hereby, BlueUp S.r.l. declares that TinyGateway WiFi is in compliance with Directives 2014/53/UE (RED) , 2011/65/UE (RoHS 2) and 2015/863/UE (RoHS 3) .



Full User Manuals

The full text of the EU and UK declarations of conformity is available at the following internet address: www.blueupbeacons.com

TinyGateway PoE BLE TinyGateway PoE Wirepas

Contacts

BlueUp S.r.l.
Loc. Belvedere, Ingresso 2, 99
IT-53034 Colle di Val d'Elsa (SI) - ITALY
E-mail: info@blueupbeacons.com
Web: www.blueupbeacons.com



BlueUp reserves the right to make changes to the product at any time