



HOW TO CHARGE

1. Connect USB end of included cable to a computer or wall charger.
2. Connect Micro USB end of included cable to the charging port.

HOW TO CONNECT

1. Turn the El Hefe speaker on.
2. Open the bluetooth setting / pairing setting on phone or computer and select El Hefe.

CONTROL PANEL

A. long press: volume down/ short press: skip back

B. play/pause

C. long press: volume up/ short press: skip forward

D. bluetooth, tf, aux mode switch


E. microphone

F. tf card slot

G. 3.5 mm microphone

H. 5V charging port

I. power on/off



TF

INPUT

DC5V

OFF

ON

POWER

EL HEFE

WIRELESS SPEAKER

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.