





USER MANUAL

1.0 ABOUT THE RC CAR

The RC car adopts 2.4G technology to control functions such as forward, backward, left and right turning and multiplayer competition without interference. The design such as powerful motor and antiskid tyres makes stable driving of the car possible, bringing you an ultimate experience full of speed and thrill!




- ① ON/OFF Switch
② Battery Compartment
③ Battery Compartment Screw
④ Rechargeable Battery
⑤ Battery Connector
⑥ Direction Fine-tuning



- ① ON/OFF Switch
② Indicator Light
③ Forward/ Backward Trigger
④ Steering Wheel

2.0 ACCESSORIES



RC Car x1



Remote Controller x1



Rechargeable Battery x1



USB Charging Cable x1





User Manual x1

3.0 PREPARATIONS

3.1 Charge the Battery for RC Car

STEPS

- Unscrew the screws on the battery compartment in the car with a screwdriver, and then open the battery cover.
- Connect one end of the USB charging cable to the battery connector and ensure it is correctly connected. Then insert the other end of the USB charging cable into safe power supplies with USB socket, such as PC, laptop, mobile power, or USB power socket etc. The red light turns solid on during charging and goes out when charging completes. Full charging takes around 3 to 5 hours.
- After charging, connect the battery with the battery connector and ensure it is correctly connected.
- Insert the battery into the battery compartment, refit the battery cover, and finally tighten the screws with a screwdriver




NOTICE:

- Juveniles shall be accompanied and guided by their guardians to charge the product.
- It is recommended to fully charge the battery to ensure sufficient power before the first use. Please understand that the running time will be relatively shortened without prior charging for the first use due to insufficient power of the battery, which is caused by the auto discharge during transportation.
- Do not charge batteries that are inflated, leaked or damaged. Do not overcharge the battery.
- Please use the original USB charging cable from the factory. Do not use charging cables that are damaged or non-original ones.
- Keep it away from flammable materials and do not put it on the surface of conductive objects (such as carpet, wooden floor or furniture, etc.) during charging.
- Please be careful to avoid electric shock while using the electrical products.

6.0 TROUBLESHOOTING




Problems	Causes	Solutions
1. RC car/ remote control not responsive	1. Switch not turned on. 2. Batteries improperly installed. 3. Low battery voltage. 4. Out of control range. 5. RC car not paired with the remote controller.	1. Turn on the switch. 2. Ensure the positive and negative terminals are correctly aligned. 3. Replace the batteries of the remote controller/ Recharge the batteries for the RC car. 4. Control it with in 45 meters. 5. Power off the RC car and the remote controller and then turn on again and pair again.
Close control range:	1. Signal interference around. 2. Low battery voltage of RC car/ remote controller.	1. Try to drive in another place. 2. Replace the batteries of the remote controller/ Recharge the batteries for the RC car.
RC car fails to drive in a straight line.	1. Excessive surface friction or extremely smooth surface. 2. Fail to activate fine-tuning function.	1. Try to drive in another place. 2. Toggle fine-tuning switch to trim the directions.

- Keep the RC car in a cool place after usage and do not touch the motor until it cools down.
- Wipe out the sand, muds and dust on the RC car after usage.
- Take out the batteries from the car and the remote controller and keep them in separate places when the RC car is not in use.
- Anti-rust oil (not included) can be applied to protect the exterior metal against rust.







5.0 MAINTENANCE

- Turn Left: Rotate the steering wheel backward to let the RC car turn left.
- Turn Right: Rotate the steering wheel forward to let the RC car turn right.
7. Fine-tuning: If the RC car fails to drive in a straight line, toggle fine-tuning switch to trim the directions from side to side accordingly as to let the front wheel move forward horizontally.



- Power on: Turn on the switches of the RC car and the remote controller to power them on.
- Pairing: The indicator light of the remote controller blinks at the beginning and turns off after pairing has completed.
- Forward: Pull the trigger of the remote controller backward to let the RC car drive forward.
- Backward: Push the trigger of the remote controller forward to let the RC car drive backward.




STEPS

4.0 DRIVE VIA REMOTE CONTROL

- Do not use it in conditions like rains and snowstorms etc. to avoid accidents.
- Do not use it on public roads to avoid impacts on the traffic.
- Do not use it near crowded places, people or animals to avoid environmental damage or body injury.
- Do not use it in the rain or let the car run over the puddle to avoid malfunction.
- Do not use it near rivers, ponds or lakes to prevent the car from falling into the water.

NOTICE:



3 Drive in Suitable Environment

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

Unsuitable Driving Environment

Asphalt Pavement/Hardwood

Gravel/Snowfield/Desert

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

SL-212A

- Please ensure the "1.5V", "+" and "-" electrodes have been correctly aligned.
- Do not mix old and new batteries.
- Do not mix different types of batteries.

NOTICE:

USE 2X1.5V "AA" BATTERIES (NOT INCLUDED)

