

COMPAQ

CT101



User Manual



Safety precautions

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Warning: Changes or modifications not expressly approved by the party responsible for compliance (MLB International Inc., PO Box 1214, Lockport, NY, 14095, Tel: 716-240-0902) could void the user's authority to operate the equipment.

CAN ICES-3(B) / NMB-3(B)

This device complies with Industry Canada License-exempt RSS Standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0cm between the radiator and your body.

Caution: Exposure to Radio Frequency Radiation.

To comply with the Canadian RF exposure compliance requirements, this device and its antenna must not be co-located or operated in conjunction with any other antenna or transmitter.

To comply with RSS 102 RF exposure compliance requirements, a separation distance of at least 0cm must be maintained between the antenna of this device and all persons.

Operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

For the frequency 5600-5650 MHz, no operation is permitted.

Warnings

- The battery cannot be subjected to during use, storage or transportation at high or low extreme temperatures and low air pressure at high altitude.
- Replacement of the battery with an incorrect type can defeat a safeguard.
- Disposal of the battery into fire or a hot oven, or mechanically crushing or cutting of the battery can result in an explosion.
- Leaving the battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas.
- Battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.

 **Caution:** Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.

 **Warning:** the AC adapter is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the mains plug from mains completely, the AC adapter should be disconnected from the mains socket outlet completely.

The socket-outlet shall be installed near the equipment and shall be easily accessible.

 Only use with the AC/DC adapter complied with UL62368-1 LPS (15VA less) PS1 type or IEC60950-1 LPS 15VA type.

Service Information

This product should be serviced only by those specially trained in appropriate servicing techniques.

Important safety instructions

PLEASE READ AND SAVE THIS FOR FUTURE REFERENCE

Some of the following information may not apply to your particular product; however, as with any electronic product, precautions should be observed during handling and use.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments / accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

ADDITIONAL SAFETY INFORMATION

- The AC adapter and apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Always leave sufficient space around the product for ventilation. Do not place product in or on a bed, rug, in a bookcase or cabinet that may prevent air flow through vent openings.
- Do not place lighted candles, cigarettes, cigars, etc. on the product.
- Care should be taken so that objects do not fall into the product.
- Do not attempt to disassemble the cabinet. This product does not contain customer serviceable components.
- To prevent the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- Do not play your headset at high volume. Hearing experts warn against extended high-volume play.

Accessories


The following accessories are included.

AC Adapter	x1
Keyboard	x1

Contents

Safety precautions	1	Basic operation	22
Important safety instructions	4	Using the Touchscreen	22
Getting to know your tablet	7	Google Now™	22
Left side view	8	Voice Search & Voice Actions	22
Buttons	9	Google Play™	23
Tablet docking/undocking	10	Google™	24
Getting started	11	Settings	24
Charging the battery	11	Preinstalled apps	26
Turn your tablet ON	13	Additional information	27
Navigating the Home Screen	15	Troubleshooting	27
Connections and setup	18	Copyright and Trademark Notices	28
Headphones	18	Specifications	28
USB	18		
MicroSD	19		
HDMI	19		
Connect to a Wi-Fi network	20		
Bluetooth	21		

Getting to know your tablet




1 Front camera

2 Trackpad

3 Rear camera

Left side view



- | | |
|---|---|
| 1 USB port
Connects to a USB storage device or a mouse or a wire keyboard. | 6 Mini HDMI port
Connects to a TV or a display device. |
| 2 Headphones jack
Headphones connection for personal listening. | 7 MicroSD card slot
Accepts microSD card (up to 128GB). |
| 3 Micro-USB port (not for charging)
Connect to a PC or USB storage device. | 8 POWER button
Press to enter standby/wake up mode, press and hold to switch On/Off the unit. |
| 4 Charging indicator
Orange: Charging
Green: Fully charged
Red (blinking): Low battery | 9 Reset
Reset the tablet (then press and hold the POWER button for 4~5 seconds to turn on the unit). |
| 5 DC jack
Connects with 5V DC charger. | 10 Volume +/- button
Press to increase/decrease the volume. |
| | 11 Microphone
For voice input. |

Buttons

POWER button

Power the tablet On

Press and hold the **POWER** button for 4~5 seconds to turn on the tablet.

Power the tablet Off

Press and hold the **POWER** button until the "  **Power off**" message displays, then tap it and the tablet will be powered off.

Sleep mode

Briefly press the **POWER** button to put the tablet in sleep mode. If you don't operate for some time, the tablet will enter sleep mode automatically.

Tip: You can go to  **Settings** -> **Display** -> **Sleep** to set the screen timeout.

Wake the tablet from Sleep mode


Press the **POWER** button to wake the tablet from sleep mode.

Volume +/- buttons

Press the **Volume +/-** buttons to increase or decrease the volume.

Tip: You can go to  **Settings** -> **Sound** to adjust volume settings.

Tablet docking / undocking




NOTE

The keyboard connects to the tablet via the Connector. When the connection is successful, the tablet will automatically adjust its settings to use the keyboard.

Getting started

Charging the battery

Use **ONLY** the included AC Adapter to charge the battery.



Charging time will vary depending on remaining battery life. Charging from 0%, should take approximately 4-5 hours. Use **ONLY** the included AC adapter with the small round port. You may not be able to turn on your tablet for at least 20 minutes if the battery was fully drained.

Battery icon

The battery icon in the upper-right corner shows the battery level or charging status.



Full
battery



Low
battery



Need to
be charged



Charging

IMPORTANT! Please Read.



We recommend fully charging your tablet before using it for the first time. For optimum performance, please connect the provided AC adapter to your tablet when it falls below 20% charge.



NOTE

In order to keep the battery working in best condition, please pay attention to the following:

- The included AC adapter is for use with this unit only. Do not use it with other equipment.
- Please do not charge the battery in high temperatures.
- Do not wait for the battery to be fully depleted before charging again. Keep the battery charged as needed.
- If tablet has not been used for a long period of time, the battery might be in over discharge protection mode and may take longer to charge.

Prolong the Battery Life

Here are some tips for how to prolong the life of the battery:

- If you aren't using Wi-Fi, go to  **Settings** -> **Network & Internet** -> **Wi-Fi**, turn it off.
- Don't leave the Maps or Navigation apps open on the screen when you're not using them.
- Turn down screen brightness and set a shorter screen timeout:  **Settings** -> **Display**.

- If you don't need it, turn off automatic syncing for all apps:  **Settings** -> **Users & accounts** -> **Automatically sync data**. This means you need to sync manually to collect messages, email, and other recent information, and won't receive notifications when updates occur.

Turning your tablet ON

Press and hold the **POWER** button 4~5 seconds until the **COMPAQ** logo appears.




Starting for the first time

When using the tablet for the first time, you will be required to setup the following:

1. Select the language, then tap **START**.
2. Set the Wi-Fi.

3. Then tap a network name to see more details or connect to it, and enter a password if necessary. When prompted, sign in using the email address and password for your Google Account. If you don't have one yet, go ahead and create one.
4. Follow the onscreen instructions to setup the tablet.




Jumping Icons
and UP arrow

5. The Jumping Icons will remind you to pull up the ALL APPs menu.
6. Tap the UP arrow or swipe up from the bottom of the screen to enter the ALL APPs menu.

In All Apps screen, you can:

- Move between screens: Slide up or down.
- Open an App: Tap its icon.
- Copy an App icon to the Home screen: Press and hold the icon or widget icon slowly to drag it to the Home screen.
- Get more apps: Tap the Google Play Store icon .
- View info about an App: Press and hold an App to display the App Info menu, then tap the App Info icon .

Navigating the Home Screen



Notification & Status Bar

Some indicators that inform you about the status of your tablet are shown at the top of the screen.

Notification Shade

Notifications may come from the system, a game, an application such as E-mail, or the music player. When Notifications are available, related icons will appear in the top left corner of the screen. To open the Notification Shade, touch the Notification icon and swipe your finger down. Some notifications allow you to take specific actions by tapping icons within the notification.

After you are finished with a notification, just slide it away to the left or right. If you want to dismiss all notifications, tap "Clear All".

Status Bar & Quick Settings

The Status Bar in the top right corner shows various indicators, including Wi-Fi connection and battery status. To access "Quick Settings", touch the status bar and swipe down. You can then adjust various settings on the tablet by touching the corresponding square.

Notification & Status Icons

The below table lists some of the frequently used icons in the Notification & Status bar:

Item	Description
 Message	Received new message.
 Music	The Google Play Music app is running.
 Wi-Fi	Has a Wi-Fi Internet connection.
 Bluetooth	Bluetooth is on.
 Play Store	An update for an app is available.

Home Screen Icons

Back 

Tap Back icon  to return to the previous screen.

- The Back icon remains on the bottom of the screen at all times, allowing you to navigate back to the previous screen.

- Once you go back to the Home screen, you can't go back any further in your history.

Home

Tap Home icon  from anywhere on your tablet to return to the Home screen.

Recent Apps

Tap Recent Apps icon  to view recently used apps. Tap an app to use it again. You can slide down to see more apps. You can also slide it away to the left or right.


Customizing the Home Screen

- From All Apps screen to Home screen: Swipe up from bottom of the Home screen to enter All Apps screen, press & hold an icon slowly to drag it to the location of your choice. This makes it much easier to change your Home screen layout.
- View widgets: Press & hold the screen on your Home screen, the widgets icon will display, and then tap it. Widgets are app information displays that can be placed on your Home screen.
- Move apps or widgets: Press & hold an icon or widget, slowly to drag it to the screen edge, the screen will switch.
- Delete apps or widgets: Press & hold an icon or widget, when the "X" icon appears at the top of the screen, drag the icon or widget into it.
- Press & hold the screen on your Home screen, and the wallpaper icon will display, tap it and choose a wallpaper.

Connections and setup

Headphones

Headphones can be connected to the tablet's headphones jack.



USB

The tablet can be connected to a USB storage device to transfer music, pictures and other files in both directions.




NOTE

To enter the USB storage device, please go to



Settings -> Storage, and tap .

MicroSD



Insert the microSD card into the tablet's microSD slot until it clicks.

To check the storage of the microSD card, go to  **Settings** -> **Storage**.

Remove the microSD card by pushing in on the card's edge. The card will pop out and can be removed.




NOTE

- You can use microSD™ card and microSDHC™ card (up to 128GB, SD card not included).
- Never remove or insert micro SD card in On mode.


HDMI

You can connect the unit to a TV or other display device using an HDMI cable through the HDMI port.



1. Go to  **Settings** -> **Display** -> **HDMI settings**, to turn on the HDMI.
2. The system interface on the unit is automatically synchronized with your TV screen.

Connect to a Wi-Fi network



1. Go to  **Settings** -> **Network & Internet**, tap **Wi-Fi** to open the Wi-Fi screen and then tap **Off** to turn it on.
2. The device will scan Wi-Fi networks automatically and display the available names.
 - **If the device finds a network that you connected to previously, it will connect to it automatically.**
3. Tap a network name to connect to it, and enter a password if necessary.

4. Alternatively, if your Wi-Fi router supports Wi-Fi Protected Setup, you can go to the Advanced Wi-Fi screen (tap **Wi-Fi preferences** and select **Advanced**) and select **WPS Push Button**, then press the WPS button on your router.
5. If your network does not broadcast its SSID, tap **+ Add network** and enter the Network SSID (name) of the network. If necessary, enter security or other network configuration details.



NOTE

You can tap the icon  at the upper-right corner in the **Settings** screen for advanced settings.


VPN (Virtual Private Network)

You can create a virtual private network (VPN) and connect to your private network securely through a public network, such as the internet. You must set a lock screen PIN or password before you can use credential storage.

Add VPN network and follow the instructions on the screen.

Bluetooth

You can use Bluetooth to communicate between the unit and other Bluetooth devices, such as a smartphone.



1. Go to  **Settings** -> **Connected devices**, tap **Bluetooth** to open the Bluetooth screen and then tap **Off** to turn it on.
2. It will scan automatically and display the available bluetooth devices.

3. Tap an available bluetooth device name to pair with it and follow the instructions to complete the pairing.

Receive Files

When the Bluetooth share icon  is shown in the Notification bar, touch and drag it to open the Notification Shade. Tap the notification and follow the instructions to complete the receiving.

Send Files

1. Go to **All Apps** -> **Files**.
2. Select a file you want to send, touch & hold it until the Notification bar appears. Touch icon  and select **Bluetooth**, then follow the instructions to complete the sending.

Basic operation

Using the Touchscreen

Here are some basic procedures for interacting with the touchscreen.




Tap

To select an item on the touchscreen, lightly tap it.




Press & Hold

In some instances, touching the item and holding your finger on it will present other options or menus.



Drag or Swipe

While holding an item such as an icon, it can sometimes be moved by dragging it to another area or screen. You may also be able to swipe your finger across a screen or item to navigate or move it.



Zoom

By placing two fingers on the screen, you can slide them apart to "Zoom In", or pinch them together to "Zoom Out".

Google Now

To create a truly personalized experience, using your location and personal Google account information, use Google Now. Touch and Hold the Home icon, and slide up to the Google Now icon. Follow the instructions to setup your Google Now experience.

Voice Search & Voice Actions

Turn Voice Search or Voice Action On

You can initiate a Voice Search or Voice Action by tapping the Microphone icon on top of the Home screen.

When you're viewing the Google Now screen, you don't have to touch anything. Just say "Google."



NOTE

To detect when you say "Google" to launch Voice Search or Voice Actions, your tablet analyzes sound picked up by your tablet's microphone in intervals of a few seconds or less.

Using Voice Search

After tapping the microphone icon, just say whatever it is you want Google to search for.

Using Voice Actions

There are many actions that the tablet can perform using "Voice Actions". For example, you can send emails, set alarms, play a song, or navigate to a website. Just tap the Microphone icon, and say what you want the tablet to do. As you speak, Voice Search analyzes your speech and initiates the action.

If Voice Search doesn't understand you, it lists a set of possible meanings. Just tap the one you want.

Google Play

In addition to the apps that come preinstalled on your tablet, you can download Android apps and games, music, movies, TV shows and magazines using the Google Play Store app.

1. On the App menu, touch the Google Play Store icon.
2. To search for an item from the Google Play Store app, touch the search icon in the upper right corner, and then type a keyword to search.
3. Touch an available item to go to its details page. From there you can install or download the item.

Google

A Google Account lets you organize and access your personal information from any computer or mobile device.

Add an Account

You can use multiple Google Accounts and Microsoft Exchange ActiveSync accounts on your tablet.

You may also be able to add other kinds of accounts, depending on your apps. To add some accounts, you may need to obtain details from your system administrator about the service to which the account connects. For example, you may need to know the account's domain or server address.

1. Go to  **Settings** -> **Users & Accounts** -> **Add account**.
2. Tap the kind of account to add. And then follow the on-screen instructions.

Remove an Account

To remove a Google account, go to  **Settings** -> **Users & Accounts** -> **Google [account-name]**, then tap **REMOVE ACCOUNT**.

Settings

Settings let you configure the tablet, set app options, add accounts, and change other preferences.

Networks & Internet

Wi-Fi — Enable or disable **Wi-Fi**, and connect to a wireless network so that you can check email, search the Web, or access social media websites.

Ethernet — Enable or disable **Ethernet**.

Airplane mode — Enable or disable **Airplane mode**.

VPN — You can add, set up, and manage virtual private networks (VPNs).

Connected devices

Bluetooth — Enable or disable **Bluetooth**.

Cast — Set preferences for **Cast**.

Printing — Enable or disable **PRINT SERVICES**.

USB — Set preferences for connected USB device.

Apps & notifications

View the Recently opened apps and all apps, and set preferences for apps.

To view information or uninstall an app, tap the relevant app.

Battery

View battery status.

Display

MiraVision™ — Display picture quality optimization.

Brightness level — Allows you to adjust the screen brightness.

Wallpaper — To choose wallpaper.

Sleep — Allows you to set the amount of time before the screen times out.

Advance — Allows you to set Auto-rotate screen, Font size, Display size, Screen saver and HDMI settings.

Sound

Allows you to set the **Media volume**, **Alarm volume**, **Notification volume** and others.

Storage

View the total storage space and free space in the device's internal storage. View a list of apps in use and the storage capacity for photo & video, music & audio, games, files, apps and system.

DuraSpeed

Switch on to allow APPs running in background.

Security & location

Use the Security & location menu to configure how to help secure your device and its data.

Users & accounts

Users — This menu displays the current users you've created.

Add account — You can add an email account or another type of account.

Automatically sync data — Let apps refresh data automatically.

Google

Use this menu to manage your Google apps and account settings.

System

Language & input — Set preferences for **Language**, **Keyboard & input**, and **Input assistance**.

Date & time — Use to set how date, time, time zone and time format will be displayed.

If the tablet connected with a Wi-Fi, you can also select use network-provided time or GPS-provided time.

Set **Automatic date & time** to **Off** and then you can also set your own data and time rather than obtaining the current time from the network or GPS.

Reset options — Use to reset app preferences.

About tablet

Check System updates, Status, Legal information, etc.

Preinstalled apps

Your tablet comes with many apps preinstalled to allow you to browse the web, send and receive email, and access entertainment. Spend some time exploring these apps to learn how your tablet can be most useful for you.

Additional information

Troubleshooting

Tablet displays network or service error message

- When you are located in places with poor signal, your tablet may lose its Wi-Fi connection. Try moving closer to the Wi-Fi router.

Touch screen response is slow or incorrect

If the tablet's touch screen response is incorrect, please try the following:

- Remove any protective film on the touch screen. The protective film may prevent the device recognition input.
- Make sure that your fingers dry and clean before you tap the touch screen.
- Restart the tablet to clear any temporary software bugs.

Tablet is frozen or a serious error appears

- If the tablet is frozen or suspended, you may need to close the app program or reset the tablet.
- If the tablet is frozen or slow to respond, press and hold the power button for 8 seconds to reset the tablet.

- If that doesn't work, insert a paper clip into the RESET hole on the tablet, then press and hold the **POWER** button for 4~5 seconds to turn on the unit.

Tablet gets warm

- When using for a long time, the tablet may be warm. This is normal and will not affect the life or performance of the unit.

Tablet can not show video of opposite side during skype call

- The Wi-Fi signal is poor. Please move closer to your wireless router, or disconnect other devices from your wireless router, or increase bandwidth of internet connection.
- Please check the Wi-Fi setting. It's recommended to use an IEEE 802.11 b/g/n. certified Wi-Fi network.

Insufficient storage

- We recommend to reserve at least 700MB of free space in internal storage for APP download.

Copyright and Trademark Notices

Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC.

The Wi-Fi CERTIFIED Logo is a certification mark of the Wi-Fi Alliance.

The Wi-Fi Protected Setup Mark is a mark of the Wi-Fi Alliance

The *Bluetooth*® word mark and logos are registered trademarks owned by the *Bluetooth* SIG Inc. Other trademarks and trade names are those of their respective owners.



HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks, registered trademarks, or service marks of HDMI Licensing, LLC in the United States and/or other countries.

About HDMI

High-Definition Multimedia Interface (HDMI) is a high-speed digital interface that can transmit uncompressed high definition video and digital multichannel audio. It delivers high quality picture and sound quality. HDMI is fully backward compatible with DVI. As required by the HDMI standard, connecting to HDMI or DVI products without HDCP (High bandwidth Digital Content Protection) will result in no Video or Audio output.

Specifications

Power: DC IN 5V (operate with AC adapter)

Specifications and external appearance are subject to change without notice.