



BIB TRACK SYSTEM

User Manual for Operating the HandHeld Unit

Radio Frequency Interference Requirements

This device must operate in compliance with Federal Communications Commission (FCC) Rules and Regulations Part 15.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and**
- (2) this device must accept any interference received, including interference that may cause undesired operation.**

FCC ID A92-76519

This device does not contain any parts, which need service by the user. Any change or modification not expressly approved by the party responsible for compliance can void FCC certification and user's authority to operate the equipment.

Do not open or modify.

**P/N 76519
MX MSPN 73214**

Guidelines for Handheld Operation:

- ◆ Keep handheld in cradle when not in use for extended periods of time so that battery can be recharged. Handheld is fully charged when the green light on the cradle is not flashing.
- ◆ Operating Temperature: 32° to 104°F/0° to 40°C
- ◆ Storage Temperature: -4° to 140°F/-20°to 60°C

Downloading Data to E.S.P. Unit

You are required to download data from your *BIB TRACK* computer to your E.S.P. Unit at the start of every workday to assure that the data you use is up-to-date.

This downloaded data includes current information about users, terminals, vendors, tire types, tire positions and vehicles. The data also includes updated codes:

- Condition Codes used when inspecting tires
- Damage or Failure Codes used when dismounting tires
- Repair Codes used when receiving a tire from repair
- Retread Reason Codes used when sending a tire to retread
- Retread Design Codes used when receiving a retreaded tire
- RAR (Returned as Received) Codes used when receiving un-repaired or un-retreaded tires
- Scrap Reason Codes used when disposing of a tire

To download data to the E.S.P. Unit, you need the *Communicator* program, the E.S.P. Unit, and the E.S.P. Unit Cradle.

1. Call up the *Communicator* opening screen on your *BIB TRACK* computer.



Communicator Opening Screen

2. Click the *Communicator* arrow that designates *Send Data to E.S.P.* The *Log-In* box will appear.



Log-In Box

3. Key in your *User ID* and *Password*.

4. Click the *OK* button.
NOTE: The *Communicator* will use on-screen messages to guide you through the download process and to notify you if data transfer was successful.
5. Place the E.S.P. Unit in its cradle, which is connected to the *BIB TRACK* computer.
6. Press the E.S.P. Unit's *On/Off* key to power up the unit.
7. If you see a menu other than the *Main Menu* on the E.S.P. Unit's screen, press the *CLR* (Clear) key until you see the *Main Menu*.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor


Main Menu

8. Use the *Up* and *Down* arrows on the E.S.P. Unit's keypad to highlight item 2: *Send/Rec Data*.
9. Press the *Enter* key to start the transfer of data. The program will notify you if data transfer was successful.

Checking Who Downloaded Data


If you need to check who downloaded data to the E.S.P. Unit, do the following:

1. On the *Main Menu*, use the arrow keys to highlight *Version*.



Main Menu

2. Press *Enter* to call up the *Version* screen.



Version Screen

3. Locate the lines that read, "Data downloaded by..." and read the name.

Uploading Data from E.S.P. Unit

Use this procedure to transfer data collected by the E.S.P. Unit to your *BIB TRACK* computer and then to the Michelin servers.

NOTE: You should perform this procedure as often as possible so that Pressure Warnings data is kept current. It is recommended that you perform these steps after every vehicle inspection.

1. At the *BIB TRACK* computer, click the *Communicator* icon to start the program.
2. Place the E.S.P. Unit in its Cradle, which is connected to the *BIB TRACK* computer.
3. Press the E.S.P. Unit's *On/Off* key to power up the unit.
4. If you see a menu other than the *Main Menu* on the E.S.P. Unit's screen, press the *CLR* (Clear) key until you see the *Main Menu*.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

5. Use the *Up* and *Down* arrows on the E.S.P. Unit's keypad to highlight item 2: *Send/Receive Data*.
6. Press *Enter*.
7. Turn to the *Communicator* program on your computer.
8. Click the icon that designates *Send Data to BIB TRACK*.
9. The *Communicator* will use on-screen messages to notify you if the data transfer was successful.

MAKING INITIAL E.S.P. UNIT READINGS

When you finish the sections listed below, you will have completed setup. You should go through these sections in the order listed.

- Matching Vehicle IDs with Sensor IDs
- Inspecting and Mounting Tires
- Adding New Tires
- Uploading Data from E.S.P. Unit

Press the *On/Off* key on the E.S.P. Unit keypad to power up the E.S.P. Unit. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears. Most E.S.P. Unit functions start at the *Main Menu*.

Matching Fleet Vehicle IDs and Sensor IDs with E.S.P. Unit

Use this procedure to match the Fleet Vehicle ID painted on the side of a vehicle with the electronic sensor ID of the sensor mounted on the vehicle. You must match these two IDs before you can inspect tires.

1. Call up the *Main Menu*.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the keypad *Up* and *Down* arrows to highlight the *Action Menu* option.
3. Press the *Enter* key.

SELECTED FLEET
Current Fleet:
Fleet 1
Current Terminal
Terminal 1

Selected Fleet Screen

4. Watch closely and check the *Selected Fleet* screen to verify that the E.S.P. Unit is set to the correct fleet and terminal. If the E.S.P. Unit is not, use the procedure "Changing Fleet on E.S.P. Unit".

After briefly appearing, the *Selected Fleet* screen disappears and the *Action Menu* appears.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

5. Use the *Up* and *Down* arrows to highlight *Match Vehicle*.

5. Press *Enter* to call up the *Match Vehicle* screen.

MATCH VEHICLE
SCAN VEH:
Press Any Key to
Scan

Match Vehicle Screen

6. Aim the E.S.P. Unit's scanning wand at the sensor mounted on the vehicle and press any key.

MATCH VEHICLE

Fleet Vehicle ID:

Fleet Vehicle ID

7. When the Match Vehicle screen appears, use the E.S.P. Unit keypad to key in the Fleet Vehicle's ID number that is painted on the vehicle.
8. Press the *Enter* key. You have matched the electronic Sensor ID and the painted Fleet Vehicle ID.

Inspecting and Mounting Tires with E.S.P. Unit

Use this procedure to inspect and/or mount tires on vehicles whose Fleet Vehicle ID and Vehicle Sensor ID have been matched.

1. Access the E.S.P. Unit's *Main Menu*. If needed, press the *CLR* key until it appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the arrow keys to select the *Action Menu* and press *Enter*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

3. On the *Action Menu*, use the arrow keys to highlight *Inspect & Mount* then press *Enter* to call up the *Tire Inspect/Mount* screen.

TIRE INSPECT/MOUNT
SCAN VEH:
Press Any Key to Scan

Tire Inspect/Mount Screen

4. Place the E.S.P. Unit scanning wand near the Vehicle ID Sensor and press any key.

5. When the unit has finished scanning, a vehicle type screen appears.

TIRE INSPECT/MOUNT VEHICLE TYPES
0: POWERED - 6X4, DUA
1: POWERED - 6X2, DUA
14 POWERED - 6X4, DU AL TIRES

Select Vehicle Type Screen

6. Use the arrow keys to highlight the correct vehicle type. You will see a more complete description of the vehicle type at the bottom of the screen.
7. Press *Enter* key. A vehicle mileage screen appears.

TIRE INSPECT/MOUNT VEH MILEAGE: _____

Enter Vehicle Mileage


8. Key in the *Vehicle Mileage*. (The mileage entry will not be recorded in *BIB TRACK*, if the fleet only allows its designated personnel to track mileage.)
9. Press *Enter*. A *Scan Tire* screen will appear.

TIRE INSPECTION SCAN TIRE: Press Any Key to Scan

Scan Tire Screen

10. Place the E.S.P. Unit scanning rod near one of the vehicle's tires and press any key.


11. Check that the *Tire Sensor ID* and the tire's *Pressure* appear on the screen.



Tire Sensor ID and Pressure

NOTE: The E.S.P. Unit displays cold equivalent pressure. This is actual tire pressure, which has been adjusted for tire temperature. This system is much more accurate than conventional pressure readings taken on hot tires.

12. Press any key to call up the *Vehicle Diagram* screen.



Vehicle Diagram

13. Use the arrow keys to highlight a tire.
14. Press *Enter* to call up the *Tread Depth* screen.



Tread Depth Screen

15. Key in the tread depth in 1/32 of an inch then press *Enter* to call up the *Tire Condition* screen.

TIRE INSPECTION
Tread Depth: 17
Tire Condition OK?
(Y/N)
Y = Tire is OK
N = Enter Condition
Code

Tire Condition Screen

16. Visually inspect the tire:
 - Press *Y* if the tire condition is acceptable. The *Tire Comments* screen will appear. See the procedure later in this section *Entering Inspection Comments*.
 - Press *N* if the tire condition is unacceptable and you need to enter a *Condition Code*. See the next procedure, *Entering a Condition Code*, for details.

Entering a Condition Code

1. To enter a *Condition Code* for an unacceptable tire, press *N* on the *Tire Condition* screen.

TIRE INSPECTION
Tread Depth: 17
Tire Condition OK?
(Y/N)
Y = Tire is OK
N = Enter Condition
Code

Tire Condition Screen

2. When the *Condition Code Search* screen appears:
 - Press *Y* to search by code.
 - Press *N* to search by description.

CONDITION CODE
Search by code? Y/N
Y = by code
N = by description

Condition Code Search Screen

Searching by Condition Code

1. Press Y to search by *Condition Code*. The *Search by Code* screen will appear.

CONDITION CODE Enter Code: _____
--

Search by Code Screen

2. On the *Search by Code* screen, you can choose to:
 - Key in an exact code.
 - Select a code from a multiple listing.

Keying in an exact code

A list of sample Condition Codes follows for your reference.

Sample Condition Code Listing

Condition Code	Description
001	Fast Wear
002	Traction Wear
003	Noise Complaint
008	Shoulder Scrubbing/Scuffing
173	Excessive Wear
176	Brake Skid Damage
181	One Sided Wear
182	Heel/Toe Wear
183	Shoulder Wear - Both Shoulders
184	Cuppins/Scallop Wear
185	Eccentric/Out-Of-Round Wear
186	Center Rib, Lug Wear
187	Shoulder Step/Chamfer
188	Erosion/River/Channel Wear
189	Rib Depression/Punch Wear
190	Diagonal Wear
191	Feather Wear
195	Multiple Flat Spotting Wear
196	Alternate Lug, Erratic Depression Wear
199	Erratic Depression Wear
681	Pulling Left or Right Complaint
682	Vibration Complaint
683	Balance Complaint
698	Ride/Handling Complaint

1. Key in the three-digit code for the condition of the tire.

CONDITION CODE Enter Code: 001

Exact Code Keyed In

2. Press *Enter*.

CONDITION CODE
0: Fast Wear
001 Fast Wear

Code Description

3. Check that the screen displays the correct description near the top of the screen. At the bottom of the screen you should see the full code and description.
4. Press *Enter* to call up the *Tire Comments* screen. See the procedure *Entering Inspection Comments*.

TIRE INSPECTION Comments:

Comments Screen

5. Press *Enter* to save comments. A screen will indicate that data has been saved.

TIRE INSPECTION DATA SAVED ANOTHER TIRE? (Y/N)

Another Tire?

Selecting from multiple listing

1. Press Y on the *Condition Code Search* screen.

CONDITION CODE
Search by code? Y/N
Y = by code
N = by description

Condition Code Search Screen

2. Key in the first and/or second number of the code on the *Search by Code* screen.

CONDITION CODE
Enter Code:
1

Entering First Digits of Code

3. Press *Enter*.
4. All codes beginning with that number(s) will be listed. For example, if you key in 6, you will see the listings Pulling Left or Right Complaint (681), Vibration Complaint (682), Balance Complaint (683), and Ride/Handling Complaint. (698). If you key in 1, you will see the screen shown below.

CONDITION CODE
0: Excessive Wear
1: Brake Skid Damage
2: One Sided Wear
3: Heel/Toe Wear
4: Shoulder Wear - Both
5: Cuppins/Scallop Wear
6: Eccentric/Out-Of-Round
7: Center Rib, Lug Wear
8: Shoulder Step/Chamfer
9: Erosion/River/Channel
183 Shoulder Wear - Both Shoulders

Code Search Results Screen

4. Use the arrow keys to highlight the listing that you want.
5. Note that when you highlight a listing, its *Condition Code* and full description appear highlighted at the bottom of the screen.
6. Press *Enter* to call up the *Tire Inspection Comments Screen*. See the procedure *Entering Inspection Comments*.

Searching by Description

1. Press *N* on the *Condition Code Search* screen.

CONDITION CODE Search by code? Y/N Y = by code N = by description
--

Condition Code Search Screen

2. Check that the *Search by Description* screen appears.

CONDITION CODE Enter Description: _____

Search by Description Screen

3. Key in the first or first few words of the description and press *Enter*.

CONDITION CODE Enter Description: FAST _____

Description Entered

4. Check that the screen reloads with a listing.

CONDITION CODE
0: Fast Wear
001 Fast Wear

Condition Code and Description

5. If more than one listing appears, use the arrow keys to highlight the listing that you want. Note that when you highlight a listing, its *Condition Code* and full description appear highlighted at the bottom of the screen.
6. Press *Enter* to call up the *Tire Inspection Comments Screen*.

Entering Inspection Comments

1. After you have entered a *Condition Code* and pressed *Enter*, you will see a *Comments* screen.

TIRE INSPECTION Comments: _____ _____
--

Tire Inspection Comments Screen

2. Enter your comments on the first line.
3. Press *Enter* once each time you need an additional line to continue your comments.
4. When finished, press *Enter* until you see the *Data Saved* screen.

TIRE INSPECTION DATA SAVED. ANOTHER TIRE? (Y/N)
--

Data Saved Screen

5. Choose one of the following:
 - *Y* to return to the *Scan Tire* screen and continue scanning tires on the vehicle.
 - *N* to return to the *Action Menu* and select another function.

Inspecting Additional Vehicles and Tires

Because most fleets use the same vehicle types, the E.S.P. Unit provides a short cut. After you scan a tire, on the next vehicle, you will see the following screen.

TIRE INSPECT/MOUNT LAST VEHICLE: POWERED - 6X4, DUAL USE VEHICLE? (Y/N)
--

The E.S.P. Unit remembers the last vehicle type entered and asks if you wish to reuse the vehicle type. If you do, press *Y* or *Enter*. If not, press *N* and a vehicle type selection screen will appear.

Adding New Tires with E.S.P. Unit

You use this function to add tires with sensors to the BIB TRACK database.

1. Turn on the E.S.P. Unit with its *On/Off* key. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the keypad *Up* and *Down* arrows to highlight the *Action Menu* option.
3. Press the *Enter* key to call up the *Action Menu*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

4. Use the *Up* and *Down* arrows to highlight *Add New Tires*.
5. Press *Enter* to call up the *Tire Info* screen.

TIRE INFO
BOL# _____

Tire Info Screen

6. Key in the *BOL#* (Bill of Lading Number) and press *Enter*. The screen will ask for an *Invoice #*.

TIRE INFO	
BOL#	
12345	_____
INVOICE#	_____

BOL and Invoice

7. Key in your *Invoice Number* and press *Enter*. The screen will ask you to select a vendor.

TIRE INFO	
BOL#	
12345	_____
INVOICE#	
54321	_____
PURCHASE VENDOR:	
0: Vendor 1	
1: Vendor 2	
2: Vendor 3	

Select Vendor

8. Use the arrow keys to highlight the tire vendor and press *Enter*.

Tires Are Not Retreaded

1. Note that the screen asks if the tire is retreaded.

TIRE INFO Are tires retreaded? (Y/N)

Tires Retreaded?

2. Press *N* meaning the tire is not retreaded.

TIRE TYPE 0: MI, XPSRIB, 7.50R16, 1: MI, XZA2, 11R24.5, G 2: MI, XZE, 11R24.5, G 10818 MI, XPSRIB, 7.50R16, D
--

Select Tire Types Screen

NOTE: Pressing the *CLR* key at this screen will bring up the full list of tire types.

3. Use the *Up* and *Down* arrows to highlight the tire's type. When you highlight the abbreviated Tire Type description from the selection list, a full description appears at the bottom of the screen.
4. Press *Enter* to select the *Tire Type*. The screen will reload, note the original tire type, and ask for a quantity.

TIRE TYPE 0: MI, XPSRIB, 7.50R16, Original Thread: 0: MI, XPSRIB, 7.50R16, QTY: __

Enter Tire Quantity

5. Key in the *Quantity* and press *Enter*. The screen reloads and asks for a tire *Unit Price*.

TIRE TYPE
0: MI, XPSRIB, 7.50R16,
Original Thread:
0: MI, XPSRIB, 7.50R16,
QTY: 2
Unit PRICE: ____ . ____

Enter Unit Price

6. Key in the unit price (price of one tire). Note that the cents decimal point is fixed on the screen.
7. Press *Enter*. You will be asked to scan each tire that you have entered.

TIRE INFO
MI, XPSRIB, 7.50R16,
QTY SCANNED: 0
SCAN TIRE:
Press Any Key To Scan

Scan Tire Screen

8. Use the E.S.P. Unit to scan the first tire's sensor.

TIRE INFO
MI, XPSRIB, 7.50R16,
QTY SCANNED: 1
SCAN TIRE:
00000001A3
OTHER TIRE ID:

Tire Scanned Screen

9. Key in an *Other Tire ID*. This is an optional number that is used for in-house identification.

10. Press *Enter*.

TIRE INFO
MI, XPSRIB, 7.50R16,

QTY SCANNED: 1

SCAN TIRE:

Press Any Key To Scan

New Tire Scanning Screen

11. The scan tire screens will repeat until you have scanned in the entire tire quantity that you entered for that tire type.

TIRE INFO
MI, XPSRIB, 7.50R16,
QTY SCANNED: 2
SCAN TIRE: TIRE #2
TIRE OTHER ID:
002

MORE TYPES? (Y/N)

More Types Screen

NOTE: When you have finished scanning in tires of the first tire type, the E.S.P. Unit will ask if you want to scan in tires belonging to a different tire type. Repeat the procedures above until all original tires are scanned in.

Tires Are Retreaded

1. Note that the screen asks if the tire is retreaded.

TIRE INFO Are tires retreaded? (Y/N)

Tires Retreaded? Screen

2. Press Y meaning that the tires you are going to add are retreaded.

MANUFACTURER 0: Bandag 1: Goodyear 2: Hawkinson 3: Hercules 4: Hercules 5: Michelin 6: Oliver
--

Select Manufacturer

3. When the *Manufacturer* screen appears, highlight the retread technology manufacturer and press *Enter*.

RETREAD DESIGN Enter Tread Design:
Enter as much as possible Example: MXDA2

Enter Retread Design

4. Key in a description of the retread design as shown on the screen.
5. Press *Enter*.
6. Select the Retread Design from the list.

7. You have entered the retread design. Press any key to enter the tire's original tire type.

TIRE TYPE
0: MI, XPSRIB, 7.50R16,
1: MI, XZA2, 11R24.5, G
2: MI, XZE, 11R24.5, G

10818 MI, XPSRIB,
7.50R16, D

Original Tire Type

6. Use the arrow keys to highlight the retreaded tire's original tire type.
7. Press *Enter*.

Retread:
0: BD,3RIBGRADER5,G
Original Thread:
0: MI, XPSRIB, 7.50R16,

QTY: _____

Enter Tire Quantity

8. In the Quantity field, key in the number of tires to scan that has the same retread design and the same original tire type.
9. Press *Enter*.

Retread:
0: BD,3RIBGRADER5,G
Original Thread:
0: MI, XPSRIB, 7.50R16,

QTY: 2

Unit PRICE: _____ . ____

Enter Unit Price

10. Key in the price per tire of the retreaded tires.

11. Press *Enter*.

TIRE INFO BD,3RIBGRADER QTY SCANNED: 0 SCAN TIRE: Press Any Key to Scan
--

Scan First Tire

12. Scan the first tire sensor with the E.S.P. Unit.

TIRE INFO BD,3RIBGRADER QTY SCANNED: 0 SCAN TIRE: 00000000AB TIRE OTHER ID: -----

Enter Other ID

13. Key in an optional Other Tire ID that is used for in-house tracking.

TIRE INFO BD,3RIBGRADER QTY SCANNED: 0 SCAN TIRE: 00000AB TIRE OTHER ID: 00965 LIVES: _____ * Enter total number * of lives
--

Enter Number of Tire Lives

14. Key in the tire's total number of lives. For example, the original lifecycle is life #1, the first retread lifecycle is life #2, and the second retread lifecycle is life #3.

15. Press *Enter*.

TIRE INFO BD,3RIBGRADER QTY SCANNED: 1 SCAN TIRE: Press Any Key to Scan
--

Scan Tire

16. Use the E.S.P. Unit to scan the sensor for next retreaded tire that has the same retread design and original tire type.

TIRE INFO BD,3RIBGRADER QTY SCANNED: 2 SCAN TIRE: 00000Aa TIRE OTHER ID: 00999 LIVES: 2 * Enter total number * of lives MORE TYPES? (Y/N)
--

More Types Screen

NOTE: After you have scanned in the last tire of the same retread design and tire type, the E.S.P. Unit will ask if you wish to enter other retreaded tires of a different retread type.

PERFORMING TIRE MAINTENANCE FUNCTIONS WITH E.S.P. Unit

The following procedures are discussed in the sections that follow:

- Dismounting Tires
- Sending Tires to Repair
- Receiving Tires from Repair
- Sending Tires to Retread
- Receiving Tires from Retread
- Disposing of Tires

Dismounting Tires with E.S.P. Unit

Use this procedure to remove a tire from a vehicle.

Scanning the Tire

1. Power up the E.S.P. Unit with its *On/Off* key. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the keypad *Up* and *Down* arrows to highlight the *Action Menu* option.
3. Press the *Enter* key to call up the *Action Menu*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

4. Use the *Up* and *Down* arrows to highlight the *Dismount Tire* option.
5. Press *Enter* to call up the *Dismount Tire* screen.

TIRE DISMOUNT
SCAN VEH:
Press Any Key to Scan

Scan Vehicle

6. Use the E.S.P. Unit wand to scan the vehicle sensor.

TIRE DISMOUNT
VEH MILEAGE: _____

Key in Mileage

7. Key in the mileage. *BIB TRACK* will ignore the mileage if the fleet only allows designated persons to enter vehicle mileage.

TIRE DISMOUNT
VEH MILEAGE: 100000
SCAN TIRE:
Press Any Key to Scan

Scan Tire Sensor

8. Use the E.S.P. Unit to scan the tire sensor.

TIRE DISMOUNT
VEH MILEAGE: 100000
SCAN TIRE: 0007
Is Tire damaged? (Y/N)

Tire Damaged?

9. You now must visually inspect the tire for damage.

NOTE: You will be asked if the tire to be dismantled is damaged or not. The screen sequence varies depending upon your answer. Refer to the procedures "Dismounting an Non-damaged Tire" and "Dismounted a Damaged Tire."

Dismounting an Non-damaged Tire

1. Inspect the tire for damage.

TIRE DISMOUNT
VEH MILEAGE: 100000
SCAN TIRE: 0007
Is Tire damaged? (Y/N)

Tire Damaged?

2. Press *N* meaning that the tire is not damaged.
3. Note that you are returned to the *Action Menu*.

Dismounting a Damaged Tire

1. Inspect the tire for damage.

TIRE DISMOUNT
VEH MILEAGE: 100000
SCAN TIRE: 0007
Is Tire damaged? (Y/N)

Tire Damaged?

2. Press *Y* meaning that the tire is damaged.

DAMAGE CODE
Search by code?
Y/N
Y = by code
N = by description

Damage Code Screen

3. When the *Damage Code* screen appears, press one of the following:
 - *Y* to search by code
 - *N* to search by description

Searching by Damage (Failure) Code

1. On the *Damage Code* screen, press the *Y* key to search by code. An *Enter Code* screen will appear.

DAMAGE CODE Enter Code: _____

Enter Code Screen

2. On the *Enter Code* screen, you can choose to:
 - Key in an exact code.
 - Select the code from a listing.

Keying in an Exact Code

1. Key in the *Damage (Failure) Code*.
2. Press *Enter*.
3. Check that the screen displays the correct description near the top of the screen. At the bottom of the screen, you will see the full code and description.

DAMAGE CODE
0: Crown Penetration
100: Crown Penetration

Damage Code and Description

4. Press *Enter* to save the transaction and be returned to the *Action Menu*.

Selecting a Code from a List

1. On the *Enter Code* screen, key in the first and/or second numbers of the code.
2. Press *Enter* to call up a list of all codes with those first digits.

DAMAGE CODE:
0: Fast Wear
1: Traction Complaint
2: Noise Complaint
3: Shoulder Scrubbing
001: Fast Wear

Select Code from List

3. Use the arrow keys to highlight the code that you want.
4. Note that when you highlight a listing, the full code and a full description is highlighted at the bottom of the screen.
5. Press *Enter* to save the code and cause the *Action Menu* to reappear.

Searching by Description

1. On the *Damage Code* screen, press the *N* key to search by description.

DAMAGE CODE Search by code? Y/N Y = by code N = by description

Damage Code Screen

2. When the screen asks you for a description, key in the first word or two that describes the damage.

DAMAGE CODE Enter Description: CROWN _____

Description Entered

3. Check that the screen reloads and displays at least one code description.

DAMAGE CODE
0: Crown Penetration
100: Crown Penetration

Damage Code and Description

4. If not already highlighted, use the arrow keys to highlight the code description that you want. Note that when an item is highlighted, the full code and full description are highlighted at the bottom of the screen.
5. Press *Enter* and the transaction will be saved. You will be returned to the *Action Menu*.

Using In Inventory Function with E.S.P. Unit

You use this procedure for the following reasons:

- To record a dismounted tire as being in a terminal or warehouse prior to sending the tire to retread, repair or disposal.
- To record a dismounted tire as being in a terminal or warehouse inventory prior to shipping the tire to another terminal or warehouse
- To inventory tires in a terminal or warehouse

To use the *In Inventory* function, do the following:

1. Power up the E.S.P. Unit with its *On/Off* key. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the keypad *Up* and *Down* arrows to highlight the *Action Menu* option.
3. Press the *Enter* key to call up the *Action Menu*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

4. Use the *Up* and *Down* arrows to highlight the *In Inventory* option.

5. Press *Enter* key to display the *In Inventory* screen.

**IN INVENTORY
SCAN TIRE:
Press Any Key to
Scan**

In Inventory Screen

6. Hold the E.S.P. Unit's scanner near the tire's sensor.
7. Press any key to scan.
8. Note that the tire is scanned and you are returned to the *Action Menu*.

Sending Tires to Repair with E.S.P. Unit

Use this procedure to send a dismounted tire to a repair vendor.

1. Turn on the E.S.P. Unit with its *On/Off* key. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the keypad *Up* and *Down* arrow keys to highlight the *Action Menu* option.
3. Press the *Enter* key to call up the *Action Menu*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

4. Use the *Up* and *Down* arrow keys to highlight *Repair Menu* and press *Enter*.

REPAIR
1: Send to Repair
2: Receive Repair
9: Back

Repair Menu

5. Use the arrow keys to highlight *Send to Repair* and press *Enter*.

SEND TO REPAIR REPAIR VENDOR 0: REPAIRER 1 1: REPAIRER 2

Select Repair Vendor

6. Use the arrow keys to select a repair vendor then press *Enter*.

SEND TO REPAIR REPAIR VENDOR 0: REPAIRER 1 REPAIR ORDER # -----v
--

Repair Order No.

7. Key in the Repair Order number and press *Enter*.

SEND TO REPAIR REPAIR VENDOR 0: REPAIRER 1 REPAIR ORDER # 002 SCAN TIRE: Press Any Key To Scan

Scan Tire

8. Use the E.S.P. Unit to scan the tire that is to be sent to repair.

SEND TO REPAIR REPAIR VENDOR 0: REPAIRER 1 REPAIR ORDER # 002 SCAN TIRE: 000008 More Tires? (Y/N)

More Tires to Repairer?

NOTE: You will be asked if you want to send additional tires to the same repair vendor under the same Repair Order number. See the procedures "Adding Tires to Same Repair Order" and "Closing the Repair Order."

Adding Tires to Same Repair Order

To add tires to be sent to the same repair vendor under the same Repair Order, do the following:

SEND TO REPAIR REPAIR VENDOR 0: REPAIRER 1 REPAIR ORDER # 002 SCAN TIRE: 00000000 More Tires? (Y/N)	
---	--

More Tires Screen

1. Press Y meaning yes.

SEND TO REPAIR REPAIR VENDOR 0: REPAIRER 1 REPAIR ORDER # 002 SCAN TIRE: Press Any Key To Scan	
--	--

Scan Tire Screen

2. Scan the next tire.

Closing the Repair Order

To close the Repair Order, do the following:

SEND TO REPAIR	
REPAIR VENDOR	
0: REPAIRER 1	
REPAIR ORDER #	
002	
SCAN	TIRE:
00000000	
More Tires? (Y/N)	

More Tires Screen

1. Press *N* meaning no.

REPAIR
1: Send to Repair
2: Receive Repair
9: Back

Repair Menu

2. From this menu, you can do the following:
 - Choose *Send to Repair* to create another Repair Order.
 - Choose *Receive Repair* to receive a repaired or returned-as-received (RAR) tire.
 - Choose *Back* to return to the *Action Menu*.

Receiving Tires From Repair with E.S.P. Unit

Use this procedure to receive a tire from a repair vendor

1. Turn on the E.S.P. Unit with its *On/Off* key. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the keypad *Up* and *Down* arrows to highlight the *Action Menu* option.
3. Press the *Enter* key to call up the *Action Menu*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

4. Use the *Up* and *Down* arrows to highlight *Repair Menu*.
5. Press *Enter* to call up the *Repair Menu*.

REPAIR
1: Send to Repair
2: Receive Repair
9: Back

Repair Menu

6. Use the arrow keys to highlight *Receive Repair* and press *Enter*.

REPAIR
1: Send to Repair
2: Receive Repair
9: Back

Receive From Repair

7. When *Scan Tire* appears on the screen, place the E.S.P. Unit's scanning wand near the tire and press any key.

RECEIVE REPAIR
SCAN TIRE:
Press Any Key to Scan

Scan Tire

8. Notice that the scanner will read both the tire sensor ID and the tire pressure.
9. Then you will be asked if the vendor repaired the tire.

RECEIVE REPAIR
Is Tire Repaired?
(Y/N)
Y = Tire Repaired
N = tire is RAR

Tire Repaired?

10. Press one of the following:
- Y for tire was repaired.
 - N for tire was not repaired and is *RAR* (Returned As Received).

Receiving a Repaired Tire

1. Press Y, which means that the tire was repaired.
2. A *Repair Type List* screen will appear.

RECEIVE REPAIR	
REPAIR TYPE	
0:	600 Bias #0
1:	601 Bias #1
2:	602 Bias #2
3:	603 Bias # 3
4:	604 Bias # 4
5:	Bias # 7
6:	Bias # 8
7:	Bias #0
8:	Bias #2
9:	Bias #3

Repair Type List Screen

3. If needed, use the arrow keys to scroll through the listing.
4. Highlight the tire's repair type.
5. Press *Enter* to record the code and call up the *Repair Cost* screen.

RECEIVE REPAIR	
COST:	____ . ____

Repair Cost Screen

6. Key in a cost and press *Enter*.

RECEIVE REPAIR
More Repairs? (Y/N)

More Repairs Screen

7. Do one of the following:
 - Press Y to be returned to the *Scan Tire* screen and receive other repaired tires.
 - Press N to be returned to the *Repair Menu*.

Receiving an Unrepaired (RAR - Returned As Received) Tire

1. At the *Receive Repair* screen, press the *N* key to indicate that the tire was unrepaired and was returned-as-received.

RECEIVE REPAIR Is Tire Repaired? (Y/N) Y = Tire Repaired N = tire is RAR
--

Tire Repaired?

2. Note that there is no RAR code for a failed repair.

Sending Tires to Retread with E.S.P. Unit

Use this function to send a tire to a retread vendor.

6. Turn on the E.S.P. Unit with its *On/Off* key. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

7. Use the keypad *Up* and *Down* arrows to highlight the *Action Menu* option.
8. Press the *Enter* key to call up the *Action Menu*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

9. Use the *Up* and *Down* arrows to highlight the *Retread Menu* option.
10. Press *Enter* to call up the *Retread Menu*.

RETREAD
1: Send to Retread
2: Receive Retread
9: Back

Retread Menu

11. Use the arrow keys to highlight *Send to Retread* and press *Enter*.

SEND TO RETREAD
RETREAD VENDOR
0: Retreader 1
1: Retreader 2
2: Retreader 3

Select Retread Vendor

12. Use the arrow keys to highlight a vendor name and press *Enter*.

SEND TO RETREAD
RETREAD VENDOR
0: Retreader 1
SCAN TIRE:
Press Any Key to Scan

Select Vendor

13. Scan the tire with the E.S.P. Unit.

RETREAD REASON
Search by code?
Y/N
Y = by code
N = by description

Search Option Screen

14. When the *Search Option* screen appears, choose one of the following:
- Y to search by code
 - N to search by description

Searching by Retread Code

1. On the *Search Option* screen, press *Y* to search by *Retread Code*. The *Enter Code* screen will appear.

RETREAD REASON Enter Code: _____
--

Enter Code Screen

2. On the *Enter Code* screen, you can choose to:
 - ◆ Key in an exact code.
 - ◆ Key in the first and second numerals of the code then select from a listing.

Keying in an Exact Code

Do the following to key in an exact code.

1. Key in the code.

RETREAD REASON Enter Code: _____
--

Key in Exact Code

2. Press *Enter*.

RETREAD REASON 0: Shoulder Wear - Both 183 Shoulder Wear - Both Shoulders
--

3. Check that the screen displays the correct description near the top of the screen. At the bottom of the screen, you will see the full code and description.

SEND TO RETREAD RETREAD VENDOR 0: Retreader 1 More Retreads? (Y/N)

More Retreads?

4. Do one of the following:
 - Enter *Y* to continue entering retreaded tires.
 - Enter *N* to return to the *Action Menu*.

Selecting a Code from a List

1. On the *Enter Code* screen, key in the first and/or second number of the code.

RETREAD REASON Enter Code: _____
--

Enter Code First Digits

2. Press *Enter* to call up a list of all codes with those first digits.
3. For example, if you key in *1*, you will see the screen shown below.

RETREAD REASON 0: Stone Drilling 1: Rib Tearing 2: Excessive Wear 3: Brake Skid Damage 4: One Sided Wear 5: Heel/Toe Wear 6: Shoulder Wear - Both 7: Cuppins/Scallop Wear 183 Shoulder Wear - Both Shoulders

Code Search Results Screen

4. Use the arrow keys to highlight the listing that you want.
5. Note that when you highlight a listing, the full code and a full description is highlighted at the bottom of the screen.

SEND TO RETREAD RETREAD VENDOR 0: Retreader 1 More Retreads? (Y/N)

More Retreads?

6. Do one of the following:
 - Enter *Y* to continue entering retreaded tires.
 - Enter *N* to return to the *Action Menu*.

Searching by Description

1. On the *Code Search* screen, press *N* to search by description.

RETREAD REASON
Search by code? Y/N
Y = by code
N = by description

Code Search Screen

2. When the screen asks you for a description, key in the first word or two that describes the retread reason.

RETREAD REASON
Enter Description:
FAST_____

Description Entered

3. Press *Enter*.
4. Check that the screen reloads with at least one listing.

RETREAD REASON
0: Fast Wear

001 Fast Wear

Retread Code and Description

5. If more than one listing appears, use the arrow keys to highlight the listing that you want.
6. Note that when you highlight a listing, its full code and full description appears highlighted at the bottom of the screen.

SEND TO RETREAD
RETREAD VENDOR
0: Retreader 1

More Retreads?
(Y/N)

More Retreads?

7. Do one of the following:
 - Enter *Y* to continue entering retreaded tires.
 - Enter *N* to return to the *Action Menu*.

Receiving Tires from Retread with E.S.P. Unit

Use this procedure to receive a tire from a retread vendor.

Scanning the Tire

1. Turn on the E.S.P. Unit with its *On/Off* key. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the keypad *Up* and *Down* arrows to highlight the *Action Menu* option.
3. Press the *Enter* key to call up the *Action Menu*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

4. Use the *Up* and *Down* arrows to highlight the *Retread Menu* option.
6. Press *Enter* to call up the *Retread Menu*.

RETREAD
1: Send to Retread
2: Receive Retread
9: Back

Retread Menu

7. Use the arrow keys to highlight *Receive Retread*.

RETREAD
1: Send to Retread
2: Receive Retread
9: Back

Retread Menu

8. Press *Enter* to call up the *Scan Tire* screen.

RECEIVE RETREAD
SCAN TIRE:
Press Any Key to
Scan

Scan Tire Screen

9. Aim the E.S.P. Unit scanning wand at the tire and press any key to read the tire ID and tire pressure.
10. Notice that after the tire is scanned, you are asked if the tire was retreaded.

RECEIVE RETREAD
Is Tire Retreaded?
(Y/N)
Y = Tire Retreaded
N = Tire is RAR

Tire Retreaded or RAR Screen

11. Select one of the choices:
- ◆ Y if tire was retreaded
 - ◆ N if tire was not retreaded and was RAR (Returned as Received)

Receiving Retreaded Tire

1. On the *Retreaded or RAR* screen, press Y, which means the tire was retreaded.

RECEIVE RETREAD Is Tire Retreaded? (Y/N) Y = Tire Retreaded N = Tire is RAR
--

Retreaded or RAR Screen

2. Check that the *Retread Design Search* screen appears.

RETREAD DESIGN Search by code? (Y/N) Y = by code N = by description
--

Retread Design Search Screen

3. Press one of the following:
 - ◆ Y to search for *Retread Design* by code
 - ◆ N to search for *Retread Design* by description

Searching by Code

1. On the *Search By Code* screen, press the Y to search by code. An *Enter Code* screen will appear.

RETREAD DESIGN Enter Code: _____
--

Enter Code Screen

2. On the *Enter Code* screen, you can choose to:
 - ◆ Key in an exact code.
 - ◆ Select the code from a listing.

Keying in an Exact Code

1. Key in the Retread Design Code.
2. Press the *Enter* key.
3. Check that the screen displays the correct code description near the top of the screen. At the bottom of the screen, you will see the full code and description highlighted.
4. Press *Enter* to save the transaction.

Selecting the Code from a List

1. On the *Enter Code* screen, key in the first and/or second numbers of the code.

RETREAD DESIGN Enter Code : _____

Enter Code Screen

2. Press *Enter* to call up a list of codes with those first digits.
3. Use the arrow keys to highlight the code that you want.
4. Note that when you highlight a listing, the full code and a full description is highlighted at the bottom of the screen.
5. Press *Enter* to save the transaction.

Searching by Description

1. On the *Retread Design Search* screen, press the *N* key to search by description.

RETREAD DESIGN Search by code? (Y/N) Y = by code N = by description
--

Retread Design Search Screen

2. When the screen asks for a description, key in the first word or two of the code's description.
3. Press the *Enter* key.
4. Check that the screen reloads and displays at least one code and description.
5. If not already highlighted, use the arrow keys to highlight the code description that you want.. Note that the full code and description appear highlighted at the bottom of the screen.
6. Press *Enter* to save the transaction.

See the procedure *Entering Costs and Other Specifics* for your next steps.

Entering Costs and Other Specifics

After you have entered the tire's Retread Design, the *Retread Design Specifics* screen will appear.

1. When the *Retread Specifics* screen appears, key in the retread cost and press *Enter*.

RETREAD DESIGN COST: ____ . ____ <i>Retread Specifics</i>

2. When the screen reloads, enter the *Tread Width* and *Depth*.

RETREAD DESIGN COST: ____ . ____ TREAD WIDTH: ____ . ____ DEPTH: ____ <i>Retread Specifics</i>
--

3. Press *Enter*, the screen will reload and ask for the *Retread Method*.

RETREAD DESIGN COST: ____ . ____ TREAD WIDTH: ____ . ____ DEPTH: ____ RETREAD METHOD: 0: Mold Cure 1: Pre-Cure <i>Retread Method</i>
--

4. Select one of the following:

- ◆ 0 for Mold Cure.
- ◆ 1 for Pre-Cure.

Receiving RAR (Returned As Received) Tire

1. On the *Retread Design Search* screen, press the *N* key to indicate that the tire was not retreaded and as Returned as Received.

RECEIVE RETREAD Is Tire Retreaded? (Y/N) Y = Tire Retreaded N = Tire is RAR
--

Retread Design Search Screen

2. Check that the *RAR Search* screen appears.

RAR CODE Search by code?? Y/N Y = by code N = by description

RAR Search Screen

3. On the *RAR Search* screen, you can choose to:
 - + Select *Y* to search by code.
 - + Select *N* to search by code description.

Searching by Code

1. On the *RAR Search* screen, press *Y* to search by code. The *Enter Code* screen will appear.

RAR CODE Enter Code: _____
--

Enter Code Screen

2. On the *Enter Code* screen, you can choose to:
 - + Key in an exact code.
 - + Select the RAR code from a listing.

Keying in an Exact Code

1. Key in the RAR Code.
2. Press the *Enter* key.
3. Check that the screen displays the correct code description near the top of the screen. At the bottom of the screen, you will see the full code and description highlighted.
4. Press *Enter* to save the transaction and be returned to the *Retread Menu*.

Selecting the Code from a List

1. On the *Enter Code* screen, key in the first and/or second numbers of the code.
2. Press *Enter* to call up a list of all codes with those first digits.

3. Use the arrow keys to highlight the code that you want.
4. Note that when you highlight a listing, the full code and a full description is highlighted at the bottom of the screen.
5. Press *Enter* to save the transaction and be returned to the *Retread Menu*.

Searching by Description

1. On the *RAR Search By Code* screen, press the *N* key to search by description.
2. When the screen asks for a description, key in the first word or two of the code's description.
3. Press the *Enter* key.
4. Check that the screen reloads and displays at least one code and description.
5. If not already highlighted, use the arrow keys to highlight the code description that you want. Note that when an item is highlighted, the full code and description appears highlighted at the bottom of the screen.
6. Press *Enter* and the transaction will be saved.

Disposing of Tires with E.S.P. Unit

You use one of these procedures when disposing of tires.

1. Turn on the E.S.P. Unit with its *On/Off* key. If you see a menu other than the *Main Menu* on the E.S.P. Unit screen, press the *CLR* (Clear) key until the *Main Menu* appears.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. Use the keypad *Up* and *Down* arrows to highlight the *Action Menu* option.
3. Press the *Enter* key to call up the *Action Menu*.
4. At the *Action Menu*, use the arrow keys to highlight *Dispose Tire*.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

5. Press *Enter* to call up the *Dispose Tire* screen.
6. Hold the E.S.P. Unit scanning wand near the tire and press any key to scan the Tire Sensor.

7. Check that the *Dispose Reason Screen* appears.

DISPOSE TIRE
0: Casing Scrapped
1: Casing Sold
2: Sold w/ Vehicle
3: Warranty

Dispose Reason Screen

8. You now must select your Dispose Reason:

- + *Casing Scrapped*
- + *Casing Sold*
- + *Sold w/ Vehicle*
- + *Warranty*

Specifying Casing Scrapped Disposal

When you specify Casing Scrapped Disposal, you must enter a Scrap Reason Code.

1. On the *Dispose Reason* screen, use the arrow keys to select *Casing Scrapped*.

DISPOSE TIRE
0: Casing Scrapped
1: Casing Sold
2: Sold w/ Vehicle
3: Warranty

Dispose Reason Screen

2. Press *Enter*.

DISPOSE TIRE
DISPOSE VENDOR
0: Disposer 1
1: Disposer 2

Select Dispose Vendor

3. Use the arrow keys to highlight the name of a disposal vendor and press *Enter*.

SCRAP REASON
Search by code?
Y/N
Y = by code
N = by description
X = no reason

Code Search Screen

4. When the *Code Search* screen appears, you have a choice of:
 - + Pressing *Y* to search by code.
 - + Pressing *N* to search by description.

Searching by Scrap Reason Code

1. On the Code Search screen, press Y to search by *Scrap Reason Code*. The *Enter Code* screen will appear.

SCRAP REASON Enter Code: _____

Enter Code Screen

2. On the *Enter Code* screen, you can choose to:
 - + Key in an exact code.
 - + Key in the first and/or second numbers of the code then select from a listing.

Keying in an exact code

1. Key in the exact Scrap Reason code.
2. Press *Enter*.

Selecting a code from a list

1. Key in the first and/or second numbers of the code.
2. Press *Enter*.
3. All codes beginning with that number(s) will be listed. For example, if you key in 5, you will see the listings Customer Spec. Repair (509), Failed Repair (537), Improper Nail Hole Repair (543), Bad Spot Repair (544).
If you key in 1, you will see the screen shown below.

SCRAP REASON 0: Crown Penetration 1: Multiple tread cuts 2: Stone Drilling 3: Rib, Lug Cracking 4: Groove Cracking 5: Regrooving Damage 6: Vehicle Damage 7: Excessive Wear 8: Brake Skid Damage 102 Multiple tread cuts/tearing
--

Code Search Results Screen

4. Use the arrow keys to highlight the listing that you want.
5. Note that when you highlight a listing, its *Condition Code* and full description appear highlighted at the bottom of the screen.
6. Press *Enter* to call up the *Dispose Vendor* Screen.

Searching by Description

1. Press *N* on the *Condition Code Search* screen to search by *Description*.

SCRAP REASON
Search by code? Y/N
Y = by code
N = by description

Condition Code Search Screen

2. Check that the *Search by Description* screen appears.

SCRAP REASON
Enter Description:

Search by Description Screen

3. Key in the first word and/or words of the description and press *Enter*.

SCRAP REASON
Enter Description:
CROWN_____

Description Entered

4. Check that the screen reloads with a listing.

SCRAP REASON
0: Crown Penetration

100: Crown Penetration

Scrap Reason Code

5. If more than one listing appears, use the arrow keys to highlight the listing that you want.
6. Note that when you highlight a listing, its *Scrap Reason Code* and full description appears highlighted at the bottom of the screen.
7. Press *Enter* to call up the *Tire Dispose Vendor* screen.

Entering "No Reason"

When entering *No Reason*, do the following.

SCRAP REASON Search by code? Y/N Y = by code N = by description X = no reason
--

No Scrap Reason Code

1. Key in X, meaning no reason.
2. You are returned to the *Action Menu*.

Selecting a Disposal Method

1. On the *Tire Dispose Vendor* screen, highlight the vendor that you want.

DISPOSE TIRE DISPOSE METHOD
0: Sent to Disposal Site
1: Picked Up by Certified Disposer
2: Picked Up by Tire Dealer

Dispose Method and Cost Screen

2. Press *Enter* to display your Dispose Method options. Highlight one and press *Enter*.

DISPOSE TIRE
COST: _____ . ____
Enter cost for each tire. If tires have different costs, redo this menu for each set with the same cost.

Enter Cost

3. When the screen reloads, key in your cost.
4. Press *Enter*.

DISPOSE TIRE
SCAN TIRE:
Press Any Key to Scan

Scan Tire

5. Scan the Tire Sensor with the E.S.P. Unit.

DISPOSE TIRE
More Tires? (Y/N)

More Tires?

6. Do one of the following:
 - Press *Y* for yes and scan another tire for disposal.
 - Press *N* and be returned to the *Action Menu*.

Specifying Casing Sold Disposal

1. On the *Dispose Reason* screen, use the arrow keys to select *Casing Sold*.

DISPOSE TIRE
SCAN TIRE:
00000001A3
DISPOSE REASON
0: Casing Scrapped
1: Casing Sold
2: Sold w/ Vehicle
3: Warranty

Dispose Reason Screen

2. Press *Enter* to call up the *Dispose Vendor* screen.

DISPOSE TIRE
DISPOSE VENDOR
0: Vendor 1
1: Vendor 2

Dispose Vendor Screen

3. Use the arrow keys to select a vendor and press *Enter* to call up the *Casing Value* entry line.

DISPOSE TIRE
CASING VALUE:
_____ . ____
Enter cost for each tire. If tires have different costs, redo this menu for each set with the same cost.

Casing Value

4. Key in the *Casing Value* and press *Enter*.

DISPOSE TIRE
SCAN TIRE:
Press Any Key to Scan

Scan Tire

5. Scan the Tire Sensor with the E.S.P. Unit.

DISPOSE TIRE
More Tires? (Y/N)

More Tires?

6. Do one of the following:
- Press *Y* for yes and scan another tire for disposal.
 - Press *N* and be returned to the *Action Menu*.

Specifying Sold with Vehicle Disposal

1. On the *Dispose Reason* screen, use the arrow keys to highlight *Sold w/ Vehicle*.

DISPOSE TIRE
0: Casing Scrapped
1: Casing Sold
2: Sold w/ Vehicle
3: Warranty

Dispose Reason Screen

2. Press *Enter*.

DISPOSE TIRE
DISPOSE VENDOR
0: Vendor 1
1: Vendor 2

Select Vendor

3. Select the disposal vendor and press *Enter*.

DISPOSE TIRE
SCAN TIRE:
Press Any Key to
Scan

Scan Tire

4. Scan the Tire Sensor with the E.S.P. Unit.

DISPOSE TIRE
More Tires? (Y/N)

More Tires?

5. Do one of the following:
6. Press *Y* for yes and scan another tire for disposal.
7. Press *N* and be returned to the *Action Menu*.

Specifying Warranty Disposal

1. On the *Dispose Reason* screen, use the arrow keys to highlight *Warranty*.

DISPOSE TIRE
0: Casing Scrapped
1: Casing Sold
2: Sold w/ Vehicle
3: Warranty

Dispose Reason Screen

2. Press *Enter*.

DISPOSE TIRE
DISPOSE VENDOR
0: Vendor 1
1: Vendor 2

Select Vendor

3. Select a vendor and press *Enter*.

DISPOSE TIRE
SCAN TIRE:
Press Any Key to Scan

Scan Tire

4. Scan the Tire Sensor with the E.S.P. Unit.

DISPOSE TIRE
More Tires? (Y/N)

More Tires?

5. Either press *Y* for yes and scan another tire for disposal. Or press *N* and be returned to the *Action Menu*.

Shipping / Receiving Tires

This procedure is used to transfer tires from the inventory of one terminal to another's.

1. Call up the *Main Menu*.

MAIN MENU
1: Action Menu
2: Send/Rec Data
3: Erase Data
4: Version
5: Read Sensor

Main Menu

2. On *Main Menu*, highlight *Action Menu* and press *Enter* key.

ACTION MENU
1: Add New Tires
2: Inspect & Mount
3: Dismount Tire
4: Repair Menu
5: Retread Menu
6: Dispose Tire
7: Ship/Receive
8: In Inventory
9: Match Vehicle
0: Change Fleet

Action Menu

3. On *Action Menu*, highlight *Ship/Receive* and press *Enter*.

SHIP/RECEIVE TIRE
1: Ship Tire
2: Receive Tire
9: Back

Ship/Receive Menu

4. Select one of the following:
 - *Ship Tire* to ship tires
 - *Receive Tire* to receive tires
 - *Back* to return to *Action Menu*.

Shipping Tires

To use this function, do the following.

SHIP/RECEIVE TIRE
1: Ship Tire
2: Receive Tire
9: Back

Select Ship Tire

1. Use the arrow keys to highlight *Ship Tire* then press *Enter*.

SHIP TIRE
SCAN TIRE:
Press Any Key to Scan

Scan Tire

2. Use the E.S.P. Unit to scan the tire's sensor.

SHIP/RECEIVE TIRE
1: Ship Tire
2: Receive Tire
9: Back

Ship/Receive Menu

Receiving Tires

Use the following procedure to receive a tire.

SHIP/RECEIVE TIRE
1: Ship Tire
2: Receive Tire
9: Back

Ship/Receive Menu

1. Use the arrow keys to highlight *Receive Tire* and press *Enter*.

SHIP TIRE
SCAN TIRE:
Press Any Key to Scan

Scan Tire

2. Use the E.S.P. Unit to scan the tire that is being received.

SHIP/RECEIVE TIRE
1: Ship Tire
2: Receive Tire
9: Back

Ship/Receive Menu