

User Guide

RMN : HSTNH-F606V

Brand : HP Inc.

© Copyright 2016 HP Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. microSD is a trademark or registered trademark of SD-3C in the United States, other countries or both. Microsoft, OneDrive, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: July 2016

Document Part Number: 855137-001

Product notice

This user guide describes features that are common to most models. Some features may not be available on your device.

Not all features are available in all editions or versions of Windows. Systems may require upgraded and/or separately purchased hardware, drivers, software or BIOS update to take full advantage of Windows functionality. Windows 10 is automatically updated, which is always enabled. ISP fees may apply and additional requirements may apply over time for updates. See <http://www.microsoft.com>.

To access the latest user guides or manuals for your product, go to <http://www.hp.com/support>. Select **Find your product**, and then follow the on-screen instructions.

Software terms

By installing, copying, downloading, or otherwise using any software product preinstalled on this device, you agree to be bound by the terms of the HP End User License Agreement (EULA). If you do not accept these license terms, your sole remedy is to return the entire unused product (hardware and software) within 14 days for a full refund subject to the refund policy of your seller.

For any further information or to request a full refund of the price of the device, please contact your seller.

Table of contents

1 Welcome	1
Finding information	2
2 Components	4
Locating hardware	4
Locating software	4
Locating help	4
Front	5
Back	8
Labels	10
Installing nano SIM cards	10
Inserting nano SIM cards	10
3 Expanding the display	12
Connecting using the desk dock	12
Accessing Continuum	13
Opening an app on an external display	13
Closing a window on an external display	14
Switch apps	14
Using HP Workspace (select products only)	14
4 Network connections	15
Connecting to a wireless network	15
Using the network & wireless controls	15
Connecting to a WLAN	15
Connecting to cellular networks	16
Using Bluetooth wireless devices	16
Connecting Bluetooth devices	17
Connecting to a wired network—LAN (select products only)	17
Sharing or paying wirelessly	17
5 Screen navigation	18
Using gestures	18
Tap	18
Swipe	18
Two-finger pinch zoom	19

One-finger slide	19
Using an optional keyboard and optional mouse	19
Using the on-screen keyboard	19
Using the screen features	20
Using the display	20
Using the navigation bar	20
Viewing the status bar	21
Checking notifications, changing settings, and accessing shortcuts	22
6 Using the voice calling and texting features	23
7 Adding apps	24
8 Using email and social networks	25
Setting up email accounts	25
Setting up a social media account	25
Sending email	25
9 Printing using HP All-in-One Remote	26
10 Entertainment features	27
Using the camera	27
Using audio	28
Connecting speakers	28
Connecting headphones	28
Connecting headsets	29
Changing the volume	29
Using sound settings	29
Using video	30
11 Power management	31
Turning off the device	31
Setting power options	31
Using power-saving states	31
Initiating and exiting screen off	31
Using the battery saver	31
Using battery power	31
Displaying the remaining battery charge	32
Maximizing battery discharge time	32
Managing low battery levels	32

Identifying low battery levels	32
Resolving a low battery level	32
Conserving battery power	32
Disposing of a battery	33
Using wireless charging	33
Using external AC power	34
Testing an AC adapter	34
12 Sharing and backing up your data	35
Using OneDrive	35
Using a microSD memory card	35
Inserting a microSD memory card	35
Using Storage	36
Determining storage space	36
Using Backup	36
Restoring or resetting your device	37
13 Security	38
Setting PIN protection	38
Using Windows Hello	38
Using a Microsoft account	38
Locking and unlocking the screen	39
Locking the screen	39
Unlocking the screen	39
14 Maintenance	40
Updating the operating system and apps	40
Updating the operating system	40
Updating apps	40
Registering your device	40
Diagnostics	40
Cleaning your device	41
Cleaning procedures	41
Cleaning the display	41
Cleaning the sides	41
Shipping your device	41
15 Accessibility	43
Supported assistive technologies	43
Contacting support	43

Index 44

1 Welcome

After you set up and register the device, we recommend the following steps to get the most out of your smart investment:



IMPORTANT: You must unlock the screen any time the screen turns off.

- ▲ Press the power button, and then swipe up from the middle of the screen. If prompted, enter your PIN.



TIP: To quickly return to the Start screen from an open app, tap  from the Navigation Bar at the bottom of the screen.

- **Expand your display**—Using the desk dock (purchased separately) and Continuum, you can connect your device to an external display. The desk dock can also be used to connect your device to a keyboard and mouse. See [Expanding the display on page 12](#).
- **Connect to the Internet**—Set up your network so that you can connect to the Internet. For more information, see [Network connections on page 15](#).
- **Get to know your device**—Learn about your device features. See [Components on page 4](#) and [Screen navigation on page 18](#).
- **Find help**—Learn about the screen and software features on your device. See [Locating help on page 4](#).
- **Find installed apps**—Access a list of the apps preinstalled on the device:
 - ▲ Swipe left from the right edge of the Start screen.
- **Add more apps**—Use the **Store** app to download apps for your device. See [Adding apps on page 24](#).
- **Share your files and back up your apps and files**—Set up a method for sharing and backing up using a OneDrive® account or a microSD memory card. See [Sharing and backing up your data on page 35](#).

Finding information

To locate resources that provide product details, how-to information, and more, use this table.

Resource	Contents
<i>Quick Start</i>	Overview of device setup and features
The Get Started app IMPORTANT: The Get Started app requires an Internet connection.  Swipe left from the right edge of the Start screen to display all apps, and then tap Get Started . Tap  , and then select a topic.	Detailed instructions and videos to help you learn about your device.
HP support For HP support, go to http://www.hp.com/support .	- Online chat with an HP technician - Support telephone numbers - HP service center locations
<i>Safety & Comfort Guide</i> To access this guide:  Swipe up from the middle of the Start screen, tap  HP Device Hub , and then tap User Guide . Select your language if prompted to do so, and then tap Safety & Comfort Guide . – or –  Go to http://www.hp.com/ergo . IMPORTANT: You must be connected to the Internet to access the latest version of the guide.	- Proper workstation setup - Guidelines for posture and work habits that increase your comfort and decrease your risk of injury - Electrical and mechanical safety information
<i>Regulatory, Safety and Environmental Notices</i> To access this document:  Swipe up from the middle of the Start screen, tap  HP Device Hub , and then tap User Guide . Select your language if prompted to do so, and then tap Regulatory, Safety and Environmental Notices . IMPORTANT: You must be connected to the Internet to access the latest version of the document.	Important regulatory notices, including information about proper battery disposal, if needed.
<i>Limited Warranty*</i> To access this document:  Swipe up from the middle of the Start screen, tap  HP Device Hub , and then tap User Guide . Select your language if prompted to do so, and then tap Warranty . – or –  Go to http://www.hp.com/go/orderdocuments .	Specific warranty information about this device

Resource	Contents
	IMPORTANT: You must be connected to the Internet to access the latest version of the document.
	*You can find your HP Limited Warranty located with the user guides on your product. In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, P.O. Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name and your name, phone number, and postal address.

2 Components

Locating hardware

To find out what hardware is installed on your device:

1. Swipe up from the middle of the screen.
2. Tap  **HP Device Hub**.

Information about the system hardware components on your device is displayed.

Locating software

To find out what software is installed on your device:

- ▲ Swipe left from the right edge of the Start screen to display all apps.

Locating help

The Get Started app provides detailed instructions, slideshows, and videos to help you learn about your device.




IMPORTANT: The Get Started app requires an Internet connection.

- ▲ Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , and then select a topic.



NOTE: For additional information, tap  to use the search feature.


Front



Component		Description
(1)	Power light	Red: The battery is near depletion and is being charged. This light will remain on until the battery is charged enough for the device to be functional.
(2)	Ambient light sensor	Detects the light in the surrounding area and then adjusts the brightness of the display. To set automatic brightness adjustment: Swipe down from the top of the screen, tap  All settings, tap System, tap Display, and then follow the on-screen instructions.
(3)	Earpiece	Produces sound for phone calls.
(4)	Audio-out (headphone)/Audio-in (microphone) combo jack	Connects optional powered stereo speakers, headphones, earbuds, a headset, or a television audio cable. Also connects an optional headset microphone. This jack does not support optional microphone-only devices. WARNING! To reduce the risk of personal injury, adjust the volume before using headphones, earbuds, or a headset. For additional safety information, see the <i>Regulatory, Safety and Environmental Notices</i>. To access this guide: Swipe up from the middle of the Start screen, tap  HP Device Hub, and then tap User Guide. Select your language if prompted to do so, and then tap Regulatory, Safety and Environmental Notices. IMPORTANT: You must be connected to the Internet to access the latest version of the document. NOTE: When a device is connected to the jack, the external speakers are disabled.
(5)	Camera	Records video and captures photographs. To use your camera: Tap  on the Start screen. For more information, see Using the camera on page 27.
(6)	Iris camera	Allows iris recognition to unlock your device, instead of a PIN. For more information, see Using Windows Hello on page 38.
(7)	Power button	- When the device is off, press the button for about 5 seconds until the device vibrates to turn on the device. - When the device is on, press the button briefly to turn off and lock the screen. - When the screen is off, press the button to display the lock screen. - When the device is on, press and hold the button until the slide down to power off message appears. Release the button, and then swipe down to turn off the device.

Component		Description
		NOTE: The device will power on when connected to a power source.
(8)	Volume up button	Increases speaker volume incrementally while you hold down the button. The volume status bar appears when you press this button. For more information, see Changing the volume on page 29 .
(9)	Volume down button	Decreases speaker volume incrementally while you hold down the button. The volume status bar appears when you press this button. For more information, see Changing the volume on page 29 .
(10)	Internal microphone	Transmits sound for phone calls and records sound for other applications on your device.
(11)	Speaker	Produces sound.
(12)	USB Type-C charging port	Connects to the AC adapter to provide power to the device, connects to the desk dock, or connects to any USB device with a Type-C connector. NOTE: Adapters (purchased separately) may be required.
(13)	Nano SIM/MicroSD memory card reader	Supports a nano subscriber identity module (SIM) card and a microSD memory card in a dual-compartment tray. Select products support two SIM cards. For installation instructions, see Inserting nano SIM cards on page 10 or Inserting a microSD memory card on page 35 . Place your fingernail in the small recess on the bottom of the card tray and pull the tray out to remove it from the device. NOTE: Your device has read/write support for microSD memory cards up to 2 TB.

Back



Component		Description
(1)	WWAN antennas*	Send and receive wireless signals to communicate with wireless wide area networks (WWANs).
(2)	WLAN antennas*	Send and receive wireless signals to communicate with wireless local area networks (WLANs).
(3)	Camera	Records video and captures photographs. To use the camera: ▲ Tap  on the Start screen. For more details, see Using the camera on page 27 .
(4)	Flash and flashlight	Provides light for photographs and videos, and can operate as a flashlight. For information about flash settings, see Using the camera on page 27 . To access the flashlight: ▲ Swipe down from the top of the screen, tap Expand , and then tap Flashlight . Tap Flashlight again to turn off the flashlight.

Component	Description
(5) Fingerprint reader	Allows a fingerprint recognition to unlock your device instead of a PIN. For more details, see Using Windows Hello on page 38. NOTE: The fingerprint reader may require additional software. For more information, go to http://www.hp.com/support.
(6) NFC tapping area	Allows you to share data and files with another device that has Near Field Communications (NFC). Simply touching the devices together. For more information, see Sharing or paying wirelessly on page 17.
(7) Wireless charging area	Allows you to charge your device wirelessly. For more information, see Using wireless charging on page 33.
(8) Accessory connector	Connects optional accessories that support Pogo pin connectors.

*The antennas are not visible from the outside of the device. For optimal transmission, keep the areas immediately around the antennas free from obstructions. For wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region.

To access this guide:



Swipe up from the middle of the screen, tap  **HP Device Hub**, and then tap **User Guide**. Select your language if prompted to do so, and then tap **Regulatory, Safety and Environmental Notices**.

IMPORTANT: You must be connected to the Internet to access the latest version of the document.

Labels

The labels for the device provide information you may need when you troubleshoot system problems or travel internationally with the device.

 **IMPORTANT:** Check the following locations for the labels described in this section: the back of the device, the device box, and the electronic regulatory labels.

To access the electronic regulatory labels:

▲ Swipe up from the middle of the screen, tap  **HP Device Hub**, and then tap **Regulatory**.

- Service label—Provides important information to identify your device. When contacting support, you will probably be asked for the serial number, IMEI number, and possibly for the product number or the model number. Locate these numbers before you contact support.
- Regulatory label(s)—Provide(s) regulatory information about the device.
- Wireless certification label(s)—Provide(s) information about optional wireless devices and the approval markings for the countries or regions in which the devices have been approved for use.

Installing nano SIM cards

Your device supports the following cards:

- Nano SIM card—Connects the device to a cellular or mobile data network, allowing you to use the calling and texting features on the device.
- Secondary nano SIM card (select products only)—Connects the device to a cellular or mobile data network. This card allows you to use a second phone number for the device's calling and texting features.

 **NOTE:** Your device also supports a microSD memory card, which provides external storage. Use this card with the Storage app; see [Using Storage on page 36](#) for more information. You cannot use a second nano SIM card at the same time you use a microSD memory card. Only one card can be installed in the second compartment at a time. You can switch the cards.

Inserting nano SIM cards

 **NOTE:** You can insert or remove a nano SIM card without turning off your device.

To insert a nano SIM card, follow these steps:


1. Place your fingernail in the small recess on the bottom of the card tray, pull out the tray **(1)**, and then remove it from the device.

 **NOTE:** The nano SIM card in your device may look different from the illustration in this section.

2. Insert the nano SIM card **(2)** into the primary compartment, the one closest to the device.

 **NOTE:** For select products, a second nano SIM card is supported. Continue to step 4 to install a second SIM card.


3. Replace the tray **(3)** in the device.



4. If your device supports a second nano SIM card, insert the nano SIM card **(1)** into the second compartment, and then replace the tray **(2)** in the device.



NOTE: Install the second nano SIM card in the same direction as the first card.



3 Expanding the display

Expand your viewing experience to a larger display using Continuum and the optional desk dock. You can also connect an optional keyboard and mouse.

 **NOTE:** You can use an HDMI-to-DVI cable (purchased separately) or an active DisplayPort-to-DVI cable (purchased separately) to connect the optional desk dock to your external display. An HDMI-to-VGA cable will work in most cases, but it will not work for video content.



Connecting using the desk dock

 **NOTE:** Additional adapters may be required. For information about the features and requirements of the desk dock, refer to the documentation provided with it.

 **NOTE:** Refer to the documentation provided with the accessories for installation instructions and pairing requirements.

1. Turn on your device.
2. Plug the desk dock into an AC power outlet.
3. Connect the optional monitor and adapter to the desk dock.
4. Connect any other wired options to the desk dock. For example, connect a USB keyboard.
5. Pair any wireless options to your device. For example, connect a Bluetooth® mouse.

6. Insert your device into the desk dock.



7. The Continuum instructions appear on the screen. Follow the instructions to continue.

Accessing Continuum

You can access the Continuum app without inserting your device into the desk dock.

1. On your device swipe left from the right edge of the Start screen to display all of the apps.
2. Tap **Continuum** , and then follow the on-screen instructions.

Opening an app on an external display

1. Select  in the desktop view of the external display.

The Start menu that opens will match your device's Start screen.



NOTE: If an app is dimmed on the external display, you cannot run it on Continuum's desktop view.

2. Select an app on the Start screen or apps menu.

Your device controls the external display as long as you stay in the Continuum app. If you want to use your device normally, go to any other view. The apps open in the desktop view stay open.



NOTE: Connect a mouse and keyboard through the desk dock to control the display with a mouse and keyboard. Using a mouse and keyboard allow you to perform tasks on your device while you perform other tasks on the external display.

Closing a window on an external display

Rest the pointer on the top-right corner of the external screen. When the **X** appears, select it to close the window.

Switch apps

Select the **Task view** icon  on the taskbar of the external screen.



NOTE: You can view only one app at a time. Use the **Task view** icon  to switch between open apps.

Using HP Workspace (select products only)

HP Workspace allows your device to access your legacy Windows applications on your device while docked. For added versatility, use the optional desk dock to connect to a large display, keyboard, and mouse.



NOTE: HP Workspace must be enabled by your IT administrator.

Accessing the HP Workspace app

1. Swipe left from the right edge of the Start screen to display all of the apps.
2. Tap **HP Workspace**, and then follow the on-screen instructions.

4 Network connections



NOTE: Contact your IT administrator for proxy settings, VPN configurations, or other network connection requirements.

Connecting to a wireless network

Your device may be equipped with one or more of the following wireless devices:

- **WLAN device**—Connects the device to wireless local area networks (commonly referred to as Wi-Fi networks, wireless LANs, or WLANs) in corporate offices, your home, and public places such as airports, restaurants, coffee shops, hotels, and universities. In a WLAN, the mobile wireless device in your device communicates with a wireless router or a wireless access point.
- **Mobile broadband module**—A wireless wide area network (WWAN) device that gives you wireless connectivity over a much larger area. Mobile network operators install base stations (similar to cell phone towers) throughout large geographic areas, effectively providing coverage across entire states, regions, or even countries.
- **Bluetooth device**—Creates a personal area network (PAN) to connect to other Bluetooth-enabled devices such as computers, phones, printers, headsets, speakers, and cameras. In a PAN, each device communicates directly with other devices, and devices must be relatively close together—typically within 10 meters (approximately 33 feet) of each other.

Using the network & wireless controls

The Network & wireless option allows you to set up a connection or network, connect to a network, create a mobile hotspot, and see your data usage.

To use network & wireless controls, follow these steps:

1. On your device, swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **Network & wireless**, and then select an option to continue.



NOTE: For additional help, refer to the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , and then tap **Get connected**.

Connecting to a WLAN



NOTE: When you are setting up Internet access in your home, you must establish an account with an Internet service provider (ISP). To purchase Internet service and a modem, contact a local ISP. The ISP will help set up the modem, install a network cable to connect your wireless router to the modem, and test the Internet service.

To connect to a WLAN, follow these steps:

1. Be sure that the WLAN device is on.
2. On your device, swipe down from the top of the screen, and then tap  **All settings**.

3. Tap **Network & wireless**.
4. Tap **Wi-Fi**.
5. Make sure **Wi-Fi networking** is set to **On**, and then connect to one of the available networks.

If the WLAN is a security-enabled WLAN, you are prompted to enter a password. Enter the password, and then tap **Done** to complete the connection.

 **NOTE:** If no WLANs are listed, you may be out of range of a wireless router or access point.

 **NOTE:** If you do not see the WLAN you want to connect to, tap **Manage**, tap **+**, and then follow the on-screen instructions to complete the connection.

After the connection is made, swipe down from the top of the screen, and then tap  to verify the name and status of the connection.

 **NOTE:** The functional range (how far your wireless signals travel) depends on WLAN implementation, router manufacturer, and interference from other electronic devices or structural barriers such as walls and floors.

Connecting to cellular networks

Your device supports a nano SIM card for connecting to cellular and data networks. Select products also support a second nano SIM card, which allows your device to have two different phone numbers. See [Installing nano SIM cards on page 10](#) for SIM card installation steps.

To access cellular and SIM settings:

1. Swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **Networks & wireless**, and then tap **Cellular & SIM**.
3. Follow the on-screen instructions.

 **NOTE:** For additional information, tap **Learn more**.

Using Bluetooth wireless devices

A Bluetooth device provides short-range wireless communications that replace the physical cable connections that traditionally link electronic devices such as the following:

- Computers (desktop, notebook)
- Phones (cellular, cordless, smartphone)
- Imaging devices (printer, camera)
- Audio devices (headset, speakers)
- Mouse
- External keyboard

Bluetooth devices provide peer-to-peer capability that allows you to set up a PAN of Bluetooth devices.

Connecting Bluetooth devices

Before you can use a Bluetooth device, you must establish a Bluetooth connection.

1. Be sure that the Bluetooth device is on.
2. On your device, swipe down from the top of the screen, and then tap  **All settings**.
3. Tap **Devices**.
4. Tap **Bluetooth**.
5. Make sure **Status** is set to **On**.
6. Select your Bluetooth device from the list, and then follow the on-screen instructions.

 **NOTE:** If the Bluetooth device requires verification, a pairing code is displayed. On the Bluetooth device you are adding, follow the on-screen instructions to verify that the code on your Bluetooth device matches the pairing code. For more information, refer to the documentation provided with the Bluetooth device.

 **NOTE:** If your Bluetooth device does not appear in the list, be sure that Bluetooth function on that Bluetooth device is turned on. Some Bluetooth devices may have additional requirements; refer to the documentation provided with the Bluetooth device.

Connecting to a wired network—LAN (select products only)

Use a LAN connection if you want to connect the device directly to a router in your home (instead of working wirelessly), or if you want to connect to an existing network at your office.

Connecting to a LAN requires an RJ-45 (network) cable and the optional desk dock.

For more information about the desk dock ports, refer to the documentation provided with the desk dock.

Contact your IT administrator for proxy settings or VPN configurations.

 **NOTE:** Support for LAN connections via proxy may require additional software. For more information, go to <http://www.hp.com/support>.

Sharing or paying wirelessly

NFC technology lets your device communicate with other devices that support NFC. With NFC and supported apps, you can wave the device over a display at a conference to view more information, tap devices with a coworker to share work products, or swipe your device to pay at a store.

To enable NFC on your device:

1. Swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **Devices**.
3. Tap **NFC**, and then follow the on-screen instructions to select **Tap to share** or **Tap to pay**.
4. Tap the NFC tapping area of your device to the NFC tapping area of another device.

 **NOTE:** For the location of the NFC tapping area on your device, see [Back on page 8](#).

5 Screen navigation

You can navigate the device screen in the following ways:

- Use touch gestures directly on the screen.
- Use an optional keyboard and optional mouse with the desk dock (purchased separately).

Using gestures

To navigate the screen, touch the screen directly using gestures described in this chapter.

Tap


Use the tap gesture to open an item on the screen.

- Tap an item to open it.



Swipe

Place your finger on the screen, quickly slide your finger a short distance, and then lift it.



Two-finger pinch zoom

Use the two-finger pinch zoom to zoom out or in on images or text.


- Zoom out by placing two fingers apart on the screen and then moving your fingers together.
- Zoom in by placing two fingers together on the screen and then moving your fingers apart.



One-finger slide

Use the one-finger slide to pan or scroll through lists and pages, or to move an object.

- To scroll across the screen, lightly slide one finger across the screen in the direction you want to move.
- To move an object, press and hold your finger on an object, and then drag your finger to move the object.



Using an optional keyboard and optional mouse

A keyboard and mouse allow you to type, select items, scroll and to perform the same functions as you do using touch gestures. A keyboard also allows you to use action keys and key combinations to perform specific functions.

For more information about connecting a keyboard or mouse, see [Expanding the display on page 12](#).

 **NOTE:** Depending on the country or region, your keyboard may have different keys and keyboard functions than those discussed in this section.

Using the on-screen keyboard

The device has an on-screen keyboard that is displayed as needed. Just begin typing when it is displayed.

To access settings for the on-screen keyboard, swipe down from the top of the screen, tap  **All settings**, and then tap **Time & language**. Tap **Keyboard**, and then follow the on-screen instructions to select the language and other settings for your keyboard.

 **NOTE:** Hot keys do not display or function on the on-screen keyboard.

 **NOTE:** Suggested words may be displayed at the top of the on-screen keyboard. Tap a word to select it.

Using the screen features

 **NOTE:** For additional information about the screen features, refer to the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , and then tap **Find your way around**.

Using the display

 **IMPORTANT:** Any time your screen turns off, press the power button, and then swipe up from the middle of the screen. Enter your PIN, if prompted to do so. If the screen does not turn on, connect your device to a power source. See [Using external AC power on page 34](#).

You can customize the device display. For example, you can choose what the lock screen displays and choose the amount of time before the device screen turns off.

Customizing the lock screen

1. Swipe down from the top of the screen, and tap  **All settings**.
2. Tap **Personalization**, and then tap **Lock screen**.
3. Make sure **My picture** displays in the **Background** selection box, and then tap **Browse**.
4. Select a photo, and then follow the on-screen instructions.

Setting the screen turn-off time

1. Swipe down from the top of the screen, and tap  **All settings**.
2. Tap **Personalization**, and then tap **Lock screen**.
3. Select a time from the **Screen times out after** selection box.

For additional information, refer to the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , tap **Make it yours**, and then follow the on-screen instructions.

Using the navigation bar

The navigation bar displays three keys across the bottom.

Key	Action
	Displays the previous screen.
	Displays the Start screen.
	Displays the search box, which allows you to begin typing the name of an app, setting, or file, or Internet topic.

Key	Action
	If your device has Cortana (select products only), tap and hold the microphone icon  , located under the search box, and say a search word.

 **NOTE:** To hide the navigation bar from the Start screen, swipe up from the navigation bar area. To see the navigation bar again, swipe up from the bottom of the screen.

Viewing the status bar

The status bar at the top of the screen displays information about the wireless connections, SIM card status, battery life, and the time.

Your icons may vary, but some of the common icons are shown in the following table. For a complete list, refer to the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , tap **Find your way around**, and then tap **Icons on your phone**.

Icon	Status
	Your device has no mobile network connection.
	No SIM card is installed in the primary compartment of the card tray. If your device supports a second SIM card and the second tray compartment is empty, the numeral on the icon will be 2.
	Airplane mode is on.
	Your device is connected to Wi-Fi.
	A Bluetooth device is connected to your device.
	The battery is fully charged.
	An app or service is using your location.

Checking notifications, changing settings, and accessing shortcuts

The action center displays notifications, such as missed calls or texts, and provides quick access to settings and other shortcuts.



NOTE: The action center can be accessed from a locked screen. However, you will be prompted to unlock the screen for certain actions.

1. Swipe down from the top of the screen to display the action center.
2. To display additional shortcuts, tap **Expand**.

To close the action center, swipe up from the middle of the screen.

6 Using the voice calling and texting features

Icon	Description
	Make a call —Tap  on the Start screen, and then tap  . Tap the keys to enter the phone number, and then tap  . — or — Tap People on the Start screen, tap a contact name, and then tap Call .
	Answer a call —Tap  .
	End a call —Tap  .
	Check voicemail —Tap  on the Start screen, and then tap  .
	Return a recent call —Tap  on the Start screen, and then tap a recent call to return it.
	Ignore a call —Tap  to ignore a call.
	Text a message —Tap  on the Start screen, and then tap  . Enter the name of a contact to text or enter a number to text, and then tap the Type a message field to start a new text message.
	Contacts —Allows you to store information for frequently contacted people. Swipe left from the right edge of the Start screen to display all apps, tap  People , and then tap  to add a contact.



NOTE: For additional calling and texting information, see the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , and then tap **Calling and messaging**.

7 Adding apps

Use the Store app to download additional apps to your device.

1. Swipe left from the right edge of the Start screen to display all apps.
2. Tap **Store**, and then tap  at the top of the screen.
3. Tap the search field, type your search term, and then tap .
4. Follow the on-screen instructions.

8 Using email and social networks

 **NOTE:** For additional information about emails and social media accounts, see the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , and then tap **Set things up**.

Setting up email accounts

1. Swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **Accounts**.
3. Tap **Your email and accounts**, and then follow the on-screen instructions.

Setting up a social media account

 **NOTE:** Use the Store app to download social networking apps. See [Adding apps on page 24](#).

1. Swipe left from the right edge of the Start screen to display all apps.
2. Tap the social networking app you want, and then follow the on-screen instructions.

Sending email

Tap **Outlook Mail** on the Start screen, and then follow the on-screen instructions.

9 Printing using HP All-in-One Remote

The HP All-in-One Remote app provides an easy way to set up and access all features of your optional HP printer. Use the app to print Portable Document Format (PDF) documents, photos, and scanned documents.

1. Swipe left from the right edge of the Start screen to display all apps.
2. Tap **HP All-in-One Remote**, and then follow the on-screen instructions.

10 Entertainment features

Use your HP device for work or play to meet with others via the camera, mix audio and video, or connect external devices like speakers. See [Components on page 4](#) to locate the audio, video, and camera features on your device.

Using the camera

Your device has a camera that allows you to video chat, record video, and take pictures.

▲ To access the camera, tap  on the Start screen.



Component		Description
(1)		Switch cameras Tap to switch to the front camera. Tap the icon again to return to the back camera.
(2)		Flash Tap to change the flash settings.
(3)		HDR Tap to access the High Dynamic Range (HDR) camera setting. When the HDR setting is on, the camera takes several photos at different exposures to create a finished picture that uses a balance of these photos. The finished

Component	Description
	picture will be the most focused, well-lit, and colorful parts of the photos.
(4)  Options	Tap to access additional options. These include settings for white balance (WB), auto-focus, ISO, shutter, and brightness. When video mode is enabled, you can also access the flashlight option.
(5)  Camera	Tap to take a picture.
(6)  Video	Tap to switch to video mode. Tap again to record a video. To stop recording, tap again.
(7)  Settings	Tap to select different lenses, set the photo timer, set the number of photos and exposure for HDR pictures, and further customize your photos and videos.

 **NOTE:** For additional camera information, see the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , and then tap **Photos**.

Using audio

You can download and listen to music, stream audio content (including radio) from the web, record audio, or mix audio and video to create multimedia. To enhance your listening enjoyment, attach headphones or speakers.

Connecting speakers

You can attach wired speakers to your device by connecting them to the audio-out (headphone)/audio-in (microphone) combo jack on your device or to a port on a desk dock.

To connect wireless speakers to your device, follow the device manufacturer's instructions. Before connecting speakers, lower the volume setting.

Connecting headphones

 **WARNING!** To reduce the risk of personal injury, lower the volume setting before putting on headphones, earbuds, or a headset. For additional safety information, see the *Regulatory, Safety and Environmental Notices*.

To access this document:

1. Swipe up from the middle of the Start screen.
2. Tap  **HP Device Hub**, and then tap **User Guide**.
3. Select your language if prompted to do so.
4. Tap **Regulatory, Safety and Environmental Notices**.

 **IMPORTANT:** You must be connected to the Internet to access the latest version of the document.

You can connect wired headphones to the headphone jack or to the audio-out (headphone)/audio-in (microphone) combo jack on your device.

To connect wireless headphones to your device, follow the headphone manufacturer's instructions.

Connecting headsets

 **WARNING!** To reduce the risk of personal injury, lower the volume setting before putting on headphones, earbuds, or a headset. For additional safety information, see the *Regulatory, Safety and Environmental Notices*.

To access this document:

1. Swipe up from the middle of the Start screen.
2. Tap  **HP Device Hub**, and then tap **User Guide**.
3. Select your language if prompted to do so.
4. Tap **Regulatory, Safety and Environmental Notices**.

 **IMPORTANT:** You must be connected to the Internet to access the latest version of the document.

Headphones combined with a microphone are called headsets. Select products include a headset with the device. You can connect wired headsets to the audio-out (headphone)/audio-in (microphone) combo jack on your device.

To connect wireless headsets to your device, follow the instructions provided with the headset.

Changing the volume

Use the external volume buttons to adjust the volume. For the location of the buttons, see [Front on page 5](#).

To change the volume for the ringer and notifications:

1. Press a volume button to display the volume status bar.
2. Use the slider on the volume status bar or use volume buttons to change the volume.

To change the volume for media and apps:

1. Press a volume button to display the volume status bar.
2. Tap **V**.
3. Use the slider on the volume status bar or use volume buttons to change the volume.

For additional information about audio, see the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , and then tap **Make it yours**.

Using sound settings

Use sound settings to change system sounds.

To view or change sound settings:

1. Swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **Personalization**, and then tap **Sounds**.

Using video

Your device is a powerful video device that enables you to watch streaming video from your favorite websites and download video to watch on your device when you are not connected to a network.

To enhance your viewing enjoyment, use the USB Type-C port on the device or one of the ports on the desk dock to connect an external monitor. For more information about the ports supported by the desk dock, see the documentation provided with the desk dock.



IMPORTANT: Be sure that the external device is connected to the correct port, using the correct cable. Follow the device manufacturer's instructions.

The following video formats adapters are supported:

- VGA
- HDMI
- DisplayPort

See [Expanding the display on page 12](#) for information about connecting the device to an external display.

11 Power management

Turning off the device

The turn off procedure closes all open programs, including the operating system, and then turns off the display and device.

Turn off the device when it will be unused and disconnected from external power for an extended period.

1. Save your work and close all open programs.
2. Press and hold the power button until the **slide down to power off** message appears. Release the power button, and then swipe down on the screen to turn off the device.

If the device is unresponsive and you are unable to use the preceding procedure, try the following emergency procedures in the sequence provided:

- Press and hold the power button for at least 5 seconds.
- Disconnect the device from external power.

Setting power options

Using power-saving states

Initiating and exiting screen off

When the device is on, you can turn the screen off by briefly pressing the power button.

To turn the screen back on, briefly press the power button.

When the screen turns back on, the lock screen appears. Swipe up from the middle of the screen to return to the screen where you stopped working.



NOTE: If you have set an unlock PIN, you must enter the PIN before the device will return to the screen.

Using the battery saver

Battery saver allows you to quickly access power settings and view the remaining battery charge.

1. Swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **System**.
3. Tap **Battery saver**.
4. Follow the on-screen instructions to view the remaining battery charge, select battery use settings, or select battery saver settings.

Using battery power

The device runs on battery power whenever it is not plugged into external AC power. Battery life varies, depending on power management settings, running programs, display brightness, external devices connected to the device, and other factors.

Displaying the remaining battery charge

The power meter icon  at the top right corner of the screen provides a visual representation of the remaining battery charge.

To display more specific details on the percentage and estimated battery time available, use the battery saver. See [Using the battery saver on page 31](#).

Maximizing battery discharge time

Battery discharge time varies depending on features you use while on battery power. Maximum discharge time gradually decreases as the battery storage capacity naturally degrades.

Tips for maximizing battery discharge time:

- Turn on the battery saver. Swipe down from the top of the screen, tap **Expand**, and then tap **Battery saver**. The battery level icon at the top right of the screen changes to show the battery saver icon. For information about additional battery saver settings, see [Using the battery saver on page 31](#).
- Lower the brightness on the display.
- Turn off any wireless options you are not using, such as Bluetooth.

Managing low battery levels

The information in this section describes the alerts and system responses set at the factory.

Identifying low battery levels

When a battery that is the sole power source for the device reaches a low or critical battery level, the battery icon  shows a low or critical battery notification.

Resolving a low battery level

Resolving a low battery level when external power is available

- ▲ Connect one of the following devices:
 - AC adapter
 - Optional desk dock, see [Expanding the display on page 12](#)
 - Optional wireless charging pad, see [Using wireless charging on page 33](#)
 - Optional power adapter purchased as an accessory from HP

Resolving a low battery level when no power source is available

To resolve a low battery level when no power source is available, save your work and then turn off the device.

Conserving battery power

- Select the battery saver, see [Using the battery saver on page 31](#).
- Turn off wireless connections when you are not using them.
- Disconnect unused external devices that are not plugged into an external power source.
- Stop, disable, or remove any external memory cards that you are not using.

- Decrease screen brightness.
- Before you leave your work, lock the device, or turn off the device.

Disposing of a battery

⚠ WARNING! To reduce the risk of fire or burns, do not disassemble, crush, or puncture; do not short external contacts; do not dispose of in fire or water.

See the *Regulatory, Safety and Environmental Notices* for proper battery disposal.

To access this document:

1. Swipe up from the middle of the Start screen.
2. Tap  **HP Device Hub**, and then tap **User Guide**.
3. Select your language if prompted to do so, and then tap **Regulatory, Safety and Environmental Notices**.

Using wireless charging

📝 NOTE: For more information about the wireless charging pad, refer to the documentation provided with it.

Using the wireless charging pad (purchased separately), you can charge your device by placing the wireless charging area of your device on the pad.



Using external AC power

 **WARNING!** To reduce potential safety issues, use only the AC adapter provided with the device, an optional desk dock, an optional wireless charger, a replacement AC adapter provided by HP, or a compatible AC adapter purchased from HP.

 **NOTE:** For information on connecting to AC power, see the *Quick Start* guide provided in the device box.

External AC power is supplied through an approved AC adapter, an optional desk dock, or an optional wireless charger.

Connect the device to external AC power under any of the following conditions:

- When charging the battery
- When installing or modifying system software
- When performing a backup or recovery

When you connect the device to external AC power, the following events occur:

- The battery begins to charge.
- The device turns on.
- The power meter icon in the status area changes appearance.

When you disconnect external AC power, the following events occur:

- The device switches to battery power.
- The power meter icon in the status area changes appearance.

Testing an AC adapter

Test the AC adapter if the device does not turn on when it is connected to AC power.

To test the AC adapter:

1. Connect the AC adapter to the device, and then plug it into an AC outlet.
2. Monitor the device for one of the following statuses:
 - If the power status light turns *on*, the AC adapter is working properly.
 - If the device turns *on*, the AC adapter is working properly.
 - If the power light remains *off* and the device remains *off*, the AC adapter is not functioning and should be replaced.

Contact support for information on obtaining a replacement AC power adapter.

12 Sharing and backing up your data

HP strongly encourages you to periodically back up the personal data on your device. You have several options available, including OneDrive and microSD memory cards. These options also allow you to share your data with others.

Using OneDrive

Use OneDrive to back up and store documents, photos, and videos. You can share these with other devices. In addition, you can restore your files from OneDrive back to your device.

 **NOTE:** OneDrive requires a Microsoft account. See [Using a Microsoft account on page 38](#).

1. Swipe left from the right edge of the Start screen to display all apps.
2. Tap  **OneDrive**.
3. Follow the on-screen instructions.

Using a microSD memory card

Optional microSD memory cards provide secure data storage for backups and convenient data sharing.

Your device has read/write support for microSD memory cards up to 2 TB.

 **NOTE:** Select devices also support a second nano SIM card. See [Installing nano SIM cards on page 10](#) for more information. You cannot use a second nano SIM card at the same time you use a microSD memory card. Only one card can be installed in the second compartment at a time. You can switch the cards.

Inserting a microSD memory card


 **NOTE:** You can insert or remove a microSD memory card without turning off your device.

To insert a microSD card, follow these steps:

1. Place your fingernail in the small recess on the bottom of the card tray, and then pull out the tray **(1)** to remove it from the device.

 **NOTE:** The microSD memory card in your device may look different from the illustration in this section.

2. Insert a microSD memory card **(2)**, and then replace the card tray **(3)** in the device.



Using Storage

You can use a microSD memory card to back up and restore your data in case of loss. You can also move files, pictures, videos, or apps to the card to free up device memory.

To set storage preferences, back up or restore your data, or move device data to a microSD memory card:

1. Swipe left from the right edge of the Start screen to display all apps.
2. Tap  **Storage**.

Determining storage space

The HP Device Hub app provides information about how much storage space is available on the device. To access that information:

1. Swipe up from the middle of the Start screen.
2. Tap  **HP Device Hub**.

The available space is displayed in the **Device Summary**.

Using Backup

The Backup option provides a way to back up content such as settings, texts, contacts, accounts, and passwords. In addition, you can schedule automatic backups and select which apps to back up.

 **NOTE:** Backup requires a Microsoft account. See [Using a Microsoft account on page 38](#).

To use Backup:

1. Swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **Update & security**.
3. Tap **Backup**, and then follow the on-screen instructions.

 **NOTE:** If a downloaded app is not included in the backup, you can re-download the app from the Store, if the app is still available. See [Adding apps on page 24](#).

Restoring or resetting your device

 **IMPORTANT:** Make sure you remember your Microsoft account information. You will need that if you want to restore your device after you reset it. For information about creating a Microsoft account, see [Using a Microsoft account on page 38](#).

 **NOTE:** Be sure to back up any data you want to save before resetting your device. Resetting restores the device's factory settings and erases all of your personal content. You can restore your backed up data after signing in to your Microsoft account.

To reset all settings and delete all data on the device follow these steps:

1. Swipe down from the top of the screen, and then tap  **All settings**, and then tap **System**.
2. Tap **About**, and then tap **Reset your phone**.
3. Follow the on-screen instructions.

13 Security

There are several options for securely unlocking your device. After an unlock PIN is set, you can also set up access using Windows Hello and the iris camera or the fingerprint reader. For the location of the iris camera or fingerprint reader, see [Components on page 4](#).

Setting PIN protection

To set the device to prompt for a PIN on the lock screen, follow these steps:

1. Swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **Personalization**.
3. Tap **Lock screen**.
4. Tap **Sign-in options**.
5. Follow the on-screen instructions to set a PIN.

Using Windows Hello

On products equipped with a fingerprint reader or an iris camera, you can use Windows Hello to sign in by swiping your finger or looking at the camera.

 **NOTE:** Additional software may be required to use the fingerprint reader. For more information, go to <http://www.hp.com/support>.

 **NOTE:** Before you use Windows Hello, you must set an unlock PIN.

To set up Windows Hello, follow these steps:

1. Swipe left from the right edge of the Start screen to display all of the apps.
2. Tap **Windows Hello**, and then follow the on-screen instructions to enroll your fingerprint or iris.

For additional information about Windows Hello, see the Get Started app; this app requires an Internet connection. Swipe left from the right edge of the Start screen to display all apps, and then tap **Get Started**. Tap , and then tap **Windows Hello**.

Using a Microsoft account

If you already have a Microsoft account, you do not have to create a new one. You can sign in using that user name and password. You will need a Microsoft account to create backups and to restore your device after you reset it. To create a Microsoft account using your device, use the following steps:

1. Swipe down from the top of the screen, and then tap  **All settings**.
2. Tap **Accounts**, and then tap **Your email and accounts**.
3. Tap **Sign in with a Microsoft account instead**, and then tap **Create one**.
4. Follow the on-screen instructions.

Locking and unlocking the screen

Locking the screen

To lock the screen, press the power button. See [Front on page 5](#) for the location of the power button.

Unlocking the screen

To unlock the screen, press the power button. See [Front on page 5](#) for the location of the power button.

If you have set authentication using a PIN, fingerprint reader, or iris scan, you will be prompted for that. See [Using Windows Hello on page 38](#) for information about setting up a fingerprint reader lock or iris recognition.

14 Maintenance

It is important to perform regular maintenance to keep your device in optimal condition. This chapter provides instructions for updating the operating system and apps, steps to clean the device, and tips for shipping the device.

Updating the operating system and apps

HP recommends that you update your operating system and apps on a regular basis. Updates can resolve issues and bring new features and options to your device.

Go to <http://www.hp.com/support> to check for the latest product information and user guides.

Updating the operating system

- ▲ Swipe up from the middle of the Start screen, tap  **HP Device Hub**, tap **Update to the latest OS**, and then follow the on-screen instructions.

Updating apps

1. Tap **Store** on the Start screen.
2. Tap , and then tap **Downloads and updates**.
3. Tap **Check for updates**, and then follow the on-screen instructions.

Registering your device

If you did not choose to register your device during the initial setup, you can use the HP OOB app to register later. The HP OOB app provides a way to activate your warranty, register your device, and provide your consent for HP terms and conditions, data collection, and updates.

To access the HP OOB app:

1. Swipe left from the right edge of the Start screen to display all apps.
2. Tap **HP OOB**, and then follow the on-screen instructions.

Diagnostics

The HP Mobile Hardware Diagnostic app provides a way to test the hardware components and memory on your device to verify they are functioning properly. Alerts providing recovery information are displayed for any disabled item. Follow the alert details to resolve any issues.

To access diagnostics:

1. Swipe up from the middle of the Start screen.
2. Tap  **HP Device Hub**.
3. Tap **HP Mobile Hardware Diagnostics**, and then follow the on-screen instructions.

Cleaning your device

Use the following products to safely clean your device:

- Dimethyl benzyl ammonium chloride 0.3 percent maximum concentration (for example, disposable wipes, which come in a variety of brands)
- Alcohol-free glass-cleaning fluid
- Solution of water and mild soap
- Dry microfiber cleaning cloth or a chamois (static-free cloth without oil)
- Static-free cloth wipes

 **CAUTION:** Avoid strong cleaning solvents that can permanently damage your device. If you are not sure that a cleaning product is safe for your device, check the product contents to make sure that ingredients such as alcohol, acetone, ammonium chloride, methylene chloride, and hydrocarbons are not included in the product.

Fibrous materials, such as paper towels, can scratch the device. Over time, dirt particles and cleaning agents can get trapped in the scratches.

Cleaning procedures

Follow the procedures in this section to safely clean your device.

 **WARNING!** To prevent electric shock or damage to components, do not attempt to clean your device while it is on.

1. Turn off the device.
2. Disconnect AC power.
3. Disconnect all powered external devices.

 **CAUTION:** To prevent damage to internal components, do not spray cleaning agents or liquids directly on any device surface. Liquids dripped on the surface can permanently damage internal components.

Cleaning the display

Gently wipe the display using a soft, lint-free cloth moistened with an alcohol-free glass cleaner.

Cleaning the sides

To clean the sides, use a soft microfiber cloth or chamois moistened with one of the cleaning solutions listed previously, or use an acceptable disposable wipe.

 **NOTE:** When cleaning the device, use a circular motion to aid in removing dirt and debris.

Shipping your device

If you have to ship your device, follow these tips to keep your equipment safe.

- Prepare the device for shipping:
 - Back up your information to an external card or OneDrive.
 - Remove all external media cards, such as memory cards.

- Turn off and then disconnect all external devices.
- Turn off the device.
- When traveling by air, carry the device as hand luggage; do not check it in with the rest of your luggage.
- If you plan to use the device during a flight, listen for the in-flight announcement that tells you when you are allowed to use your device. In-flight use is at the discretion of the airline.
- If you are shipping the device, use suitable protective packaging and label the package “FRAGILE.”
- The use of wireless devices may be restricted in some environments. Such restrictions may apply aboard aircraft, in hospitals, near explosives, and in hazardous locations. If you are uncertain of the policy that applies to the use of a wireless device in your device, ask for authorization to use your device before you turn it on.
- If you are traveling internationally, follow these suggestions:
 - Check the computer-related customs regulations for each country or region on your itinerary.
 - Check the power cord and adapter requirements for each location in which you plan to use the device. Voltage, frequency, and plug configurations vary.

 **WARNING!** To reduce the risk of electric shock, fire, or damage to the equipment, do not attempt to power the device with a voltage converter kit sold for appliances.

15 Accessibility

HP designs, produces, and markets products and services that can be used by everyone, including people with disabilities, either on a stand-alone basis or with appropriate assistive devices.

Supported assistive technologies

HP products support a wide variety of operating system assistive technologies and can be configured to work with additional assistive technologies. Use the Search feature on your device to locate more information about assistive features.



NOTE: For additional information about a particular assistive technology product, contact customer support for that product.

Contacting support

We are constantly refining the accessibility of our products and services and welcome feedback from users. If you have an issue with a product or would like to tell us about accessibility features that have helped you, please contact us at +1 (888) 259-5707, Monday through Friday, 6 a.m. to 9 p.m. North American Mountain Time. If you are deaf or hard-of-hearing and use TRS/VRS/WebCapTel, contact us if you require technical support or have accessibility questions by calling +1 (877) 656-7058, Monday through Friday, 6 a.m. to 9 p.m. North American Mountain Time.



NOTE: Support is in English only.

Index

- A**
 - AC adapter, testing 34
 - accessibility 43
 - ambient light sensor, identifying 6
 - audio-out (headphone)/audio-in (microphone) combo jack
 - identifying 6
- B**
 - back key 20
 - backup 35
 - battery
 - conserving power 32
 - discharging 32
 - displaying remaining charge 32
 - disposing 33
 - low battery levels 32
 - battery power 31
 - battery saver 31
 - Bluetooth device 15, 16
 - Bluetooth label 10
 - bottom 10
 - button
 - power 6
 - volume down 7
 - volume up 7
- C**
 - camera
 - identifying 8
 - using 27
 - camera, identifying 6
 - cameras, identifying 6
 - caring for your device 41
 - cleaning your device 41
 - components
 - back 8
 - front 5
 - connecting to a WLAN 15
 - conservation, power 32
 - Continuum 12
 - corporate WLAN connection 15
- D**
 - desk dock 12
 - desk dock, connecting 12
 - diagnostics 40
- E**
 - earpiece, identifying 6
 - external AC power, using 34
- F**
 - factory data reset 35
 - fingerprint reader, identifying 9
 - fingerprints, registering 38
 - flashlight
 - identifying 8
- G**
 - gestures
 - using 18
- H**
 - headphones, connecting 28
 - headsets, connecting 29
 - HP Mobile Hardware Diagnostics 40
 - HP resources 2
 - HP Workspace app 14
- I**
 - internal microphone, identifying 7
 - Iris camera, identifying 6
- J**
 - jacks
 - audio-out (headphone)/audio-in (microphone) combo 6
- K**
 - keyboard and mouse
 - using 19
 - keyboard, on-screen 19
- L**
 - labels
 - Bluetooth 10
 - regulatory 10
 - serial number 10
 - service 10
 - wireless certification 10
 - WLAN 10
- lights
 - status 6
- Limited Warranty, accessing 2
- locating information
 - hardware 4
 - help 4
 - software 4
- low battery level 32
- M**
 - maintenance
 - tasks 40
 - updating the operating system and apps 40
 - microSD card reader, identifying 7
 - microSD card size 7
 - microSD memory card
 - inserting 35
 - supported formats 35
 - Microsoft account, creating 38
- N**
 - nano SIM card
 - installing 10
 - navigation bar 20
 - NFC
 - using 17
 - NFC tapping area, identifying 9
- O**
 - one-finger slide touch screen
 - gesture 19
 - OneDrive 35
- P**
 - PIN, setting 38
 - Pogo pin connector, identifying 9
 - ports
 - USB Type-C charging 7
 - power
 - battery 31
 - conserving 32
 - options 31

- power button, identifying 6
- power off the device 31
- power-saving states 31
- product name and number, device 10
- public WLAN connection 15

R

- registration 40
- regulatory information
 - regulatory label 10
 - wireless certification labels 10
- Regulatory, Safety and Environmental Notices, accessing 2
- reset 37

S

- Safety & Comfort Guide, accessing 2
- screen off
 - exiting 31
 - initiating 31
- screen, turning on 20
- search key 20
- searching 4
- security 38
- serial number 10
- serial number, device 10
- service labels, locating 10
- setting PIN protection 38
- setting power options 31
- shipping the device 41
- shutdown 31
- sign-in options 38
- SIM card
 - inserting 7
 - removing 7
- SIM card slot, identifying 7
- SIM cards, installing 10
- slots
 - microSD card reader 7
 - SIM card 7
- sound settings, using 29
- speakers
 - connecting 28
- speakers, identifying 7
- status bar 21
- status light 6
- switch apps 14

T

- tap screen gesture 18
- testing an AC adapter 34
- texting 23
- touch gestures
 - swipe 18
 - tap 18
 - two-finger pinch zoom 19
- touch screen gestures
 - one-finger slide 19
- traveling with the device 10
- turning off the device 31
- two-finger pinch zoom touch screen gesture 19

U

- unresponsive system 31
- updating the operating system and apps 40
- USB Type-C charging port, identifying 7
- using
 - external AC power 34
 - power-saving states 31
- using gestures 18
- using sound settings 29
- using the keyboard and mouse 19

V

- video 30
- voice calling 23
- volume button, identifying 7

W

- window, closing on external display 14
- Windows Hello
 - using 38
- Windows key 20
- wireless antennas, identifying 8
- wireless certification label 10
- wireless charging area, identifying 9
- wireless controls
 - operating system 15
- wireless network (WLAN)
 - connecting 15
 - corporate WLAN connection 15
 - functional range 16
 - public WLAN connection 15
- WLAN antennas, identifying 8

- WLAN device 10
- WLAN label 10
- WWAN antennas, identifying 8
- WWAN device 15