

HP iPAQ

Product Information Guide



© 2006 Hewlett-Packard Development Company, L.P.

Microsoft, Windows, the Windows logo, Outlook, and ActiveSync are trademarks of Microsoft Corporation in the U.S. and other countries.

HP iPAQ Products are Powered by Microsoft® Windows Mobile™ 5.0 software for Pocket PC.



SD Logo is a trademark of its proprietor.

Bluetooth® is a trademark owned by its proprietor and used by Hewlett-Packard Development Company, L.P. under license.

All other product names mentioned herein may be trademarks of their respective companies.

Hewlett-Packard Company shall not be liable for technical or editorial errors or omissions contained herein. The information is provided "as is" without warranty of any kind and is subject to change without notice. The warranties for Hewlett-Packard products are set forth in the express limited warranty statements accompanying such products. Nothing herein should be construed as an additional warranty.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Development Company, L.P.

HP iPAQ Product Information Guide

First Edition (September 2006)

Table of contents

HP iPAQ Product Information Guide

Welcome	1
Box Contents	2
Components	3
Top Components	3
Front Components	4
Back Components	5
Left and Right Side Components	6
Getting Started CD Contents	7
Navigation Quick Start	8
Installing the Battery	8
Powering On and Setting Up	10
HP Quick Launch	10
Navigation Setup	11
Car Kit Setup	12
Using TomTom Navigator 6	15
Navigating to Destinations	15
Menus	15
Saving Destinations	16
Preferences	16
Points of Interest (POI)	17
TomTom Plus	17
Travel Tools	18
WorldMate Standard Edition	18
Organizer Features	18
Continuing Setup	18
Setting Up the Travel Companion	18
Finding the Serial Number and Model Number	22
Protecting Your HP iPAQ with a Password	22
Today Screen	23
Status Icons	23
iPAQ Wireless	24
Checking the Battery Charge Level	25
Battery Saving Tips	25
Entering Text	25
Entering Text Using Block Recognizer	26
Entering Text Using the On-screen Keyboard	26
Entering Text Using Letter Recognizer	27
Writing with Transcriber	27
Resetting Your HP iPAQ	27

Performing a Soft Reset	27
Performing a Factory Reset	28
Entertainment	28
Windows Media Player 10 Mobile	28
Listening to Music and Watching Videos	29
Clearing the Now Playing List	29
Updating a Library	29
HP Photosmart Mobile	29
Attaching a Voice Note to a Picture	30
E-mailing Pictures	30
Viewing a Slideshow	30
Mobile Office	31
Calendar	31
Accessing Calendar	31
Viewing Today's Agenda	31
Viewing Appointments	32
Scheduling an Appointment	32
Sending a Meeting Request	32
Contacts	33
Accessing Contacts	33
Creating a Contact	33
Finding a Contact	34
Tasks	34
Creating a Task	34
Locating a Task	34
E-mail	35
Different Ways to Access E-mail Messages	35
Setting up an E-mail Account on an Exchange Server	35
Setting up a POP3, HTTP, or IMAP4 E-mail Account	36
Composing and Sending Outlook E-mail Messages	37
Replying to or Forwarding an Outlook E-mail Message	37
Sorting the Message List	37
Internet Explorer Mobile	37
Word Mobile	38
Excel Mobile	38
PowerPoint Mobile	38
WLAN	39
Turning WLAN On or Off	39
Searching for WLAN Networks to Access	40
Configuring Network Security Settings	40
Bluetooth	40
Turning Bluetooth On or Off	41
Connecting to a Bluetooth Headset	41
Protecting the HP iPAQ Screen from Cracking or Damage	41
Obtaining Services for a Cracked or Damaged Screen	42
Additional Guidelines for Using Your HP iPAQ	42
Frequently Asked Questions	42
Finding More Information	43

Index	45
--------------------	-----------

HP iPAQ Product Information Guide



CAUTION Text set off in this manner indicates that failure to follow directions could result in damage to equipment or loss of information.

Welcome

Thank you for purchasing the HP iPAQ Travel Companion. This guide has been designed to help you begin using your device quickly. For more detailed information, please refer to the Finding More Information section. In this guide you will learn how to:

- Use the travel-related functionality of the Travel Companion, including the built-in Global Positioning System (GPS) and WorldMate travel assistant.
- Set the Travel Companion to synchronize digital media and personal information such as Calendar, Contacts, and E-mail with a personal computer.
- Protect the Travel Companion from unintended damage by showing how to properly replace the battery cover on the device and by providing important information about protecting the device screen.
- Improve the device battery life, allowing for longer use between charges.
- Perform a soft reset or a factory reset to adjust device performance.
- Troubleshoot common device issues, including synchronizing.
- Use the on-screen keyboard, function keys, Calendar, Contacts, and Tasks.
- Use messaging, WLAN*, and Bluetooth.


*WLAN is available on rx5900 series models only.

Box Contents

This illustration depicts the items that come in the box with the Travel Companion. Use this illustration to become more familiar with the device.



NOTE Box contents vary by model.



Box Contents


- | | |
|------|---|
| (1) | HP iPAQ |
| (2) | Case |
| (3) | Mini-USB synchronization cable/power cable (2 ea) |
| (4) | HP iPAQ Documentation |
| (5) | Stylus |
| (6) | 1,700mAh li-ion removable/rechargeable battery |
| (7) | Getting Started CD with special software |
| (8) | AC adapter with interchangeable plug |
| (9) | Car kit — holder |
| (10) | Car kit — Travel power adapter |
| (11) | Car kit — windshield mounting bracket |

Components




NOTE Not all models or features are available in all regions.

Top Components




Component	Function
(1) Reset Button	Press to perform a soft reset of the Travel Companion.
(2) Record Button	Press to record voice or sound.
(3) SD Slot	Insert a Secure Digital (SD) storage card for data storage or a Secure Digital Input/Output card (SDIO) card to extend the functionality of the Travel Companion.

Front Components




Component	Function
(1) Start Menu Button	Press to open the Start menu.
(2) OK Button	Press to close the current window or exit the current application.
(3) 9-Way Navigation Button	- When in Standard mode: - Top — Scroll up - Bottom — Scroll down - Left — Scroll left - Right — Scroll right - When using GPS: - Top — Zoom in - Bottom — Zoom out - Left — Volume down - Right — Volume up

Back Components



Component	Function
(1) Speaker	Use the speaker to get spoken navigation instructions.
(2) Battery Cover Release Button	Press to remove the battery cover.
(3) Battery Cover	Remove to install or remove the battery.
(4) Stylus	Use to input information. Slide out to remove the stylus. Slide in to replace the stylus.

Left and Right Side Components



Component	Function
(1) MMCX External Antenna Port	Connects to 3V active external GPS antenna.
(2) Charging/Communications Port	Connects to mini-USB synchronization cable.
(3) Headset Connector	Plug a headset into this connector to listen to music.
(4) Stylus	Use to input information. Slide out to remove the stylus. Slide in to replace the stylus.
(5) Internal WLAN Antenna*	Allows connection to wireless networks. (rx5900 series models only)
(6) Microphone	Speak into the microphone to record voice notes.
(7) Quick Launch Button	Press to access the HP Quick Launch screen. Press and hold to launch Calendar.
(8) Navigation Button	Press to launch GPS navigation. Press and hold to launch Contacts.
(9) Windows Media Player Button	Press to launch Windows Media Player. Press and hold to launch Pocket Internet Explorer.
(10) Rotate Screen Button	Press to rotate the screen to portrait or landscape orientation. Press and hold to launch Photosmart Mobile.
(11) Wireless LED	- Blue LED—WLAN*, Bluetooth, or GPS is on. - LED off—WLAN*, Bluetooth, or GPS is off. *WLAN is available on rx5900 series models only.

	Component	Function
(12)	Internal Bluetooth Antenna	Allows connection to other Bluetooth devices.
(13)	Power Button and LED	Press to turn the unit on and off. • Solid amber light — Battery is charging • Solid green light — Battery is fully charged • Flashing amber light — Reminder or alarm

Getting Started CD Contents

The *Getting Started* CD includes:

- Microsoft ActiveSync 4.1 or later
- Microsoft Outlook 2002
- *Additional Product Information*
- *Important Safety Information*
- **WorldMate Active Sync Plug-in**
- **HP Photosmart Premier**
- Additional software for the Travel Companion and personal computer

All software and documents are designed to be installed on a personal computer to enable use of the Travel Companion to its full potential.



NOTE All current Microsoft operating systems are supported by ActiveSync 4.1, except Windows 98SE and Windows ME.

Navigation Quick Start

The Travel Companion can be used as a GPS navigation system right out of the box. The sections that follow provide instruction to prepare and use the Travel Companion immediately after purchase.




CAUTION Drive with due care and attention when using the Travel Companion for navigation.

Installing the Battery


The battery provides power for the Travel Companion to operate. The Travel Companion comes with a mini-USB synchronization cable, which you must use with a power adapter to charge the device.

To install the battery:


1. Turn the Travel Companion over so you can see the back battery cover.
2. Press the battery release button (1).
3. Slide the battery compartment cover down about 1/2 inch, and then lift the cover off the Travel Companion (2).



4. Insert the battery into the compartment (1) so that the connectors on the battery mate with the pins in the battery compartment, and then press down until the battery locks into place (2). As you insert the battery, be sure to pull the battery removal tab out so it is on the outside of the battery.



5. Replace the cover by first laying the cover on the battery compartment opening, aligning the tabs, and then sliding the cover until it locks into place.




Do not attempt to insert the battery cover tabs into the compartment slots without first placing the cover onto the compartment and sliding it closed.



Powering On and Setting Up



NOTE To start the Travel Companion after installing the battery, press and hold the **Reset** button for at least two seconds, or connect to power (AC or travel adapter).



The first time you turn on the Travel Companion, follow the on-screen set up instructions. After completing this initial setup, the Travel Companion displays the Quick Start Tour, which provides information about using the Travel Companion. View as much of the Quick Setup Tour as needed. When exiting the tour, the Travel Companion initiates the HP Quick Launch screen, which provides the ability quickly and easily open applications on your iPAQ.

HP Quick Launch

HP Quick Launch is a simple way to open the most frequently used programs on the Travel Companion.

- Tap the **Today** icon to access the **Today** page.
- Tap the **Travel Assistant** icon to access WorldMate travel applications, Calendar, Contacts, and the Calculator.

- Tap the **Entertainment** icon to access entertainment applications like Windows Media Player 10, Photosmart Mobile, and games.
- Tap the **Internet** icon to access the Internet browser.
- Tap the **Navigation** icon to use GPS navigation.

HP Quick Launch is configured by default to be the home screen of the Travel Companion. Switch to use the Today screen as the home screen by tapping **Menu > Settings** and clearing the check boxes. You can also access the **Today** screen from the **Start** menu.

You can also configure Quick Launch by tapping **Menu > Settings** and:

- Selecting **Launch On Reset** to automatically start Quick Launch every time the device is soft reset.
- Selecting **Launch on Wakeup** to automatically start Quick Launch every time the device is switched on.

To learn more about the capabilities of the Travel Companion, refer to this guide as well as the *Additional Product Information* on the *Getting Started* CD. To begin navigation, proceed to the next step.

Navigation Setup

If you do not want to navigate now, continue learning about the Travel Companion and refer back to this section when you do want to use navigation.

You can use the navigation features of the Travel Companion right out of the box. The easiest way to open the GPS application is from the HP Quick Launch screen. When launching the GPS application for the first time, follow the on-screen instructions to configure and set up personal preferences.

The Travel Companion includes a built-in GPS receiver. To navigate to a destination, the GPS application must determine your current position, for which it uses the Global Positioning System (GPS). Available for free and without subscription, GPS uses satellites to transmit signals to GPS receivers. GPS signals work in all weather, anywhere in the world.

To establish a GPS signal, use the GPS receiver outdoors with a clear view of the sky. The GPS application can take up to five minutes to find your current position during its first use. If it takes longer than five minutes, make sure that you are in an open place without tall buildings or trees nearby. In subsequent uses, the GPS application will find your position much faster. Once the GPS application locates your current position, the application shows your position on the map.

If you want to immediately start navigating:


1. Press the power button to power on the Travel Companion. If this is the first time powering on the Travel Companion, you must either press the Reset button or connect to power for the unit to power on.
2. Start the GPS application by tapping **Navigation** from the HP Quick Launch screen.
3. Place the Travel Companion in a location with a clear view of the sky.
4. Install the car kit.
5. Insert the Travel Companion and plug it in using the travel power adapter.

Car Kit Setup


The car kit allows you to mount the Travel Companion in a location in your car that provides the best access to a GPS signal.

To install the car kit:


1. Plug the power cable into the Travel Power Adapter, and then plug the adapter into a vehicle power outlet.
2. Attach the power cable to the clips on the back of the Travel Companion holder. Be sure to leave enough cable to plug into the Travel Companion, and that the connector is turned the correct way to plug into the unit.




3. Install the holder onto the windshield mounting bracket.




4. Place the car kit assembly onto the windshield (1), and then press the locking lever (2) to securely mount the assembly into place.



5. To install the Travel Companion:
- a. Insert the Travel Companion into the mounted car kit holder (1).
 - b. Insert the securing clip into the slot on the top of the Travel Companion (2).
 - c. Plug the power cable into the Travel Companion (3).



6. Use the knobs to adjust the vertical and horizontal orientation of the Travel Companion.



Using TomTom Navigator 6

For more detailed information about TomTom Navigator 6, see the TomTom user guide on the *Getting Started* CD.



CAUTION Drive with due care and attention when using the Travel Companion for navigation.

Navigating to Destinations



NOTE TomTom Navigator 6 must first locate its current position before it can plan a route.

To plan a route:

1. With TomTom open, tap the screen to display the main menu.
2. Tap **Navigate to**. There are several options to navigate to. This procedure demonstrates navigating to an address.



NOTE Travel Companion/GPS integration also allows you to navigate to any entry in your personal Contact list that has an address entered.

3. Tap **Address**. When entering an address, select from the following options:
 - **City center**: Tap to set the destination as the center of a city or town.
 - **Street and house number**: Tap to set an exact address as the destination.
 - **Zip Code**: Tap to enter a zip code as the destination.
 - **Cross street or intersection**: Tap to set the destination as the point where two streets meet.

This procedure demonstrates navigating to an exact address.

4. Tap **Street and house number**.
5. Start to type the name of the town to which to navigate. As you type, names of towns display that match what you have typed. When the correct town displays, select it.
6. Start to type the name of the street. As you type, the names of the streets display that match the street you typed. When the correct street displays, select it.
7. Type the house number of the destination, and then tap **Done**.
8. TomTom asks whether you need to arrive at a particular time. If you tap **YES** and select an arrival time, TomTom indicates whether you will arrive on time.
9. After TomTom calculates the route, tap **Done**.

TomTom immediately starts guiding you to your destination with spoken and visual instructions.

Menus

To open the main menu, tap the screen at any time when TomTom displays the Driving View.



NOTE The following list is only a subset of all of the available menus. For a complete list, see the TomTom Navigator 6 documentation on the *Getting Started* CD.

Navigate to: Tap to start planning a route.

Find alternative: Tap if you want to avoid part of the route, travel by way of a specific location, or calculate an alternative route.

TomTom Traffic: Tap to access information about the traffic along your route. TomTom Traffic is not available in all countries.

Add favorite: Tap to create a Favorite, which may be a favored location, or a frequently visited location.

Change preferences: Tap to open the **Preferences** menu and change the way TomTom behaves.

Saving Destinations

Use the **Favorites** feature to save destinations to make it easy to navigate to them later. Favorites are frequently visited places. Create Favorites to avoid entering an address every time you want to navigate there.

To create and save a favorite destination:

1. From the Main Menu, tap **Add Favorite**. Select the location of the Favorite from the following list :
 - **Home:** You can specify your Home location as a Favorite.
 - **Address:** You can specify an address as a Favorite. When entering an address, choose from the same four options available in the **Navigate to** menu.
 - **Recent destination:** Select a Favorite location from a list of recently used destinations.
 - **Point of interest (POI):** Add a Point of Interest (POI) as a Favorite.
 - **GPS position:** Add your current position as a Favorite.
 - **Point on map:** Create a Favorite using the map browser. Select the location of the Favorite using the cursor, and then tap **Done**.
 - **Latitude/Longitude:** Create a Favorite by entering latitude and longitude values.
 - **TomTom Buddy:** Create a Favorite based on the current position of a TomTom Buddy. TomTom Buddies are other TomTom users that you can track, exchange Points of Interest with, etc.
2. Assign the contact a name that is easy to remember. TomTom suggests a name, usually the address of the Favorite. Start typing to specify a different name.

Preferences

To change the behavior of TomTom, tap **Change preferences** in the Main Menu. Some of the options include:

- **Use night colors:** Tap to reduce the brightness and use darker colors on the map.
- **Turn off 3D display:** Tap to view the map from above while navigating. When you turn off the 3D display, you can choose whether the map shows north or your direction of travel at the top.
- **Enable/disable POIs:** Tap to set which Point of Interest categories display on the map.
- **Safety preferences:** Tap to set the safety preferences such as the safety lock. When you enable the safety lock, you cannot access all buttons and features of TomTom while driving.

- **Change voice:** Tap change the voice that provides spoken instructions.
- Tap the arrow to open the next page of buttons.

Points of Interest (POI)

Points of Interest or POIs are useful locations on the map. Examples include:

- Restaurants
- Hotels
- Museums
- Parking garages
- Gas stations

To navigate to a POI:

1. Tap the screen to display the main menu.
2. Tap **Navigate to** in the main menu.
3. Tap **Point of Interest**.
4. Narrow the number of POIs by selecting the area of the POI location. Select one of these options:
 - **POI near you:** To search from a list of POIs near your current position.
 - **POI in city:** To choose a POI in a particular town or city.
 - **POI near Home:** To search from a list of POIs near your Home location.

If currently navigating to a destination, you can select from a list of POIs that are on the route or near the destination. Choose one of these options:

- **POI along route**
 - **POI near destination**
5. Select the category of POI.

Tap any POI category to search for a POI by name. If you do not find the POI, tap its category. Tap the arrow to choose from the complete list of categories. Select the category from the list or start to type the name of the category and select it when it displays in the list.

6. From the list of POIs, select the POI to navigate to. If you know the name of the POI, tap **Find**, and then type the name. Select it from the list when it displays.

After you select a POI, TomTom calculates the route to the POI.

TomTom Plus

TomTom PLUS is a collection of services that keep you informed and entertained while on the road. You can subscribe to a range of extras and download them either directly to your Travel Companion or download them to your computer, and then transfer them to your Travel Companion.

Travel Tools

WorldMate Standard Edition

The Travel Companion comes preinstalled with WorldMate Standard Edition. This travel assistant provides a host of tools that aid in travel planning. Features include:

- Clocks for global city list
- Currency converter with ability to automatically or manually update currency rates
- World map with city locator
- Weather forecasts for global city list
- Measurement converter
- Country phone codes and area codes
- Clothing size chart
- Extensive packing lists

Weather forecasts and automatic currency conversion require synchronizing the Travel Companion with a PC that is connected to the Internet and running WorldMate Active PC Sync Plug-in.

For more information about WorldMate Standard Edition, see the *Additional Product Information* on the *Getting Started* CD.

Organizer Features

The Travel Companion includes a number of organizer features that allow you to manage busy travel times.

E-mail — While traveling, you can use an Internet Service Provider (ISP) to send and receive Outlook and Internet e-mail. You can also access e-mail using a VPN connection.

Calendar — Sync with the company network and use the built-in Outlook calendar to update and manage appointments, including meetings and other events. You can display appointments for the day on the **Today** screen.

Contacts — Use the built-in contacts database to manage travel contacts.

Wireless — Using WLAN* and Bluetooth, connect to and exchange information with other handheld devices, various network types, or the Internet.



NOTE WLAN is available on rx5900 series models only.

Continuing Setup

Setting Up the Travel Companion

Use the following steps to quickly set up the Travel Companion. These steps allow you to load software so you can sync with your personal computer and update WorldMate information, integrate with e-mail and contacts, etc.

Step 1: Charge the battery



CAUTION To avoid damaging the Travel Companion or the AC adapter, be sure all connectors are properly aligned before connecting.

It takes approximately 2 to 4 hours to fully charge the battery the first time. Subsequent charges may take longer.

1. Insert the USB end of the mini-USB cable into the port on the AC adapter.
2. Install the appropriate head onto the AC adapter.
3. Connect the AC adapter to an electrical outlet.
4. Connect the mini-USB cable to the charging/communications port on the Travel Companion. The cable connector only fits one way, so do not force it. If the connector does not insert easily, turn it over.



NOTE Whenever a replacement battery is inserted into the Travel Companion, press and hold the **Reset** button for at least two seconds, or attach an AC adapter to turn on the device.

Step 2: Insert the *Getting Started* CD into the CD drive of a personal computer

Use the *Getting Started* CD to complete the setup of the Travel Companion and to synchronize the Travel Companion with a personal computer.

The **HP Install Wizard** automatically opens, and the application starts to run.



NOTE Do you have administrative rights on your personal computer? If not, you may have problems installing the applications from the *Getting Started* CD. An administrator needs to install the applications.

Step 3: Follow the personal computer on-screen instructions

The **HP Install Wizard** installs:

- Microsoft Outlook 2002
- Microsoft ActiveSync
- WorldMate Active Sync Plug-in
- Additional software applications

Step 4: Synchronize your HP iPAQ with your personal computer

Synchronization

Microsoft ActiveSync software, located on the *Getting Started* CD, allows your HP iPAQ and your personal computer to communicate with each other.

For synchronization to work properly, install Microsoft ActiveSync on your personal computer *before* connecting your HP iPAQ to your computer.

Use Microsoft ActiveSync to:

- Synchronize information between your HP iPAQ and up to two computers or one server so that the latest information is in all locations.
- Change synchronization settings and the synchronization schedule.
- Copy files between your HP iPAQ and computer.
- Install applications on your HP iPAQ.
- Synchronize links.
- Send and receive e-mail.
- Request meetings.

Synchronizing your HP iPAQ with a personal computer keeps the same information (such as calendar, contacts, and e-mails) on both units, making it available when you work on your personal computer or when you take your HP iPAQ on the go. Synchronize your HP iPAQ with a personal computer using one of the following methods:

- Mini-USB synchronization cable
- Bluetooth

To synchronize your HP iPAQ and a personal computer using the mini-USB synchronization cable:

1. Be sure ActiveSync 4.1 or later is installed on your personal computer.
2. Plug the USB end of the synchronization cable into your personal computer.
3. Connect the mini-USB end on the synchronization cable to the charging/communications port on your HP iPAQ.



CAUTION To avoid damaging your HP iPAQ or the AC adapter, check to be sure all connectors are properly aligned before connecting them.

Synchronization begins automatically.

4. Click **Next** on the **Synchronization Setup Wizard** screen.
5. Perform one of the following:
 - By default, the check box is selected to synchronize directly with a Microsoft Exchange Server. Clear this check box if you do **not** want to synchronize directly with a Microsoft Exchange server, and then click **Next**.
 - Click **Next** to synchronize directly with a Microsoft Exchange server.
6. When the **Synchronization Options** screen displays, select the items to synchronize between your HP iPAQ and your computer, and then click **Next**.
7. After the items have been synchronized, click **Finish**. The **Synchronization Setup Wizard** starts synchronizing the items you checked.

If ActiveSync does not begin synchronizing, start it manually:

- ☐ On your personal computer, open ActiveSync by selecting the **Start** menu > **Programs** > **Microsoft ActiveSync**.

Troubleshooting Help for Synchronization Issues

Following is a list of symptoms that may indicate synchronization issues are occurring:

- No ActiveSync chimes sound (or a gray icon displays), and there is no activity in the ActiveSync window on your personal computer.
- ActiveSync chimes sound, and the ActiveSync icon on your personal computer changes to a swirling green icon. The “retrieving settings” message appears on your personal computer, but the ActiveSync connection drops prior to establishing the partnership.
- ActiveSync is searching for a connection but none occurs. (The green icon on your personal computer continues to spin.)
- Synchronization has been established between your HP iPAQ and personal computer but connection is dropped. (The green icon on your personal computer stops spinning and grays out.)
- Firewall or other network protection software message box is displayed for ActiveSync to access the network or Internet.

If you experience difficulty while synchronizing your HP iPAQ and personal computer, try the following solutions to troubleshoot any synchronization issues:

- Confirm that you are running ActiveSync on your personal computer with a supported operating system (OS).
 - To get more information about the supported OS versions, visit: www.microsoft.com/windowsmobile.
 - The latest version of ActiveSync is at: www.microsoft.com/windowsmobile/downloads.
- If you are running ActiveSync 4.1 or later and personal firewall software on your personal computer, please add ActiveSync to the firewall program’s exception list.

(Firewall software, such as Sygate Personal Firewall, TrendMicro PC-cillin Internet Security, Norton Personal Firewall, McAfee Personal Firewall, or Zone Alarm Security Suite may block synchronization.) Refer to the documentation that came with your firewall program to determine how to add ActiveSync 4.1 or later to the program’s exception list. To further troubleshoot a firewall application and enable ActiveSync 4.1 or later, visit: www.microsoft.com/windowsmobile/help/activesync.

- During the ActiveSync installation, if you inadvertently left the Microsoft Exchange Server option box checked and are not planning to connect to an Exchange server, follow these steps:
 - Connect your HP iPAQ to your personal computer. Be sure an ActiveSync connection is established.
 - On your personal computer, click **Start > All Programs > Microsoft ActiveSync**.
 - Click **Tools > Options > Sync Options** tab.
 - Uncheck the boxes for the sync items listed under the Server group.
 - Place a checkmark in the boxes under the Desktop group for those items to synchronize.
- Disconnect your HP iPAQ from your personal computer and wait for the ActiveSync message confirming that your device is no longer connected. Reconnect your HP iPAQ to your personal computer. Wait for about two minutes to see if your HP iPAQ connects to your personal computer.

- On your personal computer, in ActiveSync, select **File > Connection Settings**. Confirm that USB is selected as a connection method.
- Connect your HP iPAQ to a different USB port on your personal computer.
- Check your mini-USB synchronization cable. Consider using another mini-USB synchronization cable if one is available.
- Try synchronizing via a Bluetooth connection.
- Restart your personal computer and perform a soft reset on your HP iPAQ. (A soft reset does not erase any settings, programs or data.) Use the stylus to lightly press the **Reset** button. Your HP iPAQ restarts and displays the HP QuickStart Tour. Once your personal computer and HP iPAQ restart, reconnect your HP iPAQ to your personal computer.
- Uninstall ActiveSync from your personal computer and then reinstall it. To uninstall ActiveSync from your personal computer, click **Start > Control Panel > Add or Remove Programs > Microsoft ActiveSync**. Then click the **Remove** button and click **Yes**.
- After trying the above solutions without any success in solving the connection problem, perform a factory reset on your HP iPAQ. (A factory reset clears all user-installed settings, programs, and data and restores your HP iPAQ to factory settings.)

Reinstall applications on your HP iPAQ once the factory reset is complete by using ActiveSync on your personal computer. Once your HP iPAQ is synchronized properly, go to ActiveSync on your personal computer and select **Tools > Add/Remove Programs** and select any programs to reinstall.

Finding the Serial Number and Model Number

Locate the serial and model numbers before contacting HP Customer Support, particularly if you are calling for in-warranty support.

View the serial number and model ID by tapping **Start > Programs > HP Help And Support > Serial and Model Number**.

You can also find this information next to the battery of your HP iPAQ. To locate the serial number:

1. Remove the battery cover.
2. Locate the label containing the serial number next to the battery.

Protecting Your HP iPAQ with a Password

Keep your data more secure by requiring a password every time you turn on your HP iPAQ.

1. Tap **Start > Settings > Personal tab > Lock > Password** tab.
2. Select the **Prompt if device unused for** check box, and select the amount of time from the list box that your HP iPAQ must be unused before the password is required.
3. In the **Password type** field, select the type of password you would like to use. Enter the password and confirm the password.

4. On the **Hint** tab, enter a phrase to help you remember your password. Be sure that your hint doesn't allow others to guess your password. The hint is displayed after the wrong password is entered five times.
5. When prompted, tap **OK**. The next time your HP iPAQ is unused for the specified amount of time, you are prompted to enter your password.



Tip Use the same steps as above to change or reset your password.

Today Screen

Access the **Today** screen by tapping **Start > Today**.

The **Today** screen shows appointments, active tasks, and information about e-mail messages. Along the top of the **Today** screen are the connectivity indicators, **Volume** icon, the battery level indicator, and the clock.

Tap a section of the **Today** screen to open the program that is associated with that section.

To customize the **Today** screen:

1. Tap **Start > Settings > Today**.
2. On the **Appearance** tab, select the desired theme for the background of the **Today** screen.
3. On the **Items** tab, select the items to appear on the **Today** screen.



Tip To change the order of items displayed on the **Today** screen, tap the item, and tap **Move Up** or **Move Down**.



NOTE There are two default softkeys on the bottom of the **Today** screen: **Calendar** and **Contacts**. On the **Today** screen, the **Calendar** softkey is also the **Notification** softkey. Any type of *alert*, such as a meeting reminder is displayed on the **Today** screen as a notification.

Status Icons

The following status icons are displayed on the Navigation or Command bar. Tap the icon on the HP iPAQ screen to view more information related to the item.

Icon	Status
	Indicates that one or more networks are present. Tap the icon to access an available network.
	Indicates connection to a wireless network.
	Indicates connection to ActiveSync, but not currently synchronizing.
	Inactive connection to computer or wireless network.

Icon	Status
	Microsoft ActiveSync is synchronizing.
	Speaker is on.
	Speaker is off (or in mute position).
	Battery power is low.
	Battery power is very low.
	E-mail has been received.
	Instant messages received.

iPAQ Wireless

Tap **Start > iPAQ Wireless** or tap the **iPAQ Wireless** icon on the **Today** screen to launch iPAQ Wireless, which provides a control center to turn WLAN and Bluetooth on and off, and to configure their settings. The GPS software controls the GPS receiver.

Icon	Status
	WLAN is on.
	WLAN is off.
	Bluetooth is on.
	Bluetooth is off.
	GPS receiver is on.
	GPS receiver is off.

*WLAN is available on rx5900 series models only.

The **iPAQ Wireless** screen has two power buttons to turn wireless features on and off. The **WLAN** and **Bluetooth** tabs allow you to access each wireless activity individually. Configure wireless connections by tapping **View WLAN Networks** on the **WLAN** tab or **Bluetooth Settings** on the **Bluetooth** tab.

Checking the Battery Charge Level

To monitor the battery power, tap either the **Battery** icon on the TodayPanel Lite or tap **Start > Settings > System tab > Power**.

If the battery charge level is low, connect to AC power.

Battery Saving Tips

The HP iPAQ is as individual as you are. Adjust the settings on your HP iPAQ to fit your individual needs and to help the battery last as long as possible between charges. Here are some recommendations for how to conserve battery life.

- Dim the Backlight – Keep the display only as bright as required to view the screen easily. On the **Today** screen, use the stylus to adjust the Backlight Brightness Level slider, near the **Light bulb** icon.
- Auto Turn Off the Backlight – On the **Today** screen, tap the **Light bulb** icon and make sure the first box is checked. Specify a short amount of time to wait before turning off the backlight.
- Keep Wireless Features Off – Always turn off the WLAN and Bluetooth power when they are not in use. Tap **Start > iPAQ Wireless**, and then tap the WLAN or Bluetooth button to turn the features off. WLAN is available on rx5900 series models only.
- Sounds & Notifications – Every time you are notified of an event, battery power is consumed. Go to **Start > Settings > Sounds & Notifications > Notifications** tab and turn off any notification types that are unnecessary.
- Auto Turn Off Device – On the **Today** screen, tap the **Battery** icon, and then tap the **Advanced** tab. Make sure the first box is checked, so the device automatically powers off when not in use. Specify a short amount of time to wait before automatically powering off your HP iPAQ.
- Turn GPS off – Always turn off the GPS receiver when you are not using GPS. Close the GPS application to turn off the receiver.

To keep your HP iPAQ charged, remember to use the car charger when using your HP iPAQ in the car.

Entering Text

Depending on your preference, use the on-screen keyboard or a handwriting recognition feature such as Block Recognizer, Letter Recognizer, or Transcriber to enter text in programs.

1. Tap **Start > Settings > Personal tab > Input**.
2. On the **Input Method** tab, select a text input method and change options as appropriate.
3. Tap **OK**.

You can now go to a program (such as Notes) and start entering text.

Text Input Method	Definition
Block Recognizer	Use a single stroke to write letters, numbers, symbols, and punctuation that are then converted into typed text. Perform gestures to enter Return and Backspace.
Keyboard	Tap keys on the on-screen keyboard displayed on the screen to enter text.
Letter Recognizer	Write individual letters, numbers, and punctuation that are converted into typed text.
Transcriber	Write in cursive, print, or mixed handwriting (consisting of both cursive and print) and convert writing into typed text.



Tip Change the text input method from within any program by tapping the **Input Selector** arrow and tapping an input method.

Entering Text Using Block Recognizer

1. From any program, tap the **Input Selector** arrow, and then **Block Recognizer**.
2. Write characters, numbers, and symbols in the designated writing area.
 - Enter letters by writing in the abc (left) area of the box.
 - Enter numbers by writing in the 123 (right) area of the box.
 - Enter symbols and punctuation by tapping in either area of the box and then writing the desired character.



NOTE Block Recognizer is available when text entry is possible.



Tip For help with writing characters with Block Recognizer, tap the question mark near the writing area.

Entering Text Using the On-screen Keyboard

1. From any program, tap the **Input Selector** arrow, and then **Keyboard**.
 2. Tap on the appropriate characters, numbers, and symbols on the on-screen keyboard.
- Increase the size of the on-screen keyboard keys to make them easier to tap.

1. Tap **Start > Settings > Personal** tab > **Input**.
2. On the **Input Method** tab, select **Keyboard** as the input method, and tap **Large keys**.
3. Tap **OK**.



NOTE Enlarge the keys even more by selecting the **Use gestures for the following keys** check box. Fewer keys appear on the keyboard, but you can do gestures for **Space**, **Backspace**, **Enter**, and **Shift+key**.

Entering Text Using Letter Recognizer

1. From any program, tap the **Input Selector** arrow, and then **Letter Recognizer**.
2. Write characters, numbers, and symbols in the designated writing area.
 - Enter capital letters by writing in the ABC (left) area of the box.
 - Enter lowercase letters by writing in the abc (middle) area of the box.
 - Enter numbers by writing in the 123 (right) area of the box.
 - Enter punctuation and symbols by tapping in either area of the box and then writing the desired character.



NOTE Letter Recognizer is available when text entry is possible.



Tip For help with writing characters with Letter Recognizer, tap the question mark near the writing area.

Writing with Transcriber

Transcriber works transparently in the background of programs, recognizing words with its integrated dictionary. When Transcriber is turned on, it interprets stylus movement anywhere on the screen as handwriting input.

To write with Transcriber:

1. From any program, position the cursor where you want the text to appear.
2. Use the stylus to write anywhere on the screen.

The handwriting is converted to text shortly after you lift the stylus from the screen.

Resetting Your HP iPAQ

You might need to perform a soft reset if your HP iPAQ stops responding. The two types of resets are soft and factory.

Performing a Soft Reset

A soft reset stops all running applications, but does not erase any programs or saved data.



NOTE Be sure to close all running applications before performing a soft reset.

To perform a soft reset:

1. Locate the recessed **Reset** button on your HP iPAQ.
2. Use the stylus to lightly press the **Reset** button.

The HP iPAQ restarts and displays the HP QuickStart Tour.

Performing a Factory Reset

A factory reset clears all user-installed settings, programs, and data, and restores your HP iPAQ to factory settings.

To perform a factory reset and return your HP iPAQ to factory settings:

1. Press and hold the **Quick Launch** and **Rotate Screen** buttons.
2. While holding these buttons, use the stylus to lightly press the **Reset** button on the HP iPAQ until the device restarts.
3. When the HP iPAQ restarts, release all of the buttons, and then remove the stylus from the **Reset** button.

The HP iPAQ restarts and powers on.

Entertainment

Your HP iPAQ lets you have fun with several entertainment features:

- Play music and watch videos

Play music and watch videos on your HP iPAQ with Windows Media Player 10 Mobile. Synchronize media files between a Windows-based computer and your HP iPAQ. Update playlists, copy music library, and use online music services with Windows Media DRM protection.

- View and manage digital photos

Use your HP iPAQ with HP Photosmart Mobile as a digital photo album that's always with you to view and share photos in high-quality color. Use the Slide Show to watch photos of friends and family, while your HP iPAQ charges.

- Play games

Let your HP iPAQ help to fill your spare time with games like Solitaire or Bubble Breaker. Purchase other Windows Mobile game titles and useful applications by visiting <http://mobile.handango.com/hp> or find more information on the *Getting Started* CD.

Windows Media Player 10 Mobile

Microsoft Windows Media Player 10 Mobile with enhanced features allows you to enjoy digital media in new ways both at home and on the go. The personal computer (PC) version of Windows Media Player 10 can be downloaded for free from Microsoft.

With this new version:

- Sync music, playlists, videos, and recorded TV to your HP iPAQ for easy enjoyment on the go.
- Automatically convert video and recorded TV during sync to an optimized and size reduced format for better viewing on your HP iPAQ.
- Manually select digital media to sync to your HP iPAQ, or automatically sync to your HP iPAQ each time you connect, based on your preferences.
- New music subscription services enable you to pay a monthly fee and download all the music you want. With Windows Media Player 10, you can now take those songs with you on your HP iPAQ.

For a complete list of features and more, visit www.microsoft.com/windows/windowsmedia/player/windowsmobile.



NOTE Protected files are digital media files that are secured with a license to prevent unauthorized use or playback. Licenses are created and managed by using the Digital Rights Management (DRM) technology.

Listening to Music and Watching Videos

Use Windows Media Player 10 Mobile to play songs, videos, and playlists that are stored on your HP iPAQ or removable storage card.

1. If you are not on the Library screen, tap **Menu > Library**.
2. If necessary, on the Library screen, tap the **Library** arrow (near the top of the screen), and then tap the library that you want to use (for example, **Storage Card**).
3. Tap a category (for example, **My Music** or **My Playlists**), tap and hold the item that you want to play (such as a song, album, or artist name), and then tap **Play** or **Queue Up**.



NOTE To play a file stored on your HP iPAQ but that is not in a library, on the Library screen, tap **Menu > Open File**. Tap and hold the item that you want to play (such as a file or a folder) and then tap **Play** or **Queue Up**.

Clearing the Now Playing List

Under Windows Media Player, the Now Playing playlist displays the currently playing file and any files that are queued up to play next. Quickly remove all items from the playlist by clearing it.

1. If you are on the **Library** screen, select the **Now Playing** category to display the **Now Playing** screen.
If you are on the **Playback** screen, select **Now Playing** to display the **Now Playing** screen.
2. On the **Now Playing** screen, tap **Menu > Clear Now Playing**.

Updating a Library

In most cases, Windows Media Player 10 Mobile automatically updates your libraries as necessary. However, you can manually update a library to ensure that it has links to any new files that you might have recently copied to your HP iPAQ or a removable storage card.

1. If you are not already on the **Library** screen, tap **Menu > Library**.
2. On the **Library** screen, tap **Menu > Update Library**.
3. Wait for the files to be added, and then tap **Done**.

HP Photosmart Mobile

Use HP Photosmart Mobile to:

- View pictures stored on the HP iPAQ or a storage card.
- Add voice or text notes to pictures.
- Print pictures.

- View a slideshow.
- Send pictures by e-mail attachments.
- Associate a picture with a Contact.
- Assign a picture to the **Today** screen background.

Attaching a Voice Note to a Picture

To attach a sound file to a picture:

1. Tap **Start > Programs > Photosmart Mobile**.
2. Tap the thumbnail picture in which you want to add a voice note.
3. Tap the **Cassette** icon.
4. Tap the **Record** button on the Recording toolbar.
5. Speak into the microphone to record the sound file and tap the **Stop** button when finished.
6. Tap the **Cassette** icon again to close the Recording toolbar.

E-mailing Pictures

1. Tap **Start > Programs > Photosmart Mobile**.
2. Tap the thumbnail picture to be e-mailed.



NOTE If you cannot view or hear the media file to be e-mailed, the file may be protected by Digital Rights Management (DRM). DRM is software that enables secure distribution and prevents illegal distribution of pictures, videos, music, movies, and ring tones over the Internet. For more information on DRM, refer to the on-screen Help by tapping **Start > Help** and search on DRM.

3. Tap **Menu > Send**.
4. Tap **E-mail Attachment**.
5. Tap the **Reduce sent photo size to** check box and select the reduction percentage desired.
6. Tap **Next**.
7. Enter the appropriate e-mail address or use Contacts by tapping **Menu > Add Recipient**.
8. Enter other appropriate information, such as an e-mail title and message.
9. Tap **Send**.

Viewing a Slideshow

To view a slideshow:

1. Tap **Start > Programs > Photosmart Mobile**.
2. Tap the slideshow icon at the bottom of the screen.
3. Tap the screen to view the **Pause**, **Forward**, **Backward**, and **Stop** buttons.

Mobile Office

Your HP iPAQ includes the following programs:

- Calendar
- Contacts
- Tasks
- E-Mail
- Internet Explorer Mobile
- Word Mobile
- Excel Mobile
- PowerPoint Mobile

With these applications:

- Manage contacts and calendar.
- Send and receive e-mail.
- Browse the Internet.
- Open and view slide show presentations.
- Create and edit documents and templates.
- Create and edit Excel workbooks and more.

To access these productivity tools and learn more about the features, tap **Start > Programs**.

Calendar

Accessing Calendar

Use Calendar to schedule appointments, meetings, and other events.

You can display appointments on the **Today** screen. If you use Outlook on your personal computer, you can synchronize appointments between your HP iPAQ and computer. You can also set Calendar to remind you of appointments with a sound or flashing LED.

You can look at your appointments in various views (Day, Week, Month, and Agenda). To see detailed appointment information in any view, tap the appointment. You can also change the Calendar view.

For easy access to your calendar, tap **Calendar** on the bottom of the **Today** screen. You can also access your calendar by tapping **Start > Calendar**.

For more information, refer to *Additional Product Information* located on the *Getting Started* CD.

Viewing Today's Agenda

1. Tap **Start > Calendar**.
2. Tap **Menu > View > Agenda**.



Tip To quickly view today's agenda, on the **Today** screen, tap one of your upcoming appointments.

Viewing Appointments

To view an appointment on your calendar:

1. Tap **Start > Calendar**.
2. Tap the appointment to view.

To view appointments for the week:

1. Tap **Start > Calendar**.
2. Tap **Menu > View > Week**.



NOTE You can also view appointments for the month or year by tapping the appropriate selection.

Scheduling an Appointment

1. Tap **Start > Calendar**.
2. Tap **Menu > New Appointment**.
3. Enter a name for the appointment and information such as start and end times.

To schedule an all-day event, in the **All Day** box, tap **Yes**.

4. When finished, tap **OK** to return to the calendar.



NOTE All-day events do not occupy blocks of time in Calendar; instead, they appear in banners at the top of the calendar.

To cancel an appointment, tap the appointment and tap **Menu > Delete**.



Tip To have the time entered automatically in Day view, tap the time slot for the new appointment, and tap **Menu > New Appointment**.

Sending a Meeting Request

Use Calendar to schedule meetings via e-mail with contacts who use Outlook or Outlook Mobile.

To send a meeting request:

1. Tap **Start > Calendar**.
2. Schedule a new appointment, or open an existing one and tap **Edit**.
3. Tap **Attendees**.
4. Tap the name of the contact to invite.
5. To invite additional attendees, tap **Add** and then tap the name.
6. Tap **OK**. The meeting request is sent to the attendees the next time you synchronize your HP iPAQ.

When attendees accept a meeting request, the meeting is automatically added to their calendars. When their response is sent back to you, your calendar is also updated.

Contacts

Accessing Contacts

Use Contacts to:

- Store phone numbers, e-mail addresses, home addresses, and any other information that relates to a contact, such as a birthday or an anniversary date.
- Add a picture to a contact.
- Quickly communicate with people.

For easy access to contacts, tap the **Contacts** softkey on the bottom of the **Today** screen or tap **Start > Contacts**.

Tap a contact in the list for a summary of contact information.

If you use Outlook on your computer, synchronize contacts between your HP iPAQ and your personal computer.

Creating a Contact

1. Tap **Start > Contacts**.
2. Tap **New** and enter the contact information.
3. When finished, tap **OK**.



NOTE If your contact list has been filtered by a category when you create a contact, that category is automatically assigned to the new contact.

To include a nickname, title, and more, while creating a contact, tap the **Name** arrow.

If most of the contacts you create have phone numbers that begin with the same area code, in Contacts, tap **Menu > Options** and enter that area code in the **Area code** box.

For more information about creating contacts, tap **Start > Help** on your HP iPAQ.

Finding a Contact

To find a contact on a long list:

1. Tap **Start > Contacts**.
2. If you are not in **Name** view, tap **Menu > View By > Name**.
3. Do one of the following:
 - Begin entering a name or phone number in the provided text box until the contact is displayed. To show all contacts again, tap the text box and clear the text, or tap the arrow to the right of the text box.
 - Use the alphabetical index displayed at the top of the contact list. Tap the tab that corresponds to the first letter of the contact's name.
 - Filter the list by categories. In the contact list, tap **Menu > Filter**. Then tap a category you've assigned to a contact. To show all contacts, select **All Contacts**.



NOTE To search for a contact by entering a name or phone number, or by using the alphabetical index, you must be in **Name** view.

Tasks

Creating a Task

Easily create to-do tasks in the Task list.

1. Tap **Start > Programs > Tasks**.
2. Tap **Menu > New Task**, enter a subject for the task, and fill in information such as start and due dates.
3. When finished, tap **OK**.

For more information, refer to *Additional Product Information* located on the *Getting Started* CD.

Locating a Task

When the task list is long, display a subset of the tasks or sort the list to quickly find a specific task.

1. Tap **Start > Programs > Tasks**.
2. In the task list, do one of the following:
 - Sort the list. Tap **Menu > Sort By**, and tap a sort option.
 - Filter the list by category. Tap **Menu > Filter**, and tap the category to display.

E-mail

Different Ways to Access E-mail Messages

When using Messaging, you can send and receive e-mail messages several ways:

- **Synchronize Outlook e-mail with your personal computer**

Tap **Start > Messaging** to use your Outlook e-mail address.

- **Microsoft Exchange 2003**

Exchange enables you to wirelessly synchronize your Inbox, Calendar, and Contacts to remotely check appointments and other information. For more information about Exchange, contact your IT administrator.

- **Messaging & Security Feature Pack (MSFP) with Microsoft Exchange 2003 Service Pack 2**

Push technology keeps Outlook Mobile up-to-date by delivering Inbox, Calendar, Contacts, and Tasks list quickly and directly to your HP iPAQ. For more information about Connect to Mobile Business E-mail using Exchange Server 2003, contact your IT administrator.

- **Internet e-mail messages**

Use the e-mail address you received from your Internet Service Provider (ISP) or your employer.



NOTE Some of the messaging applications may vary and are available only on select HP iPAQ models.

Setting up an E-mail Account on an Exchange Server

Synchronize directly with an Exchange Server using a connection to a wireless network or a personal computer.

To set up e-mail on an Exchange server:

1. Tap **Start > Programs > ActiveSync**.



NOTE If a screen displays several messages, click on the link that reads **If your company supports synchronizing directly with its Exchange Server you can set up your HP iPAQ to synchronize with it**, then follow the series of steps to synchronize your e-mail account with the Exchange Server. Otherwise, continue with the steps below.

2. Tap **Menu > Configure Server**.

If you have not set up a synchronization server link, the following message is displayed: **Add Server Source**.

3. In the **Server address** box, enter the name of the server running Exchange 2003.

4. Select the **This server requires an encrypted (SSL) connection** check box if required by your IT department.

Most companies require this option, and if this box is not checked, you cannot sync with your company Exchange Server.

5. Tap **Next**.

6. Enter your name, password, and domain, and then tap **Next**.
7. Select the **Save password** text box if you want to enable automatic sync.
8. To change the rules for resolving synchronization conflicts, tap **Advanced**.
9. Select the check boxes for the types of information items that you want to synchronize with Exchange Server.
10. To change available synchronization settings, select the type of information and tap **Settings**.
11. Tap **Finish**.

You can set up your HP iPAQ to synchronize with Exchange Server over a wireless network or through a cable or Bluetooth connection to a personal computer. You must have the following information to sync wirelessly: server name, user name, password, and domain name.



NOTE Synchronizing directly with Exchange Server is supported only on Windows Mobile-powered Pocket PC 2002 or later.

By clicking **Tools > Options**, you can determine whether an information type is synchronized with a personal computer or with Exchange Server.

Setting up a POP3, HTTP, or IMAP4 E-mail Account

To send and receive mail, you need to set up an e-mail account with an Internet Service Provider (ISP) or have an account that you access using a virtual private network (VPN) server connection (typically a work account).

Be sure you have the proper plan with your wireless service provider and the connections have been set up correctly.

To set up an e-mail account on your HP iPAQ:

1. Tap **Start > Messaging**.
2. Tap **Menu > Tools > New Account**.
3. Enter your e-mail address, and tap **Next**.

Auto configuration attempts to download necessary e-mail server settings so that you do not need to enter them manually.

4. Once Auto configuration has finished, tap **Next**.
5. Enter your name (the name you want displayed when you send e-mail) and your password.

If Auto configuration is successful, your user name is already entered. Tap **Next**, then **Finish** to complete setting up your account, or tap **Options** to access additional settings. For example:

- Change the time intervals for downloading new messages
- Download attachments
- Limit the number of messages that are downloaded

If Auto configuration is unsuccessful, tap **Start > Help** and search on email.



NOTE You can set up several e-mail accounts in addition to your Outlook E-mail account. You cannot add a new account while connected. Tap **Menu > Stop Send/Receive** to disconnect.

Composing and Sending Outlook E-mail Messages

To compose and send a message:

1. Tap **Start > Messaging**. Outlook E-mail is displayed.
2. Tap **New**. An Outlook E-mail text box is displayed.
3. Enter the e-mail address or phone number of one or more recipients, separating them with a semicolon. To access addresses and phone numbers from Contacts, tap **To**.
4. Enter your message. To quickly add a canned message, tap **Menu > My Text** and tap a desired message.
5. To check spelling, tap **Menu > Spell Check**.
6. Tap **Send**. If you are working offline, your message is moved to the Outbox folder and is sent the next time you connect.



NOTE Tap the **Inbox** drop-down arrow to access other Outlook folders such as Drafts, Outbox, and Sent Items.

Replying to or Forwarding an Outlook E-mail Message

To reply to or forward a message:

1. Tap on the message to open it, and then tap **Menu > Reply, Reply All, or Forward**.
2. Enter your response. To quickly add common messages, tap **Menu > My Text** and tap a desired message.
3. To check spelling, tap **Menu > Spell Check**.
4. Tap **Send**.



NOTE To keep the original text with the outgoing message, tap **Menu > Tools > Options** then tap the **Message** tab. You must check the **When replying to e-mail, include body** option.

Sorting the Message List

To sort the message list:

1. In the message list, tap the sort list (labeled **Received** by default) and select an option.
2. Select the option again to reverse the sort order (ascending and descending).

Internet Explorer Mobile

Use Internet Explorer Mobile to view and download web pages as well as browse web sites through synchronization, or when connected to the Internet.

Before connecting to the Internet, setting up a wireless connection or network card, obtain the following:

- Internet Service Provider (ISP) or wireless service provider
- ISP server phone number or access point
- User name and password

To access Internet Explorer Mobile, tap **Start > Internet Explorer**.

Word Mobile

You can create and edit documents and templates in Word Mobile. You can also save the documents and templates as .doc, .rtf, .txt, and .dot files.

With Word Mobile:

- Edit Word documents and templates created on your computer.
- Open and edit Pocket Word (*.psw) documents.



NOTE If you edit a file, save it in .doc, .rtf, .txt, or .dot format.

To access Word Mobile, tap **Start > Programs > Word Mobile**.

Excel Mobile

Create and edit workbooks and templates on your HP iPAQ with Excel Mobile.

With Excel Mobile:

- View, edit, and create charts and graphics, which can be embedded as objects in a worksheet or placed on a separate worksheet.
- Enter formulas and functions, and then filter data to see the subset of information you want.
- Split panes to view different parts of a worksheet at the same time.
- Freeze the top and left-most panes in a worksheet to keep row and column labels or other data visible as you scroll through a sheet.

To access Excel Mobile, tap **Start > Programs > Excel Mobile**.

PowerPoint Mobile

Use PowerPoint Mobile to open and view slide show presentations created on your computer.

With PowerPoint Mobile:

- Open a presentation from an e-mail message.
- Download a presentation from a file share or the Internet.
- Copy a presentation to your HP iPAQ via a storage card.
- Obtain a presentation by synchronizing with your computer.



NOTE Slide shows created in *.ppt or *.pps format with PowerPoint '97 and later can be viewed on your device.

PowerPoint features that are not supported on your HP iPAQ include:

- Notes: Notes written for slides are not visible.
- Rearranging or editing slides: PowerPoint Mobile is a viewer only.

To access PowerPoint Mobile, tap **Start > Programs > PowerPoint Mobile**.

WLAN



NOTE WLAN is available on rx5900 series models only.

With wireless access, cables are not needed to connect your HP iPAQ to the Internet. Instead, access points transmit data to and from your wireless device. Your HP iPAQ can connect to an 802.11b/g WLAN or connect directly to other WLAN-enabled devices. With WLAN, you can:

- Access the Internet
- Send and receive e-mail
- Access corporate network information
- Use virtual private networks (VPNs) for secure remote access
- Use hotspots for wireless connectivity

Turning WLAN On or Off

To turn WLAN on or off:

1. Tap **Start > Today > iPAQ Wireless**.
2. Tap the **WLAN** icon on the **iPAQ Wireless** screen.

When WLAN is on:

- The **WLAN** icon on the **iPAQ Wireless** screen turns amber or green.
- The wireless light-emitting diode (LED) on your HP iPAQ flashes blue.



NOTE Even though the indicator is blue to indicate WLAN is turned on, it does not necessarily mean a connection has been established with another device or access point.

Turn WLAN off when you are not using it by tapping the **WLAN** icon again.

When **WLAN** is off, the **WLAN** icon turns gray, and the blue LED turns off.

Searching for WLAN Networks to Access

Networks that have been already configured are preferred networks. Choose whether to connect only to preferred networks or to have your HP iPAQ search for and connect to any available network (preferred or not).

1. Tap **Start > Today > iPAQ Wireless**.
2. Tap the **WLAN** icon to turn on WLAN.
3. Tap **View WLAN Networks**.
4. In the **Networks to access** box, tap the type of network to connect to (**All Available**, **Only access points**, or **Only computer-to-computer**).
5. Tap the wireless network to which you want to connect.

Configuring Network Security Settings

A wireless network can be added when the network is automatically detected. Or, manually enter the settings information to add the network. To determine if authentication information is needed, check with your Network Administrator or Hotspot Service Provider.

1. Tap **Start > Today > iPAQ Wireless**.
2. Turn on WLAN by tapping the **WLAN** icon.
3. Tap **View WLAN Networks** to choose an available network.
4. In **Configure Wireless Networks**, select the network to configure.
5. To use authentication, tap the **Network Key** tab and select the authentication method from the **Authentication** list.
6. To use data encryption, select an encryption method from the **Data Encryption** list.
7. To automatically use a network key, tap **The key is automatically provided**. Otherwise, enter the network key manually.

Bluetooth

Your HP iPAQ comes with built-in Bluetooth which is a short-range wireless communications technology. Devices with Bluetooth capabilities can exchange information over a distance of about 30 feet (10 meters) without requiring a physical connection.

Use Bluetooth to:

- Transfer information, such as files, appointments, tasks, and contact cards, between devices that have Bluetooth capabilities.
- Print data to a Bluetooth-designated printer.
- Use a Bluetooth service. Once you connect to another device or computer using Bluetooth, you can locate and use any of the services available on that device.



Tip Your HP iPAQ may include additional Bluetooth features.

For more information, refer to *Additional Product Information* located on the *Getting Started* CD.

Turning Bluetooth On or Off

To turn on Bluetooth:

1. Tap **Start > Today > iPAQ Wireless**.
2. On the **iPAQ Wireless** screen, tap the **Bluetooth** icon.

When Bluetooth is turned on, the wireless LED on your HP iPAQ flashes blue.

To turn off Bluetooth, tap the **Bluetooth** icon again. When Bluetooth is turned off, the Bluetooth LED turns off and no incoming or outgoing Bluetooth connections are possible.



Tip To save battery power, turn Bluetooth off when you are not using it.

Connecting to a Bluetooth Headset

You can use a Bluetooth headset (or other Bluetooth hands-free device) with your HP iPAQ when you create a partnership between them.

1. Make sure that the two devices are turned on, discoverable, and within close range.
2. Tap **Start > Today > iPAQ Wireless > Bluetooth** tab.
3. Tap **Bluetooth Connections > New**.
4. Select **Hands-free/Headset setup** and follow the on-screen instructions.

Protecting the HP iPAQ Screen from Cracking or Damage



CAUTION The screen of your HP iPAQ is made of glass and can be damaged or broken by drops, impacts, or pressure.

To reduce the risk of damage to the internal components, do not spray liquid directly on the screen, or allow excess liquid to drip inside your HP iPAQ. Using soap or other cleaning products on the screen might discolor the finish and damage it.

- Observe the following practices to protect the screen of your HP iPAQ from damage:
 - Do not sit on your HP iPAQ.
 - When transporting your HP iPAQ in a purse, pocket, briefcase, etc., ensure the device does not get compressed, bent, dropped, or hit.
 - When not in use, use the protective screen cover (if one is available) on your HP iPAQ and store it in a case. Select from a wide variety of case options at www.hp.com/accessories/ipaq or www.casesonline.com.
- Do not place anything on top of your HP iPAQ.
- Do not bang your HP iPAQ against hard objects.

- Never use any device other than the stylus that comes with the HP iPAQ or an approved replacement to tap or write on the screen. If you lose or break your stylus, order extras at www.hp.com/accessories/ipaq.
- Clean your HP iPAQ by wiping the screen and the exterior with a soft, damp cloth lightly moistened only with water.

Obtaining Services for a Cracked or Damaged Screen



NOTE HP is not responsible for damage that occurs as a result of failure to follow the instructions that came with the HP branded product. Refer to the warranty document included with your HP iPAQ for more information.

If you have a nonwarranty event occur such as a damaged or cracked screen and want your device repaired, contact HP Customer Support at www.hp.com/support for service. However, contacting HP customer service on a nonwarranty event results in a charge for the repair.

Additional Guidelines for Using Your HP iPAQ

- Disconnect all external devices.
- Take the AC adapter and charger adapter with you.
- Keep your HP iPAQ in a protective case and keep it in your carry-on luggage.
- For air travel, be sure to turn off Bluetooth and WLAN. To turn off all wireless features, tap **Start > Today > iPAQ Wireless**.
- When traveling internationally, be sure you have the plug adapter appropriate for the country you are visiting.

Frequently Asked Questions

How Do I...	Find information here...
Install Microsoft ActiveSync and create an ActiveSync partnership?	Synchronization
Troubleshoot ActiveSync?	Troubleshooting Help for Synchronization Issues
Locate the serial and model number for my HP iPAQ?	Finding the Serial Number and Model Number
Set up an e-mail account?	Setting up an E-mail Account on an Exchange Server
Perform a soft or factory reset?	Resetting Your HP iPAQ
Use wireless connections?*	WLAN
Use built-in Bluetooth technology?	Bluetooth
Conserve battery power?	Battery Saving Tips
Protect my HP iPAQ from screen damage and cracking?	Protecting the HP iPAQ Screen from Cracking or Damage
Start the GPS software?	HP Quick Launch



NOTE WLAN is available on rx5900 series models only.

Finding More Information

For information on...	See this source...
Using your HP iPAQ	<i>Additional Product Information</i> on the <i>Getting Started</i> CD.
Connecting to and synchronizing with a computer	ActiveSync Help on your computer. To view Help, start ActiveSync, then click Help > Microsoft ActiveSync Help .
Troubleshooting on ActiveSync connections	ActiveSync Troubleshooting on your computer. From ActiveSync, click Help > Microsoft ActiveSync Help > Troubleshooting .
Programs that are on your HP iPAQ	<i>Getting Started</i> CD and Help located on the HP iPAQ. From the Start menu, tap Help .
Safety precautions	<i>Important Safety Information</i> on the <i>Getting Started</i> CD.
Web sites optimized for your HP iPAQ	www.hp.com/go/ipaqmobile
Accessory products	www.hp.com/accessories/ipaq
Warranty information	www.hp.com/go/handheldwarranty

Additional Product Information

User Guide



© Copyright 2006 Hewlett-Packard
Development Company, L.P.

Microsoft, Windows, the Windows logo,
Outlook, and ActiveSync are trademarks of
Microsoft Corporation in the U.S. and other
countries.

HP iPAQ Products are Powered by
Microsoft® Windows Mobile™ Version 5.0
for Pocket PC.

SD Logo is a trademark of its proprietor.

Bluetooth® is a trademark owned by its
proprietor and used by Hewlett-Packard
Development Company, L.P. under license.

All other product names mentioned herein
may be trademarks of their respective
companies.

The information contained herein is subject
to change without notice. The only
warranties for HP products and services are
set forth in the express warranty statements
accompanying such products and services.
Nothing herein should be construed as
constituting an additional warranty. HP shall
not be liable for technical or editorial errors
or omissions contained herein.

This document contains proprietary
information that is protected by copyright. No
part of this document may be photocopied,
reproduced, or translated to another
language without the prior written consent of
Hewlett-Packard Development Company,
L.P.

First Edition September 2006

Document Part Number: 433176-xx1

Table of contents

1 Registering the iPAQ	
Registering your HP iPAQ	1
2 GPS	
GPS General Information	3
Verifying Compatibility	4
Configuring My GPS Software to Connect to My HP iPAQ's GPS Receiver	5
Managing GPS Automatically	6
Identifying the COM Port for My GPS Receiver	7
Identifying Your HP iPAQ's Embedded Receiver	8
Using an External Antenna with your GPS Receiver	9
Losing The GPS Signal While in My Car	10
Losing the GPS Signal Frequently	11
Common Reasons For Interference When Using GPS Software	12
3 Travel Assistant	
WorldMate Travel Assistant Standard Edition	13
Screen Navigation	13
Clocks	14
Using the Alarm	15
World Map	16
Weather Service	17
City List	18
Currency Converter Service	19
Updating Currency Rates	20
Measurement Converter Service	21
Country and Area Codes	22
Clothing Sizes	23
Packing List	24
WorldMate's ActiveSync Settings	25
4 Connections	
Connections	27
Connecting to Intranet URLs	28
Changing an Intranet URL	29
Setting Up an Automatic Choice for Connections	30
Setting Up Proxy Server Settings	31
Configuring Advanced Proxy Settings	32
Using Advanced Connection Settings	33

Setting Up a VPN Server Connection	34
Changing a Connection Group Name	35
Ending a Connection	36
Wi-Fi	37
Wi-Fi	37
Wi-Fi Terms	37
Automatically Connecting to a Wi-Fi Network	38
Manually Connecting to a Wi-Fi Network	38
Finding an IP Address	38
Deleting a Wireless Network	39
Configuring 802.1x Authentication Settings	39
Bluetooth	40
Bluetooth Terms	40
Working with Bluetooth Manager	40
Connecting to a Computer using Bluetooth	41
Bluetooth Device Profiles	41
Creating, Ending, and Accepting a Bluetooth Partnership	42
Renaming a Bluetooth Partnership	42
Making a Device Discoverable	43
Opening Bluetooth Settings	43
Setting Up an Incoming or Outgoing Bluetooth Serial (COM) Port	43

5 HP Photosmart Mobile

HP Photosmart Mobile	45
Attaching a Voice Note to a Picture	46
E-mailing Pictures	47
Viewing a Slideshow	48

6 HP Photosmart Premier

HP Photosmart Premier	49
-----------------------------	----

7 Messaging

Understanding Messaging	51
Using Folders	52
Synchronizing E-mail	53
Setting Up Messaging Accounts	54
Receiving Attachments	54
Receiving Meeting Requests	54
Creating or Changing a Signature	55
Using Messaging	56
Composing and Sending Messages	56
Replying to or Forwarding a Message	56
Adding an Attachment to a Message	56
Downloading Messages	56
Downloading Messages from a Server	57
Installing an Online Address Book	57

8 Learning The Basics

Entering Owner Information	59
----------------------------------	----

Using TodayPanel Lite	60
Viewing the Operating System Information	61
Changing the Regional Settings	62
Adjusting the Volume	63
Changing Power Management Settings	64
Dimming or Adjusting the Brightness of the Backlight	65
Installing and Removing Programs	66
Opening and Closing Programs	67
Customizing the HP iPAQ	68
Setting Alarms	69
Shortcut Menus	70
Showing the Clock in All Programs	71
Creating and Assigning a Category	72
Adjusting the Speed for Scrolling Through Items in a List	73

9 Calendar

Accessing Calendar	75
Changing the Display of the Work Week	75
Setting a Default Reminder for All New Appointments	76
Updating an Appointment	77
Canceling an Appointment	78

10 Contacts

Creating a Contact	79
Finding a Contact	80
Deleting a Contact	81
Changing Contact Information	82
Copying a Contact	83
Sending an E-mail Message to a Contact	84
Adding and Removing a Picture	85
Working with the Contact List	86

11 Notes

Writing a Note	87
Converting a Handwritten Note to Typed Text	88
Creating a Copy of a Note	89

12 Storage Cards

Using Storage Cards	91
Installing a Storage Card	92
Removing a Storage Card	93
Viewing Content of a Storage Card	94

13 Synchronizing

Copying (or Transferring) Files	95
Migrating Data from Palm Desktop to Microsoft Windows Mobile 5.0	96
Wireless Synchronization Cost Saving Tips	97

14 Tasks

Setting the Start and Due Dates for a Task	99
Showing Start and Due Dates in the Task List	100
Setting Options for Displaying Tasks on the Today Screen	101
Marking a Task as Completed	102

15 Product Specifications

System Specifications	103
Physical Specifications	105
Operating Environment	106

16 Regulatory Notices

Federal Communications Commission Notice	107
Modifications	107
Cables	107
Declaration of Conformity for products marked with the FCC logo (United States only)	108
Canadian Notice	108
Avis Canadien	108
European Union Notice	108
Battery Warning	109
Battery Recycling	110
Equipment Warning	111
Medical Electronic Equipment	112
Wireless Notices	113
U.S. Regulatory Wireless Notice	113
Canadian Regulatory Wireless Notice	113
Brazilian Notice	113
Japanese Notice	114
Wireless LAN 802.11b devices	114
Wireless LAN 802.11g devices	114
Taiwan Notice	115
Korean Notice	116

Index	117
--------------------	------------

1 Registering the iPAQ

Registering your HP iPAQ

When you register your HP iPAQ with Hewlett-Packard, you receive e-mail regarding special offers and promotions. Take time now to register your HP iPAQ online at <http://www.register.hp.com>.

If your mailing or e-mail address needs to be updated after registering, enter your user ID and registration password to edit your online profile at <http://www.register.hp.com>.

Antenna House XSL Formatter

2 GPS

GPS General Information

Satellite signal reception for your GPS-enabled HP iPAQ generally requires that you go outdoors to start the GPS navigation software. Place the HP iPAQ where there is a clear view of the sky or on the dashboard of a vehicle that does not have thermal glass windshields or windows.



NOTE Interference might take place close to tall buildings or large trees, and under very cloudy or overcast skies, all of which can block the satellite signal from reaching the HP iPAQ. Try to avoid these obstructions before using GPS.



WARNING! When using hardware and software navigation aids, in a vehicle or elsewhere, it is your sole responsibility to place, secure, and use these aids in a manner that will not cause accidents, personal injury, property damage or obstruct your view. You are solely responsible for observing safe driving practices. Do not operate this product while driving. Park the vehicle first.

If you are going to use GPS navigation in your vehicle for an extended period of time, charge your HP iPAQ using the Auto adapter.

For information on GPS accessories, visit www.hp.com/go/ipaqnavigation.

Verifying Compatibility

All HP iPAQ Global Positioning System (GPS) enabled devices come with HP iPAQ compatible GPS navigation software solutions.

If you are interested in purchasing additional GPS navigation software to use on your HP iPAQ, check with the GPS software supplier (before you purchase, download, or install any GPS navigation software) to determine that the application is compatible with your specific HP iPAQ model.

Once you have verified compatibility, purchase and install a map onto the HP iPAQ or memory card to be able to start using the GPS navigation technology.



NOTE HP recommends that you download all GPS maps to a memory card that is compatible with your specific HP iPAQ model, or to the iPAQ File Store folder. This prevents you from losing your map data due to a possible power loss or a need to perform a clean reset on your HP iPAQ. Since your HP iPAQ model uses Windows Mobile 5.0, you can store maps in main memory that is not erased if the battery loses power.

You can purchase memory cards at www.hp.com/accessories/ipaq.

Configuring My GPS Software to Connect to My HP iPAQ's GPS Receiver

All GPS software applications need to know which communications port to use to access GPS data. Your HP iPAQ already has the GPS port specified for the GPS software applications that came with the device. However, if you install additional GPS applications onto your HP iPAQ, you may need to specify the GPS port in your GPS application's configuration settings.

If your GPS software does not automatically discover the GPS receiver on your HP iPAQ, set your GPS application's configuration settings to **COM7** and a baud rate of **57600**. If you need help, refer to the documentation that came with your GPS software application.

Managing GPS Automatically

Your GPS-enabled HP iPAQ uses Microsoft Windows Mobile 5.0, so the operating system automatically manages access to the HP iPAQ GPS receiver to allow multiple programs to simultaneously access GPS data.

If your GPS-enabled HP iPAQ **does not** automatically discover the GPS receiver on your device, set your GPS application's configuration settings to **COM7** and a baud rate of **57600**. If you need help, refer to the documentation that came with your GPS software application.

Identifying the COM Port for My GPS Receiver

The GPS receiver on your GPS-enabled HP iPAQ is set to **COM7** and a baud rate of **57600**.

Identifying Your HP iPAQ's Embedded Receiver

The GPS receiver in your HP iPAQ is the SiRFstarIII from SiRF and is software upgradeable. The SiRFstarIII is a high sensitivity GPS receiver with rapid time-to-first fix technology that provides superior location performance, so under normal use there is no need for an external antenna.

However, an optional external antenna is available if you want to use your HP iPAQ in locations that do not provide ideal GPS reception.

Using an External Antenna with your GPS Receiver

Under normal use, there is no need for an external GPS antenna. However, if you want to use your HP iPAQ in locations less favorable for GPS reception, such as inside of a car away from the windshield, you can use an optional 3V active external antenna. Plug this antenna into the gold MMCX connector on the left side of your HP iPAQ.

Losing The GPS Signal While in My Car

GPS performance on the HP iPAQ may be affected if the vehicle has thermal glass windows and windshields, which can block the HP iPAQ from receiving a GPS signal from satellites.

To improve GPS signal strength, place the HP iPAQ where there is a clear view of the sky or on the dashboard of a vehicle that does not have thermal glass windshields. A direct line of sight is required between the HP iPAQ and the GPS satellites to access information from the satellites.

Losing the GPS Signal Frequently

To improve the satellite signal to the GPS-enabled HP iPAQ, go outdoors to start the GPS navigation software. Place the HP iPAQ where there is a clear view of the sky or on the dashboard of a vehicle that does not have thermal glass windshields or windows.



NOTE Interference may exist close to tall buildings, large trees, and under very cloudy or overcast skies, all of which can block the satellite signal from reaching the HP iPAQ. Try to avoid these obstructions before using GPS.

Common Reasons For Interference When Using GPS Software

Interference Type	How to Avoid
Vehicles with thermal glass windows and windshields	Place the HP iPAQ where there is a clear view of the sky or on the dashboard of a vehicle that does not have thermal glass windows.
Cell Phones or other equipment radiating Radio Frequency (RF) energy or emitting strong electromagnetic radiation. For example, microwave ovens, high-power cordless phones, CB radios, Walkie-talkies, HAM equipment, X-ray and MRI machines, etc.	Move away from interference source or switch off the interference source.
Tall buildings, large trees, and very cloudy or overcast skies.	Move away from interference source so there is a clear view of the sky.

3 Travel Assistant

WorldMate Travel Assistant Standard Edition

Your HP iPAQ comes preinstalled with WorldMate Travel Assistant Standard Edition. This travel assistant provides a world clock, currency converters, weather, and other travel organizing tools.

Screen Navigation

WorldMate Standard contains several screens that you can access using the tabs at the bottom of the screen. Tap the tabs to switch between the clocks, weather, maps, currencies and more.

Clocks

The **Clocks** screen displays your home clock plus four other pre-selected clocks. To change a displayed city, tap the city name and select a new city from the list. Tap the (i) icon near any clock to change the selected city's details. Tap the cloud icon to view the weather forecast for that city. You must sync your HP iPAQ with a PC running WorldMate software to get updated forecasts.

Using the Alarm

To set the alarm, tap the bell icon on the **Clocks** screen to access the alarm settings screen. The alarm on icon displays below the bell icon after you turn the alarm on.

To turn the alarm off:

1. Select **Set alarm for**, and then set the alarm time.
2. If you want a sound to play when the alarm goes off, select **Play sound**, and then select an alarm sound from the list.
3. If you want a message to display when the alarm goes off, type the message in the **Message** box.

Your HP iPAQ displays the **Alarm** screen when the alarm goes off.

World Map

World Map provides a map of the world that shows where it is currently daylight and dark, as well as global city locations.

To view a city location:

- Select the city from the list below the map.
- Or, tap the map to display the closest city.

You can also display the weather forecast for the selected city by tapping the **Sun/Cloud** icon. Note that you must sync with a PC that is online running the WorldMate software to get weather forecasts.

Weather Service

You can access the weather from either the **World Map** screen or the **Clocks** screen. Tap the **Sun/Cloud** icon to get a 5-day forecast for the selected city.



NOTE WorldMate supports only built-in cities for weather updates.

To get current forecasts, update the WorldMate software on your PC, sync your HP iPAQ with your PC, and then tap **Get Updated Forecast**.

City List

To edit the cities list, from either the **World Map** screen or the **Clocks** screen, tap **Tools > Edit Cities**.

The city list is sorted by name, offset from GMT or state of Daylight Saving Time (DST). To sort, tap the appropriate label at the top of the list. To add a city, tap **New**.

To add your own city, type the city name, GMT offset, Daylight Saving Time information, and its location on the map.

Currency Converter Service

This easy-to-use converter allows you to simultaneously calculate the sum of values in up to three different currencies, as well as receive updated rates online or insert them manually.

To convert currencies:

1. Tap the arrow in each heading cell to display a list from which you can select a currency.
2. Type a value to convert in the editable fields below the heading fields. Currency values are automatically computed for each selected currency.

Tap **Get Updated Rates** to access the Internet and update WorldMate with the latest exchange rates.

Tap **Clear** to delete all values in the table.

Updating Currency Rates

To manually update currency rates:

1. Tap **Tools** > **Edit Currencies**.
2. Tap on the currency you want to update.
3. Type the rate relative to the base currency (the value of the base currency in terms of what you are editing).



NOTE Updating a Euro-based currency will affect all other Euro based currencies. You cannot change exchange rates between two Euro-based currencies.

Sync your HP iPAQ with the PC running WorldMate to automatically update currency rates.

Measurement Converter Service

To use the **Measurements Converter** screen:

1. Select the type of measurement (length, temperature, etc.) from the **Convert** list.
2. Select the measurements (meters, feet, etc.) from the two lists below the **Convert** list.
3. Type a number to convert in the box to the left of the measurements. The converted value automatically displays below box.
4. Tap **Clear** to delete field values.

Country and Area Codes

Tap the **Show** list to switch between international dialing prefixes, U.S., and Canadian area codes. The table provides:

- Country/State names
- Dialing prefixes
- Local time offset from GMT in hours (this table does not update for Daylight Saving Time)

Tap a column heading to sort according to the column.

Use the **Find** box to look up prefixes according to the currently selected column. For example, type “1” to locate the first country that starts with the letter I, or select the **Code** column and type “2” to find the first country with an area code that starts with the number 2.

Clothing Sizes

This table shows which clothing sizes to buy when traveling overseas. Use the different categories with the man-woman-child icons to quickly find the size you need.



NOTE Use the size table only as a guideline. Different manufacturers have slightly different size tables.

Packing List

Use the **Packing List** screen to create and keep track of a list of items you need to pack. A list of items is provided in categories that you can select at the top of the screen.

To create a packing list:

1. Select the category of items you want to select from the category drop-down list at the top of the screen.
2. Select the items you want to pack from the **All Items** list. WorldMate automatically moves items you select to **My List**. You can then use the **My List** items as a checklist.
3. Tap an item to change its description, category, or list location.
4. To add or edit a category, select **Edit Categories** from the category drop-down list .

WorldMate's ActiveSync Settings

The WorldMate installer installs the WorldMate Standard application on your Windows Mobile Pocket PC and the WorldMate ActiveSync component on your computer. Once installed, the WorldMate ActiveSync component will update currency rates and weather forecasts, as well as your HP iPAQ clock with Atomic time whenever you synchronize your HP iPAQ while connected to the Internet.

The WorldMate ActiveSync component is fully configurable and you may adjust the options to fit your needs.

To access the WorldMate ActiveSync component set up screen on your PC:

1. Right-click **ActiveSync** located on the system tray (next to the clock).
2. Select **Open Microsoft ActiveSync**.
3. Scroll the list of **ActiveSync** components for WorldMate Standard.
4. Right-click WorldMate Standard and select **Settings**.

Online Content Updates: WorldMate's ActiveSync component can check for updates every 6, 12, or 24 hours. Select zero for the WorldMate ActiveSync component to update every time you connect your HP iPAQ to your PC.

Network Settings: Use the Network Settings to configure the WorldMate ActiveSync to work behind a firewall or proxy server. Consult your network administrator for the correct settings.

Antenna House XSL Formatter

4 Connections

Connections

You can use your HP iPAQ to connect to and exchange information with other handheld devices, your computer, various network types, or the Internet. You can connect using:

- Wi-Fi
- Bluetooth

All these connection types can be accessed by tapping **Start > Settings > Connections** tab.

Connecting to Intranet URLs

To connect to intranet sites that have periods in their URLs (for example, intranet.companyname.com), add them to the Work URL Exceptions list.

1. Tap **Start > Settings > Connections** tab.
2. Tap **Connections > Advanced tab > Exceptions**.
3. Tap **Add new URL**.
4. In **Work URL**, enter the intranet URL.



NOTE If you use many URLs that share the same root company name, you can avoid entering them individually by entering *.companyname.com.

Changing an Intranet URL

1. Tap **Start > Settings > Connections tab > Connections > Advanced tab > Exceptions**.
2. Tap the intranet URL exception you want to change, then make the desired changes.



NOTE To delete a work URL exception, tap and hold it in the list, then tap **Delete**.

Setting Up an Automatic Choice for Connections

If you have already created more than one connection, you can set up your HP iPAQ to connect to the best available connection automatically.

1. Tap **Start > Settings > Connections** tab > **Connections**.
2. Under **My ISP** or **My Work Network**, tap **Manage existing connections**.
3. Tap **Auto pick**.

Setting Up Proxy Server Settings

If you are connected to your Internet Service Provider (ISP) or private network during synchronization, your device should download proper proxy settings during synchronization from your computer. If these settings are not on your computer or need to be changed, you can change them manually.

Before you begin, obtain the following information from your Internet Service Provider (ISP) or network administrator:

- User name
- Password
- Server type
- Proxy server name
- Port
- Type of Socks protocol used

To set up proxy server settings:

1. Tap **Start > Settings > Connections** tab > **Connections**.
2. If a proxy server has not been set up, tap **Set up my proxy server**. Otherwise, tap **Edit my proxy server**.
3. Select the **This network connects to the Internet** and **This network uses a proxy server to connect to the Internet** check boxes.
4. In the **Proxy server** box, enter the proxy server name.
5. To change such settings as port number or proxy server type, tap **Advanced** and change desired settings.

Configuring Advanced Proxy Settings

1. For the appropriate server type, enter the proxy server name and port.
2. If necessary, enter the credentials for connecting with your proxy server.
3. If you are configuring a Socks proxy, select **Socks 4** or **Socks 5**. If using Socks 5, enter the credentials for connecting with your proxy server.

Using Advanced Connection Settings

1. Tap **Start > Settings > Connections** tab > **iPAQ Wireless**.
2. Tap the **Wi-Fi** icon to turn on Wi-Fi.
3. Connect to a network by tapping **Start > Settings > Connections** tab > **Connections** icon > **Advanced** tab > **Select Networks** button.
4. Select **My ISP** to connect to the Internet through an Internet Service Provider (ISP) or select **My Work Network** to connect to a company network. You should only choose **My Work Network** if the network requires a proxy server. If you need to change or create a new network management name, tap the **Edit...** or **New...** button and **OK**.
5. From the Connections screen, tap the **Advanced** tab to set up your **Dialing Rules** and **Exceptions** and press **OK**.

Setting Up a VPN Server Connection

A Virtual Private Network (VPN) connection helps you to securely connect to servers, such as a corporate network, via the Internet.

Before you begin, obtain the following information from your network administrator:

- User name
- Password
- Domain name
- TCP/IP settings
- Host name or IP address of the VPN server

To set up a VPN server connection:

1. Tap **Start > Settings > Connections** tab > **Connections**.
2. Under **My Work Network**, tap **Add a new VPN server connection** and follow the instructions in the New Connection wizard.
3. Under most circumstances, you should not need to change any advanced settings. However, you need to change advanced settings when:
 - The server to which you are connecting does not use dynamically-assigned addresses, and you need to enter your TCP/IP settings.
 - You need to change server DNS or WINS settings.
4. If either of these circumstances applies, from the **My VPN** screen, tap the **Advanced** button and fill in the appropriate information. Tap **OK** to save the changes and return to the **My VPN** screen.
4. To view additional information for any screen in the wizard or while changing settings, tap the **Help** question mark.



NOTE To change existing settings, under **My Work Network**, tap **Manage existing connections > VPN** tab. Select the desired VPN connection, tap **Edit**, then follow the instructions on the screen.

To manually start a connection, tap and hold the connection, then tap **Connect**.

To delete a connection, tap and hold the connection you want to remove, then tap **Delete**.

Changing a Connection Group Name

Your device is already set up with two groups of connection settings: My ISP and My Work Network. You can change the name of these groups to something more meaningful. For example, if you put all of your corporate settings under My Work Network connections, you can change the name to your company's name.

1. Tap **Start > Settings > Connections** tab > **Connections**.
2. Under **My ISP** or **My Work Network**, tap **Manage Existing Connections**.
3. Tap the **General** tab.
4. Enter a name for the settings group.

Ending a Connection

It can be useful to end a connection when you are done using it. This frees resources on your HP iPAQ and can save connection charges.

- When connected using a modem or Virtual Private Network (VPN), tap **Connections** icon > **Disconnect**.
- When connected using a cable, detach your HP iPAQ from the cable.
- When connected using Bluetooth, tap **Start > iPAQ Wireless > Bluetooth** tab > **Bluetooth Connections > Active Connections** tab. Tap and hold the connection name, and then tap **Delete**.
- When connected using a network (Ethernet) card, remove the card from your HP iPAQ.
- When connected to GPS, close the GPS software.

Wi-Fi

Wi-Fi

With wireless access, you do not need to use cables to connect your HP iPAQ to the Internet. Instead, access points transmit data to and from your wireless device. Your HP iPAQ can connect to an 802.11b/g WLAN or connect directly to other WLAN-enabled devices. With Wi-Fi, you can:

- Access the Internet
- Send and receive e-mail
- Access corporate network information
- Use Virtual Private Networks (VPNs) for secure remote access
- Use hotspots for wireless connectivity

Tap **Start > iPAQ Wireless** to access the Wi-Fi features.



NOTE Use of dial-up and wireless Internet, e-mail, corporate networks, and other wireless communications, such as Bluetooth devices, may require separately purchased additional hardware and other compatible equipment, in addition to a standard Wi-Fi infrastructure and a separately purchased service contract. Check with your service provider for availability and coverage in your area. Not all web content may be available. Some web content may require installation of additional software.

Wi-Fi Terms

It is recommended that you become familiar with the following terms as you begin to use Wi-Fi technology.

Term	Definition
802.11 standard	An approved standard specification of radio technology from the Institute of Electrical and Electronic Engineers (IEEE) used for wireless local area networks (WLANs).
Device-to-computer or ad-hoc	A mode that does not use access points. It provides independent peer-to-peer connectivity in a wireless LAN.
Domain Name System (DNS)	The way that Internet domain names are located and translated into IP addresses. It is an easy to remember name for an Internet address. Every web site has its own specific IP address on the Internet.
Encryption	An alphanumeric (letters and/or numbers) conversion process of data primarily used for protection against any unauthorized people.
Hotspots	Public or private areas where you can access Wi-Fi service. These wireless connections can be located, for example, at a library, cyber cafe, hotel, airport lounge, or convention center. This service can be free or sometimes requires a fee.
Infrastructure	This connection mode uses wireless access points to connect to networks.

Automatically Connecting to a Wi-Fi Network

When you connect to a Wi-Fi network, the HP iPAQ automatically detects Wi-Fi networks that are broadcasting their signal. If your Wi-Fi network isn't set to broadcast, then you must connect to it manually. Before trying to connect to a Wi-Fi network, determine if authentication information is needed by contacting your network administrator.

1. Tap the **iPAQ Wireless** icon.
2. Tap the **Wi-Fi** icon to turn Wi-Fi on.
3. Once the HP iPAQ detects a Wi-Fi network, you are asked to choose if you want to connect. Select the network you want to connect to and tap **Connect**.

Manually Connecting to a Wi-Fi Network

A wireless network can be added manually by entering the settings information to add the network. Before trying to connect to a Wi-Fi network, determine if authentication information is needed by contacting your network administrator.

1. Tap the **iPAQ Wireless** icon.
2. Tap the **Wi-Fi** icon to turn Wi-Fi on.
3. On the **Wi-Fi** tab, tap **View Wi-Fi Networks**.
4. Tap **Add New**.
5. Enter the Network name.
6. Choose a connection method. Select **The Internet** to connect to the Internet through an Internet Service Provider (ISP) or select **Work** to connect to a company network. You should only choose **Work** if the network requires a proxy server.
7. Tap the **Network Key** tab.
 - To use authentication, and select the authentication method from the **Authentication** list.
 - To use data encryption, select an encryption method from the **Data encryption** list.
 - To automatically use a network key, tap **The key is automatically provided**. Otherwise, enter the network key.



NOTE To delete a connection, tap the **iPAQ Wireless** icon > **Wi-Fi** tab > **View Wi-Fi Networks**. Tap and hold the connection you want to remove, and then tap **Remove Settings**.

Finding an IP Address

1. Tap the **iPAQ Wireless** icon.
2. Tap the **Wi-Fi** icon to turn Wi-Fi on.
3. Connect to a network automatically, or connect manually by tapping **View Wi-Fi Networks** on the **Wi-Fi** tab.

4. Select a Wi-Fi network and tap **OK**.
5. Tap **Advanced** located on the Wi-Fi tab. The Wi-Fi IP Address is shown here as well as other detailed information about your current Wi-Fi connection.

Deleting a Wireless Network

You can delete networks you manually entered. However, if a network was automatically detected, you are not able to delete it.

To delete an existing or available wireless network:

1. Tap the **iPAQ Wireless** icon.
2. Tap the **Wi-Fi** icon to turn Wi-Fi on.
3. Tap the **Wi-Fi** tab > **View Wi-Fi Networks** > **Wireless** tab.
4. In the **Configure Wireless Networks** box, tap and hold the network you want to delete.
5. Tap **Remove Settings**.

Configuring 802.1x Authentication Settings

Before performing these steps, determine if authentication information is needed by contacting your network administrator.

1. To manually enter information, tap **Start** > **iPAQ Wireless** > **Wi-Fi** tab > **View Wi-Fi Networks** > **Wireless** tab.
2. In **Configure Wireless Networks**, select the network you want to configure.
3. For increased security, tap **802.1X** tab > **Use IEEE 802.1x network access control**. Then select the appropriate EAP type.

Bluetooth

Bluetooth Terms

It is recommended that you become familiar with the following terms as you begin to use Bluetooth technology.

Term	Definition
Authentication	Verification of a numeric passkey before a connection or activity can be completed.
Authorization	Approval of a connection, access, or activity before it can be completed.
Bonding (Paired devices)	Creating a trusted connection between your device and another. After a bond is created, the two devices become paired. A paired device does not require authentication or authorization.
Device address	Unique electronic address of a Bluetooth device.
Device discovery	Location and recognition of another Bluetooth device.
Device ID	Name that a Bluetooth device provides when discovered by another device.
Encryption	Method of protecting data.
Passkey	Code you enter to authenticate connections or activities requested by other devices.
Personal Information Manager (PIM)	Collection of programs used to manage daily business tasks (for example: Contacts, Calendar, and Tasks).
Profiles	Collection of Bluetooth settings.
Service discovery	Determination of which programs you have in common with other devices.

Working with Bluetooth Manager

Use Bluetooth Manager to:

- Establish connections
 - Exchange business cards
 - Display shortcuts
1. Tap the **iPAQ Wireless** icon.
 2. Tap the **Bluetooth** icon to turn Bluetooth on.
 3. Tap the **Bluetooth** tab > **Bluetooth Connections**. The first screen that displays is **My Shortcuts**.

When you are required to locate a device and connect to it, the Bluetooth browser searches for other Bluetooth devices.

Connecting to a Computer using Bluetooth

For best results, connect the HP iPAQ to the computer using USB to establish a synchronization relationship before connecting using Bluetooth.

1. Follow the instructions in ActiveSync Help on the computer for configuring Bluetooth on your computer to support ActiveSync.
2. On the HP iPAQ, tap **Start > Programs > ActiveSync**.
3. Tap **Menu > Connect via Bluetooth**. Make sure the device and computer are within close range.
4. If this is the first time you have connected to this computer using Bluetooth, complete the Bluetooth wizard on the HP iPAQ and set up a Bluetooth partnership with the computer.
5. Tap **Sync**.
6. When finished, tap **Menu > Disconnect Bluetooth**.
7. To preserve battery power, turn off Bluetooth.

Bluetooth Device Profiles

The functions that Bluetooth supports are called services or profiles. You can communicate only with Bluetooth devices that support at least one of the following profiles:

- ActiveSync—Uses SPP to connect to ActiveSync on a computer
- Advanced Audio Distribution Profile (A2DP)
- Audio Video Remote Control Profile (AVRCP)
- Basic Imaging Profile (BIP)
- Basic Printer Profile (BPP)
- File Transfer Protocol (FTP)
- Generic Access Profile (GAP)
- Hands Free Profile (HFP)
- Headset Support Profile (HSP)
- Human Interface Device Profile (HID)
- LAN Access Profile (LAP)
- Object Exchange (OBEX) Protocol
- Object Push Protocol (OPP)
- Personal Area Network (PAN)
- Serial Port Profile (SPP)
- Service Discovery Application Profile (SDAP)

Creating, Ending, and Accepting a Bluetooth Partnership

You can create a partnership between your HP iPAQ and another device that has Bluetooth capabilities. Once you do this, the devices must have Bluetooth turned on but do not need to be discoverable for you to exchange information between them.

1. Be sure the two devices are turned on, discoverable, and within close range.
2. Tap **Start > iPAQ Wireless > Bluetooth tab > Bluetooth Connections**.
3. Tap **New**.
4. Follow the instructions on the screen..

To end a Bluetooth Partnership:

1. Tap **Start > iPAQ Wireless > Bluetooth tab > Bluetooth Connections**.
2. Tap and hold the partnership you want to end.
3. Tap **Delete**.

To accept a Bluetooth Partnership:

1. Be sure your device is turned on, discoverable, and within close range.
2. When prompted to accept a partnership with the device that is requesting the relationship, tap **Yes**.
3. If a passkey is requested, enter an alphanumeric passkey between 1 and 16 characters in **Passkey**, and tap **Next**. Enter the same passkey in the device requesting the partnership. Using a passkey provides greater security.

If you cannot discover another device, try the following:

- Be sure Bluetooth is turned on.
- Move closer to the device.
- Be sure the device you are attempting to connect to is on and allows access to being discovered by other devices.

Renaming a Bluetooth Partnership

1. Tap **Start > iPAQ Wireless > Bluetooth tab > Bluetooth Connections**.
2. Tap and hold the partnership you want to rename on the **My Shortcuts** tab.
3. Tap **Rename**.
4. Enter a new name for the partnership.

Making a Device Discoverable

When your HP iPAQ is discoverable, other devices with Bluetooth capabilities can detect, or discover, your HP iPAQ and attempt to beam information to it, establish a partnership, or use a Bluetooth service.

1. Tap **Start > iPAQ Wireless > Bluetooth** tab > **Bluetooth Settings> Accessibility** tab.
2. Select the **Allow other devices to connect** and the **Other devices can discover me** check boxes.
3. Tap **OK**.



NOTE If you no longer want your HP iPAQ to be discoverable, clear the check boxes.

Opening Bluetooth Settings

1. Tap the **iPAQ Wireless** icon.
2. Tap the **Bluetooth** icon to turn on Bluetooth.
3. Tap the **Bluetooth** tab > **Bluetooth Settings**.

Setting Up an Incoming or Outgoing Bluetooth Serial (COM) Port

1. Be sure your HP iPAQ is connected to the other device via Bluetooth.
2. Tap **Start > Settings > Connections** tab.
3. Tap **Bluetooth > Services** tab.
4. Tap **Serial Port > Advanced**.



NOTE **Outbound COM Port** is only available if at least one Bluetooth device supports serial (COM) connection.

5. Select a numbered COM port from the list.



NOTE If the port cannot be created, it is in use. Select a different numbered port.

6. Tap **OK**.
7. To limit communication on this COM port to only devices with which the HP iPAQ has a Bluetooth partnership, select the **Authentication (Passkey) required** check box.

Antenna House XSL Formatter

5 HP Photosmart Mobile

HP Photosmart Mobile

Use HP Photosmart Mobile to:

- View pictures stored on the HP iPAQ or a storage card.
- Add voice or text notes to pictures.
- Print pictures.
- View a slideshow.
- Send pictures by e-mail attachments.
- Associate a picture with a Contact.
- Assign a picture to the Today screen background.

Attaching a Voice Note to a Picture

To attach a sound file to a picture:

1. Tap **Start > Programs > Photosmart Mobile**.
2. Tap the thumbnail picture in which you want to add a voice note.
3. Tap the **Cassette** icon.
4. Tap the **Record** button on the Recording toolbar.
5. Speak into the microphone to record the sound file and tap the **Stop** button when finished.
6. Tap the **Cassette** icon again to close the Recording toolbar.

E-mailing Pictures

1. Tap **Start > Programs > Photosmart Mobile**.
2. Tap the thumbnail picture to be e-mailed.



NOTE If you cannot view or hear the media file to be e-mailed, the file may be protected by Digital Rights Management (DRM). DRM is software that enables secure distribution and prevents illegal distribution of pictures, videos, music, movies, and ring tones over the Internet. For more information on DRM, refer to the on-screen Help by tapping **Start > Help** and search on DRM.

3. Tap **Menu > Send**.
4. Tap **E-mail Attachment**.
5. Tap the **Reduce sent photo size to** check box and select the reduction percentage desired.
6. Tap **Next**.
7. Enter the appropriate e-mail address or use Contacts by tapping **Menu > Add Recipient**.
8. Enter other appropriate information, such as an e-mail title and message.
9. Tap **Send**.

Viewing a Slideshow

To view a slideshow:

1. Tap **Start > Programs > Photosmart Mobile**.
2. Tap the slideshow icon at the bottom of the screen.
3. Tap the screen to view the **Pause**, **Forward**, **Backward**, and **Stop** buttons.

6 HP Photosmart Premier

HP Photosmart Premier

HP Photosmart Premier allows you to view, organize, edit, share, and print pictures on your personal computer. Use the *Getting Started CD* to install this imaging software on a personal computer.

With HP Photosmart Premier, you can:

- View, organize, and manage pictures
 - View variable thumbnail size, single, full screen, and slide show images
 - Assign keywords for fast, reliable searches
 - Sort pictures by date, name, keywords, location, or recently used
 - Create slide shows with music for your personal computer
- Edit pictures
 - Correct red-eye and crop, rotate, and flip images
 - Auto corrects the picture with the one-button auto-fix
 - View edited images side-by-side with the original
 - Play, trim, and extract single frames from video
- Print pictures
 - Printing the most popular size pictures
 - Set correct driver properties for photo printing on "older" HP printers
 - Adjust printing with active preview
 - Create custom photo packages with page optimization, index, and video action printing
- Create templates
 - Produce easy-to-use album templates
 - Generate plug-ins for additional album templates, panoramas, and creative projects
 - Construct easy panorama stitching and printing
 - Build hundreds of creative templates for cards and calendars, album pages, CD labels, flyers and brochures

- Share pictures
 - Use HP Instant Share e-mailing—e-mail pictures without large attachments
 - Select picture thumbnails for e-mail lists
 - Integrate with Outlook™ address books
- Backup images of pictures
 - Upgrade available for CD archiving
 - Back up and restore to CD (or DVD with upgrade)
 - Set reminders to archive photos
 - Digital negatives

For detailed instructions on each HP Photosmart Premier feature, refer to Help inside the application.

7 Messaging

Understanding Messaging

To send and receive e-mail messages for an e-mail account that you have with an Internet Service Provider (ISP) or that you access using a VPN server connection (typically a work account), you need to connect to the Internet or your corporate network, depending on the account.

You can send and receive Outlook e-mail and Internet e-mail through an Internet Service Provider (ISP). You can also access e-mail from work using a VPN connection.

E-mail in the Outlook e-mail account is sent and received through synchronization with a personal computer using ActiveSync or through wireless synchronization directly with an Exchange Server.

Internet e-mail is sent and received by connecting to a Post Office Protocol 3 (POP3) or Internet Message Access Protocol 4 (IMAP4) e-mail server. When connecting to a POP3 or IMAP4 server, you use a modem to connect to your Internet Service Provider (ISP). You can also use a modem or Ethernet card to connect to the local area network that your e-mail server is connected to.

Using Folders

Each Messaging account has its own set of folders with five default Messaging folders:

- Inbox
- Outbox
- Deleted Items
- Drafts
- Sent Items

The messages you receive and send through the account are stored in these folders. You can also create additional folders within each account.

The way folders work vary by type:

- If you use an Outlook e-mail account, e-mail messages in the Inbox folder in Outlook are synchronized automatically with your device. You can select to synchronize additional folders by designating them for synchronization. The folders you create and the messages you move are mirrored on the e-mail server. For example, if you move two messages from the Inbox folder to a folder named Family, and you have designated Family for synchronization, the server creates a copy of the Family folder and copies the messages to that folder. You can then read the messages while you are away from your personal computer.
- If you use a POP3 account and you move e-mail messages to a folder you created, the link is broken between the messages on the device and their copies on the e-mail server. When you connect, the e-mail server detects that the messages are missing from the Inbox folder on the device and deletes them from the e-mail server. This prevents having duplicate copies of a message, but it also means that you no longer have access to messages that you move to folders created from anywhere except the device.
- If you use an IMAP4 account, the folders you create and the e-mail messages you move are mirrored on the e-mail server. Therefore, messages are available to you anytime you connect to your e-mail server, whether it is from your device or personal computer. This synchronization of folders occurs whenever you connect to your e-mail server, create new folders, or rename/delete folders when connected. You can also set different download options for each folder.

Synchronizing E-mail

When you synchronize Outlook e-mail on the personal computer with your device, e-mail messages are synchronized as follows:

- Messages in the Inbox folder on your personal computer or Exchange Server are copied to the Inbox folder of the Outlook e-mail account on your device.
- Messages in the Outbox folder on your device are transferred to Exchange Server or Outlook and then sent from those programs.
- When you delete a message on your device, it's deleted from your personal computer or Exchange Server the next time you synchronize.
- The default sync settings synchronize messages from the past three days only and the first .5KB of each new message is downloaded. It does not download file attachments.



NOTE For more information on starting Outlook e-mail synchronization or changing synchronization settings, see ActiveSync Help on the personal computer or tap **Contents**.

Text messages are not received via synchronization. Instead, they are sent to your device via your service provider.

Setting Up Messaging Accounts

Receiving Attachments

An attachment sent with an e-mail message or downloaded from the server appears below the subject of the message. Tapping the attachment opens the attachment if it has been fully downloaded or marks it for download the next time you send and receive e-mail. You can also download attachments automatically with your messages if you have an Outlook e-mail or IMAP4 e-mail account.

If you have an Outlook e-mail account, do the following:

1. Tap **Start > Programs > ActiveSync**.
2. Tap **Menu > Options**.
3. Tap **E-mail > Settings**, and then select **Include file attachments**.

If you have an IMAP4 e-mail account with an Internet Service Provider (ISP) or an account that you access using a VPN server connection (typically a work account), do the following:

1. Tap **Start > Messaging**.
2. Tap **Menu > Tools > Options**.
3. Tap the name of the IMAP4 account.
4. Tap **Next** until you reach **Server information**, and tap **Options**.
5. Tap **Next** twice, and select **Get full copy of messages** and **When getting full copy, get attachments**.



Tip Embedded images and objects cannot be received as attachments.

An embedded message can be viewed as an attachment when using IMAP4 to receive e-mail. However, this feature does not work if Transport Neutral Encapsulation Format (TNEF) is enabled so that you can receive meeting requests.

To store attachments on a storage card rather than on the device, tap **Menu > Tools > Options > Storage** tab, and select the **Store attachments on storage card** check box.

Receiving Meeting Requests

If you receive your e-mail messages through ActiveSync, you can receive meeting requests. When connecting directly to an e-mail server, the server must be running Microsoft Exchange Server version 5.5 or later for you to receive meeting requests.

If the server is running Microsoft Exchange Server 2000 or later, your meeting requests are automatically received in your Inbox. However, to receive meeting requests on Microsoft Exchange Server 5.5, do the following:

- Ask your system administrator to activate Rich Text Format (RTF) and Transport Neutral Encapsulation Format (TNEF) support for your account.

With TNEF enabled, your messages that are included in other messages as attachments are not received, and you can not know if a message has an attachment until you get the full copy. In addition, download time may be longer.

- Change e-mail download options if your account is not set up to receive attachments.

After you are set up to receive meeting requests, do the following:

1. Open the meeting request.
2. Tap **Accept**, or **Menu > Tentative**, or **Menu > Decline**. If you want, you can also include a message with the response. The response is sent the next time that you synchronize or connect to your e-mail server, and your device calendar is updated.

Creating or Changing a Signature

1. Tap **Start > Messaging**.
2. Tap **Menu > Tools > Options**.
3. Tap **Accounts** tab > **Signatures**.
4. Select the account for which you want to create or change a signature.
5. Select the **Use signature with this account** check box if it is not already selected.
6. Select the **Use when replying and forwarding** check box if wanted.
7. Enter a signature in the box.

To stop using a signature, clear the **Use signature with this account** check box.



Tip You can use a different signature with each Messaging account.

Using Messaging

Composing and Sending Messages

1. In the message list, tap **Menu > Switch Accounts** and select the account.
2. Tap **New**.
3. Enter the e-mail address or text message address of one or more recipients, separating them with a semicolon. To access addresses and phone numbers from **Contacts**, tap **To**.
4. Enter your message. To quickly add common messages, tap **Menu > My Text** and tap a desired message.
5. To check the spelling, tap **Menu > Spell Check**.
6. Tap **Send**.



Tip To set the priority, tap **Menu > Message Options**.

If you are working offline, e-mail messages are moved to the Outbox folder and are sent the next time you connect.

Replying to or Forwarding a Message

1. Tap on the message to open it, and then tap **Menu > Reply**, **Reply All**, or **Menu > Forward**.
2. Enter your response. To quickly add common messages, tap **Menu > My Text** and tap a desired message.
3. To check the spelling, tap **Menu > Spell Check**.
4. Tap **Send**.



NOTE If you want to keep the original text with the outgoing message, tap **Menu > Tools > Options...** then tap the **Message** tab. You must check the **When replying to e-mail, include body** option.

Adding an Attachment to a Message

1. In an open message, tap **Menu > Insert** and tap the item you want to attach: **Picture**, **Voice Note**, or **File**.
2. Select the file you want to attach or record a voice note.



NOTE Embedded objects cannot be attached to messages.

Downloading Messages

To send and receive e-mail for an Outlook E-mail account, begin synchronization through ActiveSync.



Tip By default, messages you send are not saved on your device to help conserve memory. If you want to keep copies of sent messages, in the messaging list, tap **Menu > Tools > Options > Message** tab, and select the **Keep copies of sent items in Sent folder** check box. If your account is an Outlook E-mail or IMAP4 account, you must also select the Sent Items folder for synchronization. To do this, tap **Menu > Tools > Manage Folders** and select the check box next to the folder.

Downloading Messages from a Server

1. Tap **Menu > Switch Accounts** and tap the account you want to use.
2. Tap **Menu > Send/Receive**. The messages on your device and e-mail server are synchronized: new messages are downloaded to the device Inbox folder, messages in the device Outbox folder are sent, and messages that have been deleted from the server are removed from the device Inbox folder.



Tip If you want to read the entire message, tap **Menu > Download Message** while in the message window. If you are in the message list, tap and hold the message, and then tap **Menu > Download Message**. The message is downloaded the next time you send and receive e-mail. This also downloads message attachments if you selected those options when you set up the e-mail account.

The size column in the message list displays the local size and server size of a message. Even when an entire message has been downloaded, these numbers may differ because the size of a message can vary between the server and the device.

Installing an Online Address Book

Many e-mail servers, including servers running Exchange Server, can verify names with an online address book, called a directory service, using Lightweight Directory Access Protocol (LDAP). When you create an e-mail account, your e-mail server's directory service is added to the Address tab, and you are given the option to enable it. After it is enabled, Messaging checks your contact list and then the directory service to verify names that you enter in the To, Cc, and Bcc fields. To enable a directory service or if you want to use additional services, follow these steps:

1. If you are adding a new account, ask your network administrator for the name of the directory service and the server.
2. In the message list, tap **Menu > Tools > Options > Address** tab.
3. In the **In Contacts, get e-mail addresses from** list, select which e-mail address book to check in **All e-mail fields**. **All e-mail fields** are checked first unless you select **None**.
4. If your e-mail server is already listed, select the server's directory service check box to enable it and tap **OK**.
5. If your e-mail service is not listed, tap **Add**.
6. In the **Directory name** and **Server** boxes, enter the LDAP directory and server names.
7. Ask your network administrator if authentication is necessary for your server. If so, select the **Authentication is necessary on this server** check box, and enter your user name and password.
8. To have Messaging check this service, select the **Check name against this server** check box.



Tip To delete a service, tap and hold the service, and tap **Delete**.

While synchronizing your Outlook E-mail account, disable any directory services you have installed by clearing the **Check name against this server** check box. This helps avoid getting error messages when Messaging tries to verify names against the service that you are not connected to.

8 Learning The Basics

Entering Owner Information

Enter your owner information so your HP iPAQ can be returned to you if it is lost.

1. Tap **Start > Settings > Personal tab > Owner Information**.
2. On the **Identification** tab, enter your personal information.



Tip If owner information is displayed on the **Today** screen, you can open and edit the information directly from the **Today** screen.

Using TodayPanel Lite

Icon	Name	Description
	TodayPanel Lite	Change the TodayPanel Lite options or the Today screen settings.
	Battery power	View the amount of battery power remaining. Set the standby period, time duration for turning off the HP iPAQ, and USB charging method.
	Main memory	View the amount of main memory available on the HP iPAQ. View, activate, and stop all running programs from this screen.
	Storage memory	View the amount of storage memory available. View, activate, and stop all running programs from this screen.
	Backlight	View and change the backlight options on the HP iPAQ.

To use TodayPanel Lite, tap the icon of your choice, make the appropriate changes, and tap **OK**.

You can change the TodayPanel Lite icons to compact mode, which allows more space on the **Today** screen. You can also change memory and storage settings to display as percentages instead of file sizes.

To change to compact mode:

1. Tap the **TodayPanel Lite** icon > **Options** to open the TodayPanel Lite application.
2. Tap the **Display Mode** list box and select **Compact**.

To display memory and storage as percentages:

1. Tap the **TodayPanel Lite** icon > **Options** to open the TodayPanel Lite application.
2. Tap the **Display Memory as** list box or the **Display Storage as** list box and select the percentage listed.
3. Tap **OK**.

To remove the TodayPanel Lite application from the Today screen:

1. Tap **Start** > **Settings** > **Today** icon > **Items** tab.
2. Clear the **TodayPanel** check box and tap **OK**.

For more options, visit <http://www.rhinocode.com> to upgrade to TODAYPANEL.PRO.

Viewing the Operating System Information

- Tap **Start > Settings > System tab > About**.

The operating system version displays near the top of the screen.

Changing the Regional Settings

The style in which numbers, currency, dates, and times are displayed is specified in regional settings.

To change the regional settings:

1. Tap **Start > Settings > System tab > Regional Settings > Region** tab.
2. Select your region.

The region you select determines which options are available on the other tabs.

3. To customize additional settings, tap the appropriate tabs and select the options you want.

To change the date and time display, follow steps 1 through 3 above then perform one of the following:

- On the **Time** tab, select the time display options you want.
- On the **Date** tab, select the date display options you want.
- On the **Region** tab, select the region display options you want.
- On the **Number** tab, select the number display options you want.
- On the **Currency** tab, select the currency display options you want.

Adjusting the Volume

You can change the volume for various sounds, such as the sound you hear when you tap program names and menu options.

1. Tap the **Speaker** icon at the top of the screen.
2. Move the system volume slider on the screen, or roll the scroll navigation wheel on the HP iPAQ to the desired volume level.
3. To mute system sounds, tap **Off**.

You can also specify the sound you want to hear for a notification.

1. Tap **Start > Settings > Personal tab > Sounds & Notifications**.
2. On the **Sounds** tab, choose how you want to be notified by selecting the appropriate check boxes.
3. On the **Notifications** tab, in **Event**, tap an event name and choose how you want to be notified by selecting the appropriate check boxes. You can choose from several options, such as a special sound, a message, or a flashing light.



NOTE Turning off sounds and the LED notification helps conserve battery power.

Changing Power Management Settings

1. Tap **Start > Settings > System** tab > **Power**.
2. Tap the **Advanced** tab to select the length of time the HP iPAQ stays on when using battery power or external power.
3. Tap the **USB** tab to select USB charging.

Dimming or Adjusting the Brightness of the Backlight

You can set the backlight to dim after a specified amount of time has elapsed.

1. Tap **Start > Settings > System tab > Backlight**.
2. Tap the **Battery Power** tab or the **External Power** tab.
3. Select the backlight options of your choice.

You can also increase or decrease the brightness of the backlight.

1. Tap **Start > Settings > System tab > Backlight > Brightness** tab.
2. Move the sliders up to increase and down to decrease the brightness.

Installing and Removing Programs

To install programs on your HP iPAQ:

1. Use the mini-USB synchronization cable to connect your HP iPAQ to your personal computer.
2. Follow the instructions in the Installation Wizard provided with the program you want to install.
3. Check the screen on your HP iPAQ to see if any further steps are necessary to complete the program installation.

To remove programs from your HP iPAQ:

1. Tap **Start > Settings > System tab > Remove Programs**.
2. Select the check box for the program(s) you want to remove, then tap **Remove**.



NOTE By removing a program from your HP iPAQ, you may increase available memory on the device.

If programs are lost from your HP iPAQ for any reason, most of them can be re-installed using ActiveSync. On your personal computer, click **Tools > Add/Remove Programs** > check the program to be added > click **OK**.

Opening and Closing Programs

You do not need to exit a program to open another or to conserve memory. The system manages memory automatically.

To open a program, tap **Start**, then tap the program you want from the list. If you don't see the program you want, tap **Start > Programs**.

In most cases, programs automatically stop to free needed memory. However, you can close programs manually if you prefer.

1. Tap **Start > Settings > System tab > Memory > Running Programs** tab.
2. In the **Running Programs** list, tap the program you want to close, then tap **Stop**, or tap **Stop All** to close all open programs

Customizing the HP iPAQ

To get detailed information:

- Tap **Start > Settings > System tab > About**.

The **Version** tab displays important device information, including the type of processor and the amount of memory installed.

The device name is used to identify the HP iPAQ in the following situations:

- Synchronizing with a computer
- Connecting to a network



NOTE If you synchronize multiple devices with the same computer, each device must have a unique name.

To change the device name:

1. Tap **Start > Settings > System > About > Device ID** tab.
2. Enter a name. The device name must begin with a letter, consist of letters from A to Z and numbers from 0 to 9, and cannot contain spaces.

Setting Alarms

1. Tap **Start > Settings > System tab > Clock & Alarms > Alarms** tab.
2. Tap **<Description>** and enter a name for the alarm.
3. Tap the day of the week for the alarm. You can select multiple days by tapping each desired day.
4. Tap the time to open a clock and set the time for the alarm. Then tap **OK**.
5. Tap the **Alarm** icon to specify the type of alarm you want. You can choose a flashing light, a single sound, or a repeating sound.
6. If you choose to play a sound, tap the list next to the **Play sound** check box, then tap the sound you want.

Shortcut Menus

A shortcut menu appears when you tap and hold an item. The menu displays the most common commands for the specific item. For example, you can delete an appointment or send a text message to a contact by using commands on a shortcut menu.

To use a shortcut menu, tap and hold the item. When the menu appears, tap the action you want to perform.

To close a shortcut menu without performing an action, tap anywhere outside the menu.

Showing the Clock in All Programs

The clock may not show in the title bar of certain programs by default. To choose to have the clock always show in the title bar:

1. Tap **Start > Settings > System tab > Clock & Alarms**.
2. On the **More** tab, click to select the **Display the clock on the title bar in all programs** check box.

Creating and Assigning a Category

In the Calendar, Contacts, and Tasks programs, you can use categories to help you organize and group your appointments, contacts, and tasks.

1. From the program, tap an existing item or create a new one.
2. Do one of the following:
 - For an existing item in Calendar and Tasks, tap **Edit > Categories**.
 - For an existing item in Contacts, tap **Menu > Edit > Categories**.
 - For a new item in Calendar, Contacts, and Tasks, tap **Categories**.
3. Tap **New**, enter the category name, then tap **Done**. The new category is automatically assigned to the item.
4. Tap **OK** to return to the appointment, contact, or task.



NOTE Categories are shared between your appointments, contacts, and tasks. A category remains in the list of shared categories as long as it is assigned to at least one appointment, contact, or task.

Adjusting the Speed for Scrolling Through Items in a List

You can scroll through items in a list by rolling the scroll navigation wheel or by using the soft keys on the screen of the HP iPAQ. To change the speed at which scrolling with the soft keys occurs:

1. Tap **Start > Settings > Personal tab > Buttons > Up/Down Control tab**.
2. Under **Delay before first repeat**, move the slider to shorten or lengthen the time that elapses before scrolling begins.
3. Under **Repeat rate**, move the slider to change the time it takes to scroll from one item to the next.

Antenna House XSL Formatter

9 Calendar

Accessing Calendar

Use Calendar to schedule appointments, including meetings and other events. You can display appointments for the day on the **Today** screen.

- To access Calendar, on the **Today** screen, tap **Calendar**, or tap **Start > Calendar** depending on your HP iPAQ model.

Changing the Display of the Work Week

You can customize your calendar so a work week starts on Sunday or Monday and continues from five to seven days.

To change the display of the work week:

1. Tap **Start > Calendar**.
2. Tap **Menu > Options > General** tab and do one or both of the following:
 - To specify the first day of the week, tap **Sunday** or **Monday** in the **1st day of week** box.
 - To specify the number of days to appear in a work week, tap **5-day week**, **6-day week**, or **7-day week** in the **Week view** box.
3. Tap **OK**.

Setting a Default Reminder for All New Appointments

To automatically turn on a reminder for all new appointments:

1. Tap **Start > Calendar**.
2. Tap **Menu > Options > Appointments** tab.
3. Select the **Set reminders for new items** check box.
4. Set the time for the reminder to alert you.
5. Tap **OK**.

Updating an Appointment

To update an appointment on your calendar:

1. Tap **Start > Calendar**.
2. Tap the appointment, then **Edit** to make your changes.
3. Tap **OK**.

Canceling an Appointment

When you delete an appointment in Calendar on your HP iPAQ, it is also deleted on your personal computer the next time you synchronize. If the appointment has not been synchronized with a personal computer, it is deleted only from your HP iPAQ.

1. Tap **Start > Calendar**.
2. In Agenda view, select the appointment to delete.
3. Tap **Menu > Delete**.
4. Tap **Yes** to delete the appointment, or tap **No** to keep it.



NOTE Calendar items can be deleted only from Agenda view or from an open calendar appointment. To delete from other views, open the appointment, and click **Menu > Delete**.

10 Contacts

Creating a Contact

1. On the **Today** screen, tap **Contacts**, or tap **Start > Contacts** depending on your HP iPAQ model.
2. Tap **New** and enter the contact information.
3. When finished, tap **OK**.



NOTE If your contact list has been filtered by a category when you create a contact, that category is automatically assigned to the new contact.

To include a nickname, title, and more, while creating a contact, tap the **Name** arrow.

If most of the contacts you create have phone numbers that begin with the same area code, in the Contacts, tap **Menu > Options** and enter that area code in the **Area code** box.

To get more information about creating contacts, tap **Start > Help** on your HP iPAQ.

Finding a Contact

1. On the **Today** screen, tap **Contacts**, or tap **Start > Contacts** depending on your HP iPAQ model.
2. If you are not in **Name** view, tap **Menu > View By > Name**.
3. Do one of the following:
 - Begin entering a name or phone number in the provided text box until the contact you want is displayed. To show all contacts again, tap the text box and clear the text, or tap the arrow to the right of the text box.
 - Use the alphabetical index displayed at the top of the contact list.
 - Filter the list by categories. In the contact list, tap **Menu > Filter**. Then tap a category you've assigned to a contact. To show all contacts again, select **All Contacts**.



NOTE To search for a contact by entering a name or number, or by using the alphabetical index, you need to be in **Name** view.

Deleting a Contact

1. On the **Today** screen, tap **Contacts**, or tap **Start > Contacts** depending on your HP iPAQ model.
2. Tap and hold the contact to delete.
3. Tap **Delete Contact**.
4. Tap **OK**.

Changing Contact Information

1. Tap **Contacts** or **Start > Contacts** depending on your HP iPAQ model.
2. Tap the contact.
3. Tap **Menu > Edit** and enter the changes.
4. When finished, tap **OK**.

To include a nickname, title, and more, for an existing contact in the contact list, tap the name of the contact, **Menu > Edit**, and tap the **Name** arrow.

Copying a Contact

1. Tap **Contacts** or **Start > Contacts** depending on your HP iPAQ model.
2. Tap and hold the contact you want to copy.
3. Tap **Copy Contact**.
4. Tap the copy of the contact.
5. Tap **Menu > Edit**.
6. Change the contact information as needed and tap **OK**.



NOTE The displayed category is automatically assigned to the new contact.

Sending an E-mail Message to a Contact

1. Tap **Contacts** or **Start > Contacts** depending on your HP iPAQ model.
2. Tap the contact you want to send a message to.
3. Tap the address you want to send a message to.
4. Tap the account you want to send the message from.



NOTE To quickly add a contact's address to a new message, tap the **To**, **Cc**, or **Bcc** line, and tap **Menu > Add Recipient**. Tap the contact you want to send the message to and choose the address, if necessary.

Adding and Removing a Picture

To add a picture to contact information:

1. Tap **Contacts** or **Start > Contacts** depending on your HP iPAQ model.
2. Tap the contact.
3. Tap **Menu > Edit**.
4. Tap **Picture**.
5. Tap the picture you want to add.

To remove a picture from contact information:

1. Tap **Contacts** or **Start > Contacts** depending on your HP iPAQ model.
2. Tap the contact.
3. Tap **Menu > Edit**.
4. Tap **Menu > Remove Picture**.

Working with the Contact List

There are several ways to use and customize the contact list. Here are a few tips on how to make it work for you.

1. On the **Today** screen, tap **Contacts** or **Start > Contacts** depending on your HP iPAQ model.
2. In the contact list, do any of the following:
 - To search for a contact by entering a name or number, or by using the alphabetical index, enter the name or number into the Name view.
 - To see a list of contacts employed by a specific name or company, tap **Menu > View By > Name or Company**.
 - To see a summary of information about a contact, tap the contact. From there you can also send a message.
 - To see a list of available actions for a contact, tap and hold the contact.



NOTE To display a greater number of contacts on the screen, tap **Menu > Options**, select the **Show contact names only** check box, and clear the **Show alphabetical index** check box.

11 Notes

Writing a Note

1. Tap **Start > Programs > Notes**.



NOTE Writing must be selected as the default input mode.

2. In the note list, tap **New**.
3. Write your text on the screen.
4. When finished, tap **OK** to return to the note list.

To select handwritten text, tap and hold next to the writing. As soon as dots appear and before they form a complete circle, quickly drag across the writing.

If a letter crosses three ruled lines, it is treated as a drawing rather than text.

For more information, refer to the on-screen Help by tapping **Start > Help > Contents > Using Notes**.

Converting a Handwritten Note to Typed Text

There may be times when you want to convert a handwritten note to typed text for easier readability. To do this:

1. Tap **Start > Programs > Notes**.
2. Tap the written note you want to convert to text.
3. Tap **Menu > Tools > Recognize**.

 **Tip** To correct a conversion, tap and hold the inaccurate word. Tap **Alternates**, and tap the correct word. If the correct word is not shown, use the keyboard to tap the backspace key and retype the word.

For more details, refer to the on-screen Help, tap **Start > Help > Contents > Using Notes**.

Creating a Copy of a Note

To create a copy of a note:

1. Tap **Start > Programs > Notes**.
2. Use the scroll navigation wheel to select the note you want to copy.
3. Tap **Menu > Create Copy**.

A copy of the note appears in the note list.

For more details, refer to the on-screen Help, tap **Start > Help > Contents > Using Notes**.

Antenna House XSL Formatter

12 Storage Cards

Using Storage Cards

Use optional storage cards for:

- Expanding the memory of your HP iPAQ
- Adding functionality



NOTE Storage cards must be purchased separately and are not included with your HP iPAQ.

To locate information about storage cards, visit <http://www.hp.com/go/ipaqaccessories>.

Installing a Storage Card

To install a storage card into the storage slot on the HP iPAQ:

1. Locate the storage slot on the HP iPAQ.
2. Remove the protective plastic card.
3. Insert the storage card into the storage slot and push the connection edge of the card firmly into the storage slot.



NOTE If your storage card is not recognized, follow the card manufacturer's instructions to install it.

If you have trouble installing a storage card, try the following:

- Be sure the label is facing the front of the HP iPAQ.
- Be sure you are not inserting the card at an angle.
- Be sure you insert the connection area (the metal area) first.

Removing a Storage Card

To remove a Secure Digital (SD) storage card from the storage slot on the HP iPAQ:

1. Close all programs that are using the storage card.
2. Remove the card from the storage slot by **lightly pushing down on the card** to unlock it.
3. When the card disengages and pops up, pull it from the storage slot.



NOTE HP recommends inserting the protective plastic card that came with your HP iPAQ into the storage slot when not in use.

Viewing Content of a Storage Card

Use File Explorer to view the files that are located on your optional storage card.

1. Tap **Start > Programs > File Explorer**.
2. Tap the **Up** soft key at the bottom of the screen, then select the **SD Card** folder to see a list of files and folders.

If the HP iPAQ does not recognize your storage card, try the following:

- Be sure you have firmly pushed the storage card down into the storage slot.
- Be sure to install any drivers that came with the storage card.
- Reset the HP iPAQ by using the stylus to lightly press the **Reset** button.

13 Synchronizing

Copying (or Transferring) Files

You can copy (transfer) files to and from your computer using Explore in ActiveSync and Windows Explorer.

To copy (transfer) files:

1. Connect your HP iPAQ to your personal computer via the mini-USB synchronization cable.
2. On your personal computer, select **Start > Programs > Microsoft ActiveSync**.
3. Select **Explore**.
4. Double-click **My Pocket PC**.
5. On your computer, right-click the **Start** menu, and select **Explore**.
6. Locate the file to be moved.



NOTE You cannot copy preinstalled files or system files.

7. Drag and drop your files between your HP iPAQ and your personal computer. ActiveSync converts the files so that they can be used by the Office Mobile programs, if necessary.

Move your files directly into My Documents on your HP iPAQ (or into a folder inside My Documents), so the programs on your device can locate them.

Migrating Data from Palm Desktop to Microsoft Windows Mobile 5.0

If you used a Palm Operating System (OS) based device before purchasing your HP iPAQ, you need to migrate your data from the Palm Desktop software to Microsoft Windows Mobile 5.0.

To migrate data from Palm Desktop to Windows Mobile 5.0:

1. If you do not already have Microsoft Outlook 98 or higher installed on your personal computer, follow the on-screen instructions to install Outlook 2002 from the *Getting Started CD*.
2. Insert the Companion CD that came with your Palm unit into your personal computer's CD-ROM drive. From the **Discover Your Handheld** screen, select **Install Microsoft Conduits**. Alternatively, you may reinstall the Palm Desktop software. During the configuration process, select **Synchronize your handheld with Microsoft Outlook and Palm Desktop software**.



NOTE Microsoft Outlook must be set as your default e-mail program to properly synchronize with the Palm Desktop software. If you need to change your settings, open Microsoft Outlook, then click **Tools > Options > Other** tab and check the **Make Outlook the default program for E-mail, Contacts, and Calendar** check box. Click **Apply > OK**, and then restart your personal computer.

3. Use the HotSync software located on the Companion CD that came with your Palm unit to synchronize your Palm information with Outlook. Refer to the instructions that came with your Palm unit for help installing or using HotSync.
4. When Outlook is synchronized with your Palm device, uninstall HotSync from your personal computer. Click **Start > Control Panel > double-click Add or Remove Programs**. Select **Palm Desktop**, then click **Remove**. Follow the on-screen instructions.
5. Insert the *Getting Started CD* into your personal computer's CD-ROM drive and follow the on-screen instructions to install ActiveSync on your personal computer and create a partnership between your HP iPAQ and your personal computer.

Wireless Synchronization Cost Saving Tips

How you manage the cost of synchronizing wirelessly from your HP iPAQ depends on your priorities.

To	Do this
Reduce network connection or data transfer costs	Increase the time between scheduled synchronizations, or synchronize manually. Check the details of your rate plan.
Extend battery life	Schedule synchronization less frequently or synchronize manually.
Keep your information up to date	During periods of high mail volume, schedule synchronization at regular but frequent intervals. During periods of low mail volume, schedule synchronization as items arrive.



NOTE The device power-down timer is reset each time you synchronize. If you schedule a synchronization interval that is smaller than the time interval set for the device to automatically power down, the device never turns off to save battery power.

Antenna House XSL Formatter

14 Tasks

Setting the Start and Due Dates for a Task

1. Tap **Start > Programs > Tasks**.
2. Tap the task you want to set start and due dates for.
3. Tap **Edit** and do one or both of the following:
 - Tap **Starts** to enter a start date for the task.
 - Tap **Due** to enter a due date for the task.
4. Tap **OK**.

Showing Start and Due Dates in the Task List

1. Tap **Start > Programs > Tasks**.
2. Tap **Menu > Options**.
3. Select the **Show start and due dates** check box.
4. Tap **OK**.

Setting Options for Displaying Tasks on the Today Screen

If you have a large number of tasks, you may want to specify the kind of tasks that show on the Today screen.

1. Tap **Start > Settings > Personal tab > Today**.
2. Tap the **Items** tab, then select the **Tasks** check box.
3. Tap the word **Tasks** to access Options, then tap the **Options** button.
4. Under **Display number of**, select the type of tasks you want to appear on the Today screen.
5. In the **Category** list, select whether to display only tasks assigned to a specific category or to display all tasks.

Marking a Task as Completed

To mark a task as completed:

1. Tap **Start > Programs > Tasks**.
2. In the task list, select the check box next to the task you want to mark as completed.

To mark an open task as completed:

1. Tap **Edit**.
2. In the **Status** box, tap **Completed**.

15 Product Specifications

System Specifications



NOTE Not all models described are available in all regions. For more information on specifications for your particular model, on your HP iPAQ, tap **Start > Settings > System tab > System Details**.

System Feature	Description
Processor	Samsung SC32442 Processor 400MHz
Operating System	Microsoft® Windows Mobile™ Version 5.0 for Pocket PC
Memory	512 MB or 2.0 GB flash ROM for persistent storage, depending on model 64 MB SDRAM for running applications
External Power	10 watt maximum output AC adapter with detachable heads, voltage range 100 to 240V Switching, Input Current 0.15A Aac max, Input Frequency 50 to 60Hz, Output Voltage 5 Vdc, Output Current 1 Amp
Display	3.5 in (89 mm) diagonal transfective TFT QVGA color, 240 x 320 pixels, 0.057(H) x 0.171(V) mm dot pitch, 16-bit color support, portrait and landscape support with touch screen
LED Backlight	Multi-level brightness adjustment with power save mode
SD Slot	Supports SD memory and 4-bit SDIO
Wired Stereo Headset	3.5mm jack with dual earbud style headset—Included in box of select models only
Antenna	Internal
Audio	Integrated microphone, receiver, stereo speakers and one 3.5mm stereo headphone jack, 3D widening/bass boost/treble adjustment LifeVibes™ Concert Sound EX, and handsfree speakerphone
Battery	1,700 mAh Li-ion removable/rechargeable battery
Bluetooth	Class II device; up to 4 dBm transmit, typical 10 meter range (approximately 33 feet)—High-speed, low-power, short-range wireless communication with other Bluetooth devices

System Feature	Description
LED Indicators:	Flashing amber indicates an event notification or alarm on your HP iPAQ.
Charge and Notification LED	- Solid amber indicates unit is charging. - Solid green indicates unit is fully charged.
Wireless LED	- Flashing blue indicates either or both: - Bluetooth is on - Wi-Fi is on.
Wi-Fi on enhanced model only.	LED off indicates Bluetooth and Wi-Fi are off

Physical Specifications

	US	Metric
Length	4.61in	117.0mm
Width	2.87in	73mm
Depth	0.65in	16.5mm
Weight	4.48oz	127g

Operating Environment

		US	Metric
Temperature	Operating	32° to 104°F	0° to 40°C
	Nonoperating	-4° to 140°F	-20° to 60°C
Relative Humidity	Operating	up to 90%	up to 90%
	Nonoperating	up to 90%	up to 90%
Maximum Altitude	Operating	15,000ft	4,572m
	Nonoperating	40,000ft	12,192m

16 Regulatory Notices

Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

This PDA has been tested and demonstrated compliance when Bluetooth and WLAN are transmitting simultaneously. This PDA must not be co-located or operating in conjunction with any other antenna or transmitter.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by HP may void the user's authority to operate the equipment.

Cables

To maintain compliance with FCC Rules and Regulations, connections to this device must be made with shielded cables having metallic RFI/EMI connector hoods.

Declaration of Conformity for products marked with the FCC logo (United States only)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following 2 conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

If you have questions about the product that are *not* related to this declaration, write to

Hewlett-Packard Company

P. O. Box 692000, Mail Stop 530113

Houston, TX 77269-2000

or call 1-800-HP-INVENT (1-800-474-6836)

For questions regarding this FCC declaration, write to

Hewlett-Packard Company

P. O. Box 692000, Mail Stop 510101

Houston, TX 77269-2000

or call HP at 281-514-3333

To identify your product, refer to the part, series, or model number located on the product.

Canadian Notice

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Avis Canadien

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

European Union Notice

Products bearing the CE marking comply with the following EU Directives:

- Low Voltage Directive 73/23/EEC
- EMC Directive 89/336/EEC

CE compliance of this product is valid only if powered with the correct CE-marked AC adapter provided by HP.

If this product has telecommunications functionality, it also complies with the essential requirements of the following EU Directive:

- R&TTE Directive 1999/5/EC

Compliance with these directives implies conformity to harmonized European standards (European Norms) that are listed in the EU Declaration of Conformity issued by HP for this product or product family. This compliance is indicated by one of the following conformity markings placed on the product.

- This CE marking is valid for non-telecommunications products and for EU harmonized telecommunications products, such as Bluetooth®.



- This CE marking is valid for EU non-harmonized telecommunications products.



*If applicable, a notified body number is used. Refer to the regulatory label provided on this product.

The telecommunications functionality of this product may be used in the following EU and EFTA countries:

Austria, Belgium, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Liechtenstein, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Slovak Republic, Slovenia, Spain, Sweden, Switzerland, and United Kingdom.

Battery Warning



WARNING! This HP iPAQ contains a lithium ion rechargeable battery. To reduce the risk of fire or burns, do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water. Replace only with the HP spare.



CAUTION Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Battery Recycling

HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, visit www.hp.com/recycle.

Equipment Warning



WARNING! To reduce the risk of personal injury, electrical shock, fire or damage to the equipment:

Plug the power cord into an AC outlet that is easily accessible at all times.

Disconnect power from the equipment by unplugging the power cord from the AC outlet or unplugging the synchronization cable from the host computer.

Do not place anything on the power cord or any of the other cables. Arrange them so that no one may accidentally step on or trip over them.

Do not pull on a cord or cable. When unplugging from the electrical outlet, grasp the cord by the plug or, in the case of the AC adapter, grasp the AC adapter and pull out from the electrical outlet.

Do not use converter kits sold for appliances to power your iPAQ Pocket PC.

Medical Electronic Equipment

If you have a medical condition that requires you to use a pacemaker, hearing aid, or any type of medical electronic equipment, consult the manufacturer of the equipment to determine if the medical equipment is shielded from RF energy. Turn off your HP iPAQ in health care facilities or hospitals when there are posted restrictions requiring you to do so.

Wireless Notices

In some environments, the use of wireless devices may be restricted. Such restrictions may apply aboard airplanes, in hospitals, near explosives, in hazardous locations, etc. If you are uncertain of the policy that applies to the use of this device, please ask for authorization to use it prior to turning it on.

U.S. Regulatory Wireless Notice



WARNING! Exposure to Radio Frequency (RF) Radiation The radiated output power of this device is below the FCC radio frequency exposure limits. Nevertheless, the device should be used in such a manner that the potential for human contact during normal operation is minimized.

To avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna should be minimized.

This PDA has been tested and demonstrated compliance when Bluetooth and WLAN are transmitting simultaneously. This PDA must not be co-located or operating in conjunction with any other antenna or transmitter.

Canadian Regulatory Wireless Notice

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Brazilian Notice

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

Japanese Notice

この機器の使用周波数帯では、電子レンジ等の産業・科学・医療用機器のほか工場・製造ライン等で使用されている移動体通信用の屋内無線局（免許を要する無線局）及び特定小電力無線局（免許を要しない無線局）が運用されています。

- 1 この機器を使用する前に、近くで移動体通信用の屋内無線局及び特定小電力無線局が運用されていないことを確認して下さい。
- 2 万一、この機器から移動体通信用の屋内無線局に対して電波干渉の事例が発生した場合には、速やかに使用周波数を変更するか又は電波の発射を停止した上、下記連絡先にご連絡頂き、混信回避のための処置等（例えば、パーティションの設置など）についてご相談して下さい。
- 3 その他、この機器から移動体通信用の特定小電力無線局に対して電波干渉の事例が発生した場合など何かお困りのことが起きたときは、次の連絡先へお問い合わせ下さい。

連絡先：日本イーシーエーカード株式会社 TEL：0120-014121

Wireless LAN 802.11b devices



Wireless LAN 802.11g devices



Taiwan Notice

低功率電波輻射性電機管理辦法

第十四條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十七條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信規定作業之無線電信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

Korean Notice

B급 기기 (가정용 정보통신기기)

이 기기는 가정용으로 전자파적합등록을 한 기기로서
주거지역에서는 물론 모든지역에서 사용할 수 있습니다.

Index

A

- alarms
 - setting 69
- attachments
 - adding to messages 56
 - receiving in messages 54

B

- backlight
 - adjusting brightness 65
 - dimming 65
- Bluetooth
 - COM port 43
 - device profiles 41
 - making a device
 - discoverable 43
 - making connections 41
 - partnerships 42
 - settings 43
 - terms 40
 - working with Bluetooth Manager 40
- Brazilian notice 113

C

- calendar
 - accessing 75
 - canceling appointments 78
 - display of work week 75
 - setting default reminders 76
 - updating appointments 77
- Canadian notice 113
- Canadian notices 108
- categories
 - assigning 72
 - creating 72
- clock
 - setting alarms 69
 - showing in all programs 71
- closing programs 67

Connections

- advanced proxy settings 32
- automatic connection
 - choice 30
- changing an intranet URL 29
- connecting to intranets 28
- connection group name 35
- connections 27
- ending connections 36
- proxy server settings 31
- using advanced connection settings 33
- using VPNs 34

contacts

- adding pictures 85
 - changing information 82
 - copying 83
 - creating 79
 - deleting 81
 - finding 80
 - information summary 86
 - listing 86
 - removing pictures 85
 - searching 86
 - sending e-mail messages 84
 - working with the contact
 - list 86
- cost saving
 - wireless synchronization tips 97
 - customizing the HP iPAQ 68

D

- Declaration of Conformity 108
- device
 - information 68
 - name 68
 - version 68

E

- European Union notices 108

F

- Federal Communications Commission
 - cables 107
 - modifications 107
 - notice 107

G

- GPS
 - configuring my GPS software to connect to HP iPAQ 5
 - identifying the COM port for my GPS receiver 7
 - identifying your HP iPAQ's
 - embedded receiver 8
 - losing the GPS signal
 - frequently 11
 - losing the GPS signal while in my car 10
 - managing GPS
 - automatically 6
 - reasons for interference using GPS software 12
 - using an external antenna with your GPS receiver 9
 - verifying compatibility 4

I

- imaging
 - attaching sounds to pictures 46
 - backing up images 50
 - creating templates 49
 - e-mailing pictures 47
 - editing pictures 49
 - HP Photosmart Mobile 45
 - HP Photosmart Premier 49

- managing pictures 49
- organizing pictures 49
- printing pictures 45, 49
- sending pictures 45
- sharing pictures 50
- viewing a slideshow 48
- viewing pictures 45, 49
- IMAP4 messaging
 - folders 52
- installing programs 66

J

- Japanese notice 114

K

- Korean notice 116

M

- meeting requests
 - receiving by e-mail 54
- messaging
 - adding attachments to messages 56
 - composing messages 56
 - downloading messages 56
 - downloading messages from a server 57
 - forwarding messages 56
 - IMAP4 52
 - online address book 57
 - Outlook e-mail 52
 - POP3 52
 - receiving attachments 54
 - receiving meeting requests 54
 - replying to messages 56
 - sending e-mail messages to contacts 84
 - sending messages 56
 - signatures 55
 - synchronizing e-mail 53
 - using folders 52
- migrating data from Palm Desktop to Windows Mobile 96
- modifications, Federal Communications Commission 107

N

- notes
 - converting handwritten notes to typed text 88

- copying 89
- writing 87
- notices
 - Brazilian 113
 - Canadian 108, 113
 - European Union 108
 - Federal Communications Commission 107
 - Japanese 114
 - Korean 116
 - Taiwan 115

O

- opening programs 67
- operating environment specifications 106
- operating system
 - viewing information 61
- organizing appointments, contacts, and tasks 72
- Outlook e-mail
 - folders 52
- owner information
 - entering 59

P

- physical specifications 105
- POP3 messaging
 - folders 52
- power management
 - changing settings 64
- programs
 - closing 67
 - installing 66
 - opening 67
 - removing 66

R

- regional settings
 - changing 62
- registering your iPAQ 1
- registration 1
- removing programs 66

S

- scrolling speed 73
- shortcut menus 70
- specifications
 - operating environment 106
 - physical 105
 - system 103

- storage cards
 - installing 92
 - removing 93
 - using 91
 - viewing content 94
- synchronization
 - migrating from Palm Desktop to Windows Mobile 96
- synchronizing
 - copying files 95
 - extending battery life 97
 - keeping information up to date 97
 - reducing network connection or data transfer costs 97
 - transferring files 95
 - wireless cost saving tips 97
- synchronizing e-mail 53
- system specifications 103

T

- Taiwan notice 115
- tasks
 - marking as completed 102
 - setting display options 101
 - setting start and due dates 99
 - showing start and due dates 100
- TodayPanel Lite 60

V

- viewing operating system information 61
- volume
 - adjusting 63

W

- Wi-Fi
 - accessing corporate networks 37
 - automatically connecting 38
 - configuring 802.1x authentication settings 39
 - connecting to an 802.11b/g WLAN 37
 - connecting to the Internet 37
 - deleting wireless networks 39
 - finding an IP address 38
 - manually connecting 38
 - terms 37
 - using hotspots 37

using VPNs 37
WLAN-enabled devices 37
wireless LAN devices 113
wireless synchronization cost
saving tips 97

Antenna House XSL Formatter

Antenna House XSL Formatter

Antenna House XSL Formatter

