


1. INTRODUCTION

The Door/Window Sensor is designed to monitor any door or window within your house. When the monitored window or door is opened, the receiver will alert you. It will beep and flash.

In this package, you should find a sensor, a magnet, 3V lithium battery, a clip and other mounting accessories.



Please follow the instructions below to set up the door / window sensor.

2. SET UP THE DOOR/WINDOW SENSOR

To program the sensor to the Control Panel AM-001

1. Press the [PROG] button on the side of the control panel, the [PROG] LED will light on.
2. Enter the current MPIN [default 1234].
3. Enter [3].
4. Select a zone and sensor location to program the sensor to.
5. Activate the sensor, the control panel will beep and you will hear "Zone $\times$ Sensor $\times$ Accepted if the sensor is programmed. The [PROG] LED will be off.
6. To program other sensor, repeat the above steps.


Notes: If an occupied sensor location is selected, the new sensor will replace the old one.

3. POWER UP THE DOOR/WINDOW SENSOR


The lithium battery is already inserted into the unit from factory. Remove the plastic strap from the battery terminal to power up the sensor.

Before apply the power, keep the magnet away from the sensor. After remove the plastic strap from the unit, the receiver will beep and flash.

You are now ready to install the sensor and the magnet to a door or window.



When the magnetic contact is closed, the receiver will not beep.



When the magnetic contact is broken (open), the receiver will beep and a LED will flash.


4. INSTALLATION

SELECT A MOUNTING LOCATION

The sensor should be mounted on the door / window frame and the magnet should be mounted on the door / window itself. Mount the sensor or magnet as high as possible.


You should find a grey alignment marking on one side of the sensor. The magnet should be in contact with this marking when the door / window is closed (Refer to Diagram A).

4. INSTALLATION CON'T



If the surface of the frame is flat enough, double-sided foam tape is sufficient, otherwise, it is recommended to use the mounting plate and screws as well.

After mounting the sensor, put the cover back on with the Skylink® logo in the upright position.



5. FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

6. WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

7. CUSTOMER SERVICE

If you would like to order Skylink's products or have difficulty getting them to work, please :

1. visit our FAQ section at www.skylinkhome.com, or
2. email us at support@skylinkhome.com, or
3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST.

Fax (800) 286-1320

CUSTOMER SERVICE

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3
Email: support@skylinkhome.com
<http://www.skylinkhome.com>
P/N 101AXXX Rev.0
©2005 SKYLINK GROUP


Water Alert

Model FS-101

1. INTRODUCTION

The Water Alert is designed to detect water overflow, water leakage, or rising water, such as the water level of your bathtub. When water is detected, the receiver will beep & flash.

In this package, you should find a water sensor, a Household Alert® receiver, an adapter, 3V lithium battery and a clip.



Please follow the instructions below to set up the water sensor and the receiver.

2. PROGRAM THE SENSOR TO THE CONTROL PANEL


To program the sensor to the Control Panel AM-001

1. Press the [PROG] button on the side of the control panel, the [PROG] LED will light on.
2. Enter the current MPIN [default 1234].
3. Enter [3].
4. Select a zone and sensor location to program the sensor to.
5. Activate the sensor, the control panel will beep and you will hear "Zone x Sensor x Accepted if the sensor is programmed. The [PROG] LED will be off.
6. To program other sensor, repeat the above steps.

Notes: If an occupied sensor location is selected, the new sensor will replace the old one.


3. POWER UP THE AND WATER SENSOR

After inserting the battery to the water sensor, you can test the water sensor by submerging the sensor portion in water. Note: Only the sensor portion of the water sensor is waterproof, the transmitter portion should never be submerged in water.



Sensor portion

Sensor portion being submerged into the water, receiver beeps and red LED flashes.





Remove the sensor portion from the water, receiver stops beeping and red LED stops flashing.

4. INSTALLATION

A clean smooth surface is required to mount the water sensor securely. Mount the transmitter portion and sensor portion to the appropriate location with suction cups respectively.

Note: The transmitter portion should never be submerged in water.



5. OPERATION

When the sensor portion detects water overflow, water leakage, or rising water, the receiver will beep and the corresponding zone red LED light will flash.

6. FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

7. CUSTOMER SERVICE

If you would like to order Skylink's products or have difficulty getting them to work, please :

1. visit our FAQ section at www.skylinkhome.com, or
 2. email us at support@skylinkhome.com, or
 3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST.
- Fax (800) 286-1320

CUSTOMER SERVICE

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3
Email: support@skylinkhome.com
<http://www.skylinkhome.com>
P/N 101AXXX Rev.0
©2005 SKYLINK GROUP