

Frequency Alignment Procedure of #630211 Lulla Bear

1. Transmitter

- a) Connect the transmitter unit to the DC power supply (+9VDC);
- b) Use the Spectrum Analyzer to monitor the frequency;
- c) Slide the channel selector to CH-A position, adjust the coil T2 on the PCB until the frequency reading on the Spectrum Analyzer is 49.845MHz +/-0.005MHz;
- d) Slide the channel selector to CH-B position, adjust the coil T3 on the PCB until the frequency reading on the Spectrum Analyzer is 49.865MHz +/-0.005MHz;
- e) Use the wax to seal and fix the coil T2 & T3.

2. Receiver

- a) Connect the receiver unit to the DC power supply (+6.0VDC);
- b) Connect a frequency counter across R2 to monitor the frequency;
- c) Slide the channel selector to CH-B position, the frequency reading on the frequency counter will be 49.79MHz +/-0.005MHz [49.865MHz – 0.075MHz (local oscillator) = 49.79MHz];
- d) Slide the channel selector to CH-A position, adjust the coil L9 on the PCB until the frequency reading on the frequency counter is 49.77MHz +/-0.005MHz [49.845MHz – 0.075MHz (local oscillator) = 49.77MHz];
- e) Use the wax to seal and fix the coil L9.