


Package Contents

- CBW383G1IND cable modem * 1
- Quick Installation Guide * 1
- RJ-45 CAT 5E cable * 1
- 12 V/1A Power Adaptor * 1

Rear Panel and Hardware Connection

This chapter describes the proper steps for connecting your cable modem. Please be sure to follow the steps in the sequence outlined below. Failure to do so could result in improper operation or failure of your cable modem.



Step 1: Connect a cable by feeding the F-connector on the back of the cable modem. Ensure the center conductor of the 75 ohm coaxial cable is inserted directly into the center of the F-connector. Secure the coaxial cable by carefully threading the outer shell of the coaxial cable connector onto the F-connector in a clockwise direction until tight. Be careful not to over-tighten the connector or you may damage either the connector or the cable modem.

Step 2: Connect the cable modem to an IEEE 802.3 10Base-T / 802.3u 100Base-TX / 802.3ab 1000Base-T Network using a RJ-45 male-terminated Ethernet cable. This cable modem equips with one Ethernet port, you can connect PC to the cable modem.

Step 3: Connect the AC Adapter to the cable modem by inserting the barrel-shaped connector into the mating power connector on the back of the cable modem. Exercise carefully to ensure the connectors are properly aligned prior to insertion and ensure the two connectors engage completely. The cable modem is shipped with an AC adapter. Remember to use only power adapter that came with the cable modem. Other power adapters might have voltages that are not correct for your particular cable

modem. Using a power adapter with the wrong voltage can damage the cable modem.

Step 4: Adjust the antenna if necessary.

Front Panel & LEDs

There are seven Light-Emitting-Diodes (LEDs) located on the front panel top provide status information to the user.



LED	NAME	COLOR	MODE	STATUS
	POWER	Green	On	DC power connected
			Off	No DC power connected
	DS	Green	Blinking	Downstream scanning
			On	Downstream locked
			Off	Cable interface idle
		Orange	On	W/DS locked
			Off	W/DS disabled or CM standby
	US	Green	Blinking	Upstream ranging
			On	Upstream locked
			Off	Cable interface idle
		Orange	On	W/US locked
			Off	W/US disabled or CM standby
	ONLINE	Green	Blinking	CM provisioning
			On	CM on-line
			Off	Cable interface idle
LINK	LAN	Green & Orange	On	ETH device connected (Green: GbE, Orange: FE)
			Blinking	Data in traffic
			Off	No ETH device connected
WPS	WPS	Green	Blinking	WPS in paring
			On	WPS enabled
			Off	WPS disabled
	Wi-Fi	Green	On	WiFi enabled
			Blinking	Data in traffic
			Off	WiFi disabled

Accessing the Web Management

For easy-changing the default settings, a Web-based GUI is built-in for your access. Use the following procedures to login to your CBW383G1IND.

1. Open your web browser. Type the default IP address of the CBW383G1IND (e.g. <http://192.168.0.1>) and press Enter.

Configuring Your WAN Connection

The DHCP page allows you to activate/deactivate the DHCP server function of the CBW383G1IND, and, if the DHCP server is activated, to see DHCP leases it has provided.

The screenshot shows the web management interface of the CBW383G1IND. The top navigation bar includes 'Status', 'Basic', 'Advanced', 'Firewall', and 'Wireless'. The 'Basic' tab is selected. On the left sidebar, there are buttons for 'Setup', 'DHCP', 'DNS', and 'Backup'. The main content area is titled 'Basic' and 'DHCP'. It contains a description: 'This page allows configuration and status of the optional internal DHCP server for the LAN.' Below this, there are configuration options: 'DHCP Server' with radio buttons for 'Yes' (selected) and 'No'; 'Starting Local Address' set to '192.168.0.10'; 'Number of Clients' set to '245'; and 'Lease Time' set to '3600'. An 'Apply' button is located below these settings. A box highlights the 'DHCP Server' radio buttons and the 'Starting Local Address' field. Below the configuration section, there is a table for 'DHCP Clients' with columns: 'MAC Address', 'IP Address', 'Subnet Mask', 'Duration', 'Expires', and 'Select'. The table currently shows 'No DHCP Clients'. At the bottom, there is a 'Current System Time' field and a 'Force Available' button.

Enable CBW383G1IND's DHCP server to allocate IP address to the connected LAN client (PC) and configure the Starting Local Address to be issued. You can also set the maximum number of PCs to which the CBW383G1IND will issue IP addresses and the release time (in second).

Check your CBW383G1IND Access Information

There is a label pasted to the bottom of CBW383G1IND case. In that label, you can obtain following information. Pls note, following label is just an example, each CBW383G1IND has their own label and setting value. Pls follow your label information to access and configure CBW383G1IND. In normal case, you don't need to change anything, all setting have been set and work properly.

SSID:
CBW383G1IND_D52D-G

WPA2-PSK passphrase

Web Management:
<http://192.168.0.1>
login: admin
password: password

SSID: This is used for your CBW383G1IND wireless setting use, and, this setting has already been set to your CBW383G1IND.

WPA Pre-Shared Key: This is the password for your wireless client when connecting to CBW383G1IND. You will be asked to key in this password so as to connect via wireless connection.

Web Management: This is the URL when you like to access to CBW383G1IND. You can simply type <http://192.168.0.1> in Microsoft Internet Explorer or any other internet browser to access CBW383G1IND web management page.

Login: This is the value when accessing CBW383G1IND web management page. You will be asked to key in this default value to access CBW383G1IND.

Password: This is the value when accessing CBW383G1IND web management page. You will be asked to key in this default value to access CBW383G1IND.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with FCC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device is intended only for OEM integrators under the following conditions:

- 1) The antenna must be installed such that 20 cm is maintained between the antenna.
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

As long as 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed (for example, digital device emissions, PC peripheral requirements, etc.).

IMPORTANT NOTE: In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

FCC Statement

This device complies with Class B Part 15 of the FCC Rules. The device generates, uses and can radiate radio frequency energy and, if not installed and used as instructed, may cause harmful interference to radio communication. Only Coaxial cables are to be used with this device in order to ensure compliance with FCC emissions limits. Accessories connected to this device by the user must comply with FCC Class B limits. The manufacturer is not responsible for any interference which results from use of improper cables, or which results from unauthorized changes or modifications to the device.

"A Minimum 26 AWG Line Core should be used for connection to the cable modem

Operation is subject to the following two conditions:

this device may not cause interference and

this device must accept any interference, including interference that may cause undesired operation of the device.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment with IC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with IC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

Warranty

Items sold by manufacturer/distributor/agent, hereinafter called "Seller", are warranted only as follows: Except as noted below Seller will correct, either by repair or replacement at its option, any defect of material or workmanship which develops within one year after delivery of the item to the original Buyer provided that evaluation and inspection by Seller discloses that such defect developed under normal and proper use. Repaired or replaced items will be further warranted for the unexpired term of their original warranty. All items claimed defective must be returned to Seller, transportation charges prepaid, and will be returned to the Buyer with transportation charges collect unless evaluation proves the item to be defective and that the Seller is responsible for the defect. In that case, Seller will return to Buyer with transportation charge prepaid. Seller may elect to evaluate and repair defective items at the Buyer's site. Seller may charge Buyer a fee (including travel expenses, if needed) to cover the cost of evaluation if the evaluation shows that the items are not defective or that they are defective for reasons beyond the scope of this warranty.

The Seller makes no warranty concerning components or accessories not manufactured by it. However, in the event of failure of such a part, Seller will give reasonable assistance to Buyer in obtaining from the manufacturer whatever adjustment is reasonable in light of the manufacturer's own warranty. Seller will not assume expense or liability for repairs made outside the factory by other than Seller's employees without Seller's written consent.

SELLER IS NOT RESPONSIBLE FOR DAMAGE TO ANY ASSOCIATED EQUIPMENT, NOR WILL SELLER BE HELD LIABLE FOR INCIDENTAL, CONSEQUENTIAL, OR OTHER DAMAGES. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING THE IMPLIED WARRANTY OF "MERCHANTABILITY" AND "FITNESS FOR PARTICULAR PURPOSE."

Note to CATV System Installer

"The EUT must be bonding the screen of the coaxial cable to the earth at the building entrance per ANSI/NFPA 70, the National Electrical Code (NEC), in particular Section 820.93, Grounding of Outer Conductive Shield of a Coaxial Cable."

Trademarks

All trademarks are the property of their respective owners.