


Package Contents

- CGA0101 cable modem * 1
- Quick Installation Guide * 1
- RJ-45 CAT 5e cable * 1
- 12 V/1.5 A Power Adaptor * 1
- Telephone cord * 1

Rear Panel and Hardware Connection

This chapter describes the proper steps for connecting your cable modem. Please be sure to follow the steps in the sequence outlined below. Failure to do so could result in improper operation or failure of your cable modem.

Please be reminded this product CGA0101v2 is designed to stand in vertical position in order to keep the ventilation as clear as possible. Please do not put it down horizontally.



Step 1: Connect a cable by feeding the F-connector on the back of the cable modem. Ensure the center conductor of the 75 ohm coaxial cable is inserted directly into the center of the F-connector. Secure the coaxial cable by carefully threading the outer shell of the coaxial cable connector onto the F-connector in a clockwise direction until tight. Be careful not to over-tighten the connector or you may damage either the connector or the cable modem.

Step 2: Connect the cable modem to IEEE 802.3 10Base-T / 802.3u 100Base-TX / 802.3ab 1000Base-T Network using a RJ-45 male-terminated Ethernet cable. This cable modem equips with two Ethernet ports, you can connect two PCs to the cable modem at the same time if necessary.

Step 3: Connect the telephone sets to TEL. Use RJ-11 telephone line to connect TEL port on the cable modem and telephone socket on telephone

Step 4: Connect the AC Adapter to the cable modem by inserting the barrel-shaped connector into the mating power connector on the back of the cable modem. Exercise carefully to ensure the connectors are properly aligned prior to insertion and ensure the two connectors engage completely. The cable modem is shipped with an AC adapter. Remember to use only power adapter that came with the cable

CGA0101v2 *Wireless Cable Gateway* Quick Installation Guide

modem. Other power adapters might have voltages that are not correct for your particular cable modem. Using a power adapter with the wrong voltage can damage the cable modem.

Step 5: Adjust the antenna if necessary.



Step 6: The screen of the coaxial cable is intended to be connected to earth in the building installation.

Front Panel & LEDs

There are nine Light-Emitting-Diodes (LEDs) located on the front panel top provide status information to the user.



CGA0101v2 Wireless Cable Gateway Quick Installation Guide

LED	NAME	COLOR	MODE	STATUS
	POWER	Green	On	DC power connected
			Off	No DC power connected
	DS	Green	Blinking	Downstream scanning
			On	Downstream locked
			Off	Cable interface idle
		Green	On	W/DS locked
			Off	W/DS disabled or CM standby
	US	Green	Blinking	Upstream ranging
			On	Upstream locked
			Off	Cable interface idle
		Green	On	W/US locked
			Off	W/US disabled or CM standby
	ONLINE	Green	Blinking	CM provisioning
			On	CM on-line
			Off	Cable interface idle
	LAN1	Green & Orange	On	ETH device connected (Green: GbE, Orange: FE)
			Blinking	Data in traffic
			Off	No ETH device connected
	LAN2	Green & Orange	On	ETH device connected (Green: GbE, Orange: FE)
			Blinking	Data in traffic
			Off	No ETH device connected
	Wi-Fi	Green	On	WiFi enabled
			Blinking	Data in traffic
			Off	WiFi disabled
	WPS	Green	Blinking	WPS in paring
			On	WPS enabled
			Off	WPS disabled
	TEL	Green	Blinking	TEL provisioning or off-hook
			On	TEL on-hook
			Off	TEL disabled

CGA0101v2 *Wireless Cable Gateway* Quick Installation Guide

Accessing the Web Management

For easy-changing the default settings, a Web-based GUI is built-in for your access. Use the following procedures to login to your CGA0101v2.

1. Open your web browser. Type the default IP address of the CGA0101v2 (e.g. <http://192.168.0.1>) and press Enter.

Configuring Your WAN Connection

The DHCP page allows you to activate/deactivate the DHCP server function of the CGA0101v2, and, if the DHCP server is activated, to see DHCP leases it has provided.

Residential Gateway - Basic Setup

192.168.1.1/RgSetup.asp

Status Basic Advanced Firewall Parental Control VPN Wireless MTA

Basic Setup

This page allows configuration of the basic features of the broadband gateway related to your ISP's connection.

LAN

IP Address: 192.168.1.1

MAC Address: 00:30:54:de:ad:95

Interface/Prefix

None Specified

WAN

IP Address: 20.20.250.11

MAC Address: 00:30:54:69:07:18

Duration: D: 00 H: 00 M: 05 S: 00

Expires: Wed Oct 29 10:21:45 2014

IPv4 DNS Servers: 168.95.1.1, 192.168.10.2

Release WAN Lease Renew WAN Lease

WAN Connection Type: DHCP

IPv4 MTU Size: 0 (256-1500 octets, 0 = use default)

Spoofed MAC Address: 00:00:00:00:00:00

Apply

Enable CGA0101v2's DHCP server to allocate IP address to the connected LAN client (PC) and configure the Starting Local Address to be issued. You can also set the maximum number of PCs to which the CGA0101 will issue IP addresses and the release time (in second).

Check your CGA0101v2 Access Information

There is a label pasted to the bottom of CGA0101v2 case. In that label, you can obtain following information. Pls note, following label is just an example, each CGA0101v2 has their own label and setting value. Pls follow your label information to access and configure CGA0101v2. In normal case, you don't need to change anything, all setting have been set and work properly.

SSID:

CGA0101v2_8C9D

WPA2-PSK(TKIP+AES)

Web Management:

<http://192.168.0.1>

login: admin

password: password

SSID: This is used for your CGA0101v2 wireless setting use, and, this setting has already been set to your CGA0101v2.

WPA Pre-Shared Key: This is the password for your wireless client when connecting to CGA0101v2. You will be asked to key in this password so as to connect via wireless connection.

Web Management: This is the URL when you like to access to CGA0101v2. You can simply type <http://192.168.0.1> in Microsoft Internet Explorer or any other internet browser to access CGA0101v2 web management page.

Login: This is the value when accessing CGA0101v2 web management page. You will be asked to key in this default value to access CGA0101v2.

Password: This is the value when accessing CGA0101v2 web management page. You will be asked to key in this default value to access CGA0101v2.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with FCC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Statement

This device complies with Class B Part 15 of the FCC Rules. The device generates, uses and can radiate radio frequency energy and, if not installed and used as instructed, may cause harmful interference to radio communication. Only Coaxial cables are to be used with this device in order to ensure compliance with FCC emissions limits. Accessories connected to this device by the user must comply with FCC Class B limits. The manufacturer is not responsible for any interference which results from use of improper cables, or which results from unauthorized changes or modifications to the device.

"A Minimum 26 AWG Line Core should be used for connection to the cable modem"

Canada-Industry Canada (IC)

Operation is subject to the following two conditions:

this device may not cause interference and

this device must accept any interference, including interference that may cause undesired operation of the device.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment with IC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with IC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

Warranty

Items sold by manufacturer/distributor/agent, hereinafter called "Seller", are warranted only as follows: Except as noted below Seller will correct, either by repair or replacement at its option, any defect of material or workmanship which develops within one year after delivery of the item to the original Buyer provided that evaluation and inspection by Seller discloses that such defect developed under normal and proper use. Repaired or replaced items will be further warranted for the unexpired term of their original warranty. All items claimed defective must be returned to Seller, transportation charges prepaid, and will be returned to the Buyer with transportation charges collect unless evaluation proves the item to be defective and that the Seller is responsible for the defect. In that case, Seller will return to Buyer with transportation charge prepaid. Seller may elect to evaluate and repair defective items at the Buyer's site. Seller may charge Buyer a fee (including travel expenses, if needed) to cover the cost of evaluation if the evaluation shows that the items are not defective or that they are defective for reasons beyond the scope of this warranty.

The Seller makes no warranty concerning components or accessories not manufactured by it. However, in the event of failure of such a part, Seller will give reasonable assistance to Buyer in obtaining from the manufacturer whatever adjustment is reasonable in light of the manufacturer's own warranty. Seller will not assume expense or liability for repairs made outside the factory by other than Seller's employees without Seller's written consent.

SELLER IS NOT RESPONSIBLE FOR DAMAGE TO ANY ASSOCIATED EQUIPMENT, NOR WILL SELLER BE HELD LIABLE FOR INCIDENTAL, CONSEQUENTIAL, OR OTHER DAMAGES. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING THE IMPLIED WARRANTY OF "MERCHANTABILITY" AND "FITNESS FOR PARTICULAR PURPOSE."

Note to CATV Sysrem Installer

"The EUT must be bonding the screen of the coaxial cable to the earth at the building entrance per ANSI/NFPA 70, the National Electrical Code (NEC), in particular Section 820.93, Grounding of Outer Conductive Shield of a Coaxial Cable."

Trademarks

All trademarks are the property of their respective owners.