


GQ802MKG


User's Manual


Driver Installation

1. Go to the directory where the Wireless Adapter Installation stored, then double-click **Setup.exe** to begin the installation.



3. **RALINK Wireless Network Card Setup** will install the driver on your system, click **Next** to continue.






4. Select the Country Channel, and click **Next** to continue.



5. The installation is now complete. Please click **Finish**.




6. When you complete the installation, the utility icon will appear on the system tray. You could double-click it to configure wireless network settings




Uninstalling the Wireless LAN Card


1. For uninstalling the Wireless LAN Card, please go to: **Start** -> **Programs** -> **Ralink** -> **RT2500** under Windows environment. Then click **Uninstall**.




2. Select **Remove** to uninstall the Wireless LAN Card.



3. The **Confirm Uninstall** screen will display, click **OK** to confirm.



4. Wait for removing the utility.



5. After completing the uninstallation, click **OK**.




Configuring the Wireless LAN Card

Double-click the utility icon  in your system tray to begin the utility configuration.

Connecting to an existing network


Select **Site Survey** Tab, all available Access Points would be listed.
Click on the desired Access Point, and click **Connect** to connect.




Configuration

- Profile

The **Profile Tab** allows you to set values for all parameters by selecting a previously defined profile. To create a profile, click **Add**, type a profile name and set the corresponding parameters. If one of the profiles is no longer used, you may remove it by clicking the **Delete** button. After changing parameters, click the **Activate** button to take effect. You can have multiple profiles and modify the profile at any time.



- Link Status



Status

The field shows the association status to available Access Point with SSID<->MAC address of the Access Point.

Current Channel

Shows the channel on which the connection is made.

Current Tx Rate

Shows the highest transmit rate of the current association.

Throughput (Kbits/sec)

This displays the instantaneous wireless Receive and Transmit throughput in Kbits per second.

Link Quality / Signal Strength


The Link Quality and Signal Strength bar graph is only active when the node is in Infrastructure Mode. The bar graph displays the quality and strength of the link between the node and its Access Point.

- **Site Survey**

Site Survey Tab lists the features of the available Access Points within range of the Wireless Adapter's signal.

Click on the desired Access Point, and click **Connect** to connect.


You may click **Rescan** to refresh the list.



Add to Profile

You may select an Access Point, and click **Add to Profile** to include it to Profile List.


Under **Add Profile** screen / **System Configuration** Tab, you may set **Power Saving Mode**, **Network Type**, **Transmit Power**, **RTS Threshold**, and **Fragment Threshold**.



The screenshot shows the 'Add Profile' dialog box with the 'System Configuration' tab selected. The 'Profile Name' is 'PROF3' and the 'SSID' is '6F'. The 'Power Saving Mode' section has 'CAM (Constantly Awake Mode)' selected. The 'Network Type' is 'Infrastructure' and 'Transmit Power' is '100 %'. The '11B Preamble Type' is 'Auto'. The 'RTS Threshold' is set to 0 and the 'Fragment Threshold' is set to 256. Both thresholds have a range from 0 to 2312. The 'OK' and 'Cancel' buttons are at the bottom.


Under **Add Profile** screen / **Authentication vs. Security** Tab, you may set **Authentication Type**, **Encryption Type**, **WPA Pre-Shared Key**, and **Wep Key**. Click **OK** when you have finished the settings.

Or click **Cancel** to abort your new settings for Add to Profile.




The screenshot shows the 'Add Profile' dialog box with the 'Authentication vs. Security' tab selected. The 'Authentication Type' is 'WPA-PSK' and the 'Encryption Type' is 'TKIP'. The 'WPA Pre-Shared Key' field is empty. The 'Wep Key' section has four keys, each with a 'Hexadecimal' dropdown and an empty text field. The 'OK' and 'Cancel' buttons are at the bottom.

After fishing the Add Profile, Check **Profile** Tab, you may find the new added profile in Profile List.




- Statistics

The **Statistics** Tab provides information about the Transmit and Receive frames.




- Advance

The Configuration Utility also offers the advanced configuration for user to set the Wireless Adapter under certain network environment. These advanced options include Wireless Mode, Adhoc Mode, TX Burst, B/G Protection, Tx Rate, and Turn Off RF.



- About

About Tab shows the product version including the detail of Configuration Utility Version, Driver Version, EEPROM Version, and NIC MAC Address.



Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

"GQ802MKG declare that GQ802MKG is limited in CH1~CH11 by specified firmware controlled in USA."

This device is intended only for OEM integrators under the following conditions:

- 1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

As long as 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed (for example, digital device emissions, PC peripheral requirements, etc.).

IMPORTANT NOTE: In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

End Product Labeling

This transmitter module is authorized only for use in device where the antenna may be installed such that 20 cm may be maintained between the antenna and users (for example: Notebook). The final end product must be labeled in a visible area with the following: "Contains TX FCC ID:RUJ-GQ802MKG".

Manual Information That Must be Included

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the users manual of the end product which integrate this module.

The end users manual for OEM integrators must include the following information in a prominent location “ IMPORTANT NOTE: To comply with FCC RF exposure compliance requirements, the antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Canada-Industry Canada(IC)

Operation is subject to the following two conditions: 1) this device may not cause interference and 2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate with an antenna having a maximum gain of 1.35dBi. Antenna having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.