

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		1 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

Manual

ST4930

Suntech International Ltd.

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		2 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

Table of Contents

1. Introduction.....	4
2. Overview.....	4
2-1. Operation modes	4
2-2. Reports sent by device.....	5
2-3. Parameter change.....	5
2-4. Features	5
3. Detailed Description on Event Lines and Features	7
3-3. Alert of Buzzer	7
3-3-1. Related with over-speed	7
3-4. Indication with Two(2) LEDs	7
3-4-1. Red LED for GPS.....	7
3-4-2. Blue LED for LTE CAT M-1/NB-IoT/BLE	7
3-5. Power Saving	8
3-6. BackupBattery	오류! 책갈피가 정의되어 있지 않습니다.
3-7. Motion Sensor.....	10
3-8. Protection of Vehicle Battery	11
3-9. Storage of Reports un-sent.....	11
Revisions.....	12

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		3 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

Disclaimer

We, at Suntech, announce that this document and all other related products (i.e. device, firmware, and software) have been developed by the company, Suntech International Ltd., which is hereinafter referred to as "Suntech". The information in this manual is believed to be accurate and reliable at the time of releasing. We, at Suntech, also assume no responsibility for any damage or loss resulting from the use of this manual, and expressly disclaim any liability or damages for loss of data, loss of use, and property damage of any kind, direct, incidental or consequential, in regard to or arising out of the performance or form of the materials presented herein or in any software program(s) that may accompany this document. When this document is released, it is most compatible with a specified firmware version. Now that the functionalities of the devices are being developed and improved continuously from time to time by Suntech, any alteration on the protocol, the firmware functions, the hardware specifications of the product is subject to change without prior notice.

Copyright

We, at Suntech, notify that Suntech holds all parts of intellectual rights applicable in the copyright laws in all the countries. The information contained in this document cannot be reproduced in any form without prior written consent made by Suntech. Any software programs that might accompany this document can be used only in accordance with any license agreement(s) between the purchaser and Suntech.

Warning

Our customers are required to be aware that connecting the wire inputs can be hazardous to both of the installer and your vehicle's electrical system(s) if not done by an experienced installer. This document assumes you are aware of the inherent dangers of working in installing the device on the vehicle(s) and the machinery.

Document Amendments

When it comes to the firmware version column with specific firmware number, any amendment(s) on the comments column should be made on this relevant firmware version (and the versions thereafter). Before applying any changes made in this protocol, you are required to make sure that you have upgraded the firmware suitable for the specified version.

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		4 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

1. Introduction

ST4930

The ST4930 is a vehicle tracking and controlling device. It is designed to collect location data through GPS technology, various vehicle conditions through event lines, and interact remotely with its server by using LTE Cat M1/NB-IoT, BLE technology.

In order to make the vehicle tracking system work, device should be configured and installed properly on a vehicle whose geographical position and/or state is desired to be remotely monitored and/or controlled.

Please note that this Operation Manual is for the standard model. In case specific requirements are incorporated into this Manual, such a manual applies only for the case.

For overall operation including installation, in addition to the 'Device Manual', users should refer to other documents such as Parameter Manual, Commands Manual, Reporting Manual and so on.

2. Overview

Main function of device installed on a vehicle is to report vehicle location and status to its monitoring server at predefined interval and to deliver command coming from the server for activating any appliance connected to the device.

2-1. Operation modes

The device works in one of the four (4) operation modes below.

- Parking(Idle) mode:
 - ✓ This mode is operational when 'Ignition' is OFF for duration longer than the pre-defined time.
 - In the parking (idle) mode, the device can get into special modes for power saving like 'Sleep mode' and 'Deep sleep mode'. These power saving modes are described in more details in the end of this document.
- Driving mode:
 - ✓ This mode starts when 'Ignition' of the vehicle is ON.
- Idle mode:
 - ✓ The speed and movement of the vehicle are not detected.
- Speeding mode:
 - ✓ Vehicle movement is detected and the vehicle speed exceeds the limited speed..

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		5 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

2-2. Reports sent by device

There are 3 types of report/response sent by device to the server as follows:

- ✓ Reports (Status / Alerts)
- ✓ Keep-alive report,

2-3. Parameter change

Parameters which have already been set on the device can be changed via LTE CAT M1/NB-IoT/BLE or via SMS or via RS232 connected with PC if a user needs to do so. Some controlling functions can also be implemented in the same way.

2-4. Features

Key features of the ST4930 device are as follows:

- Unified Protocol

- ✓ Support standard report format fixed to all models.
- ✓ Customer can select only the data they want from the data included in the report, so that they can configure their own report format.

- Multiple Modes

- ✓ Customer can set up multiple modes of operation so they can see more detailed routes as needed.
 - Each operation mode consists of PARKING/DRIVING/IDLE/SPEEDING

- PROFILE

- ✓ By introducing the concept of profile. It is possible to selectively use a preset profile for each mode.
 - Each profile consists of “Time interval, Travel distance, Travel angle” setting value.
- ✓ Detailed travel route can be confirmed.
 - Because DEVICE judges the three conditions together and reports, you can check the detailed route of the vehicle.

- Power Saving Modes (Power Down Modes)

- ✓ The device can save power consumption of the battery by using one of two modes such as Sleep Mode or Deep Sleep Mode.

- Event Lines

- ✓ Device has 1 output lines, 1 input lines and one ignition line.
Please refer to Chapter 3-1

- LED Indicators

- ✓ The LEDs indicate LTE CAT M1/NB-IoT, BLE, GPS and Charging status. It is helpful to check what error(s) and why such an error has occurred.
Please refer to Chapter 3-4

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		6 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

- Maintenance server support

- ✓ Upgrading Firmware by Over The Air (Firmware OTA)

- Checking Status of Main Power Source

Device recognizes its connectivity with the main power source (i.e. vehicle's battery) and is able to inform the server about status on whether or not the main power line is disconnected. The device is also able to inform the server about the voltage level status of the main power source and informs the server in case the voltage level of the main power source drops down below the pre-set value. This function is applicable to battery-installed device models only.

- Alerting Battery Error

Device sends an alert when a battery charging error occurs. This function is applicable only to the device models available with back-up battery.

GENERAL & GPRS SPECIFICATION

Power Supply	Li-SOCL2, 12AH Primary Lithium Battery (ST4930) Li-ion , 5900mAh Rechargeable Polymer Battery (ST4932)
Power Consumption	Operation current (Max current): 220mA Deep sleep current : less than 15uA
Battery Autonomy	Stock mode : TBD Normal mode: TBD Emergency TBD
Frequency	Cat M1 : B2/B4/B12/B66 NB-IoT : B2/B4/B66/B85
Temperature Range	-20°C ~ +80°C
Packet Switched data rate	Support 3GPP Rel. 14 Support LTE Cat M1 / NB-IoT
Dimension	113.5 x 62.28x 25 mm (ST4930)
Weight	196 g (ST4930)
Approval	CE,FCC, PTCRB,


	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		7 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

3. DETAILED DESCRIPTION ON EVENT LINES AND FEATURES

3-3. Alert of Buzzer

In a case that the Output type is set to 'Buzzer', the buzzer alerts. The following table shows such cases:

3-3-1. Related with over-speed

Condition	Alert Pulse	Meaning
Over-speed (Out = Buzzer)		When vehicle's speed exceeds the over-speed value.

3-4. Indication with Two(2) LEDs

RED LED indicates GPS status and blue LED indicates LTE CAT M1/NB-IoT/BLE status while the device is not processing call.

3-4-1. Red LED for GPS

GPS	Blink Count	Meaning
Normal	1	
No Fix	2	 <Probable Situations> 1. If power is on, GPS chipset tries to find position for some minutes. 2. If device has weak connectivity with GPS network or if it has no GPS signal position. 3. If GPS connectivity with a device is weak.
GPS Chipset Error GPS Antenna Error	4	 <Probable Situations> 1. If GPS antenna is disconnected. 2. If GPS antenna or socket of GPS antenna is broken. 3. If device is broken.

3-4-2. Blue LED for LTE CAT M1/NB-IoT/BLE

LTE CAT M1 /NB-IoT/BLE	Blink Count	Meaning
Normal	1	

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		9 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

- If communication with the server fails continuously, the device processes Deep Sleep after trying to make communications for 8 minutes.
- While the device is in deep sleep, it cannot process charging the backup battery.

Device turns off LED and sends a status report and a related alert before entering the power-down functionality.

The device terminates power down either when ignition is ON. In such cases, the device sends related alert and status string, instead.

- Sleep

Device turns off only GPS part and LTE CAT M1/NB-IoT/BLE part enters Sleep. Even for time of Sleep, all communication with the server works normally and the device can receive SMS or call always. Average of Sleep current is lower than 10mA and this current may be increased under weak LTE CAT M1/NB-IoT/BLE condition.

- Deep Sleep

Device turns off GPS and LTE CAT M1/NB-IoT part. For the time of Sleep, all communication with the server is impossible and it cannot receive any SMS messages, either. Device turns on LTE CAT M1/NB-IoT/BLE session every max. 30 minutes. However, the device cannot receive SMS or call while it is in Deep Sleep. Average current during Deep Sleep mode is around 5mA (non-battery version).

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		10 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

3-7. Motion Sensor

<About How to activate Motion Sensor>

- Ignition ON (Driving)

The sensor mode goes to collision detection mode. So, if the vehicle has a car accident, the accident may bring about a big impact of which value is higher than that of the specified collision threshold (COLL_THRES). In this case the device will be reporting a collision message to the server.

After a collision is made against the vehicle, the sensor will be disabled for a while (30 seconds) so as to avoid sending to the server the same message as the first one repeatedly.

- Ignition OFF (Parking)

'Ignition Off' situation means that the vehicle is in state of parking and that the sensor goes to 'parking mode' (shock or movement detection mode).

In this situation, if there is a shock made on the vehicle by somebody, the device will report a shock message to the server. The device will also exit from the power down mode if the device has been in power down mode.

After triggering an event such as a shock or a movement, the sensor will be disabled for a while (for 30 seconds) so as to avoid sending to the server the same message as the first one repeatedly.

<About Threshold>

- Collision Threshold

Our recommendation is 0.7 but it is only for reference value obtained from our field testing made on real vehicles (nearby gear). The value may vary in a real situation depending upon driving manner or condition of road. So, you need to check this value.

- Shock Threshold

Our recommendation is 0.04 but it is only for reference value obtained from our field testing made on real vehicles (nearby gear). Motion sensor is installed on an inside part of the vehicle's body to measure sensitivity value(s) created by vibration and shock impact given to the vehicle. Value of this sensitivity varies because it depends on what body part of the vehicle the motion sensor is installed.

Shock Threshold is also used for checking movement of vehicle. So, the device may not be able to recognize if a shock threshold value is too high. You need to consider these kinds of factors measurable under realistic environment when you also adjust the values.

State	Detection			Exit from Power down			Reporting about:		
	Motion	Shock	Collision	Motion	Shock	Collision	Motion	Shock	Collision
Parking	ON	Enable	X	Exit	Exit	Exit	X	Enable	X
Driving	OFF	OFF	Enable	X	X	X	X	X	Enable

<Notes>

- ON: Activation.
- OFF: Deactivation.
- Enable: Enable or Disable by setting.
- X: Please, do not care.

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		11 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

For setting method, please refer to "Motion Sensor Parameter Settings".

[Caution]: Basically, the device checks any motions in parking mode(Ignition Off). It does not care about the enable flags such as COLL_EN or SHOCK_EN. This means that, if the device senses any motion (movement) created in the power down mode, it will exit from the power down mode as if a creature would wake up from sleeping suddenly. So, if you want to check the power down mode to save power consumption of the backup battery, DO NOT give any impacts to the vehicle.

3-8. Protection of Vehicle Battery

For a period of duration that the vehicle has been in a parking mode for a long time by consuming vehicle's battery down to a very low level, the device starts entering the Deep Sleep Mode automatically. This situation happens because the device intends to prevent vehicle's battery from wasting power. In this case, the device alerts with ALERT_ID 14 before entering the deep sleep mode, and exits from the deep sleep mode either when ignition line goes to 'ON' or until the voltage level is increased sufficiently.

The vehicle's battery level for protection can be changed by making a Command. Refer to Voltage control parameters section.

3-9. Storage of Reports un-sent

Device has maximum storage capacity of the un-sent reports in such cases as follows:

- 3,000 reports (**),
- 1024 bytes for the response that the command has required the device to respond with as command response

Note (**):

Due to bad report-routing environment, device could not make a real-time based reporting. For example, the reporting router does neither run properly, is nor connected properly. In such a situation there might be a report which has consequently failed to arrive in the server successfully after making several attempts to send the report to the server. In that case, the device stores such a report for a while until such environment (e.g. LTE CAT M1/NB-IoT network,BLE) gets back to normal to enable the device to try to send the report to the server again.

When 'reports' start being accumulated, max 3000 reports can be hold in the buffer storage of the device. If those 'reports' are triggered out to the server, the oldest report is erased first and a new report is buffered if the buffer is completely full of those reports. And then, a new status report enters (FIFO: First In First Out as a sequential system).

Caution

FCC Part 15.19

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

	Doc. Title	Author		Page of Pages
	ST4930 OPERATION MANUAL	SK LEE		12 of 12
	Concerning	Doc. No.	Rev.	Date
	Features and How to set parameters		1.0	27 Oct 2023

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement:

[EN] FCC and IC RF Radiation Exposure Statement: This equipment complies with FCC and IC RF Radiation exposure limits set forth for an uncontrolled environment.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

[FR] RF du FCC et IC d'exposition aux radiations: Cet équipement est conforme à l'exposition de FCC et IC rayonnements RF limites établies pour un environnement non contrôlé. L'antenne pour ce transmetteur ne doit pas être même endroit avec d'autres émetteur sauf conformément à FCC et IC procédures de produits Multi-émetteur. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

REVISIONS

Rev. No.	Date	Modifications were made on:	Writer
Rev. 1.00	2023-10-27	Draft a manual	LJH

- End of the Document -