

Security of your terminal

Your device fulfils current applicable PCI PTS security requirements.

Upon receipt of your terminal you should check for signs of tampering of the equipment. It is strongly advised that these checks are performed regularly after receipt. You should check, for example: that the keypad is firmly in place; that there is no evidence of unusual wires that have been connected to any ports on your terminal or associated equipment, the chip card reader or any other part of your terminal. Such checks would provide warning of any unauthorised modifications to your terminal, and other suspicious behaviour of individuals that have access to your terminal. Your terminal detects any “tampered state”. In this state the terminal will repeatedly flash the message” Alert Irruption!” and further use of the terminal will not be possible. If you observe the “Alert Irruption!” message, you should contact the terminal helpdesk immediately.

You are strongly advised to ensure that privileged access to your terminal is only granted to staff that have been independently verified as being trustworthy. The terminal must never be put in or left at a location where it could be stolen or replaced by another device.

CAUTION: Positioning of the ISC250-V4 on check stand must be in such a way to make cardholder PIN (Personal Identification Number) spying infeasible.

NEVER ask the customer to divulge their PIN Code. Customers should be advised to ensure that they are not being overlooked when entering their PIN Code.

WARNING TO USERS IN THE UNITED STATES

Federal Communication Commission Interference Statement 47 CFR Section 15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

NO UNAUTHORIZED MODIFICATIONS

47 CFR Section 15.21

- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: This equipment may not be modified, altered, or changed in any way without signed written permission from Ingenico. Unauthorized modification may void the equipment authorization from the FCC and will void the Ingenico warranty.

ANTENNA REQUIREMENT

47 CFR Section 15.203

This device ISC250-V4 complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING TO USERS IN THE CANADA:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

SAFETY

CAUTION: risk of explosion if the battery is replaced by an incorrect type. Dispose of used battery according to the instructions

An excessive acoustic pressure of headset can involve deafness!

Only use the power supply AC/DC provided with iSC250-V4 (8VDC, 2A) or the power provided by a cash register (16 Watt min, 8V min) limited power source (LPS).

Remove the power jack to power off the terminal.

Authorized power supply units :

FRIWO (Trademark: Ingenico and FWGB)	152810
FRIWO (Trademark: Ingenico and FWGB)	153051
PHIHONG (Trademark: Ingenico)	PSC16E-080
PHIHONG (Trademark: Ingenico and PHIHONG)	PSC16A-080



ISC250-V4


Installation Guide



Equipment check list

Carefully inspect the shipping carton and its contents for shipping damage. If the device is damaged, file a claim immediately with the shipping company and notify Ingenico.

You should have :



- The box may also include the following items depending on your configuration working:
- Cable (specific to your connectivity requirements)
 - Power supply unit

Save the carton and packing material for repackaging or moving the device in the future. Connect the cable to the HOST port before connecting the device to power.

Power & Cable connections




Turn the terminal. There is one port on the back for power and communication. Connect the cable on the terminal. Connect the other end to the power supply unit. Connect the power supply unit to the mains by the wall receptacle.

Two ports at the rear side:

- audio out
- USB host

Stylus Pen Connection



Insert the stylus connector into the iSC250-V4 stylus port at the rear of the iSC250-V4.



Swiping a Magnetic Stripe Card

The iSC250-V4 device's magnetic stripe reader reads debit, credit, and all standard magnetic stripe cards.



Take care to ensure that the card is inserted in the correct manner (direction is marked on terminal). Slide the card from the rear to the front in a continuous motion for best results

Contactless Reader

Bring the card firmly up to the active zone one above the display (at about 1cm). Keep the card close to the Reader during the transaction.



Smart Card Reader (SCR)

Take care to ensure that the card is inserted in the correct manner, chip facing up (direction is marked on terminal).



Signature Handling

The iS250-V4 can capture an electronic image of a customer's signature for transactions that require a signature and transmit to a host system.



The signature area displays on the screen for transactions requiring a customer signature. Use the electronic stylus attached to the device.

Troubleshooting

Magnetic Card Reader Does Not Work Properly

1. When sliding the card through the reader, make sure that the magnetic stripe on the card is facing the iSC250-V4 display screen (see *Swiping a Magnetic Stripe Card*).
2. Swipe the card at a faster or middle steady speed.
3. Inspect the magnetic stripe on the card to make sure it is not scratched or badly worn.
4. security tag deactivation system could disturb the magnetic card reader
5. To determine if the problem is with the card:
 - a. If your host device has a magnetic stripe reader, try swiping the card there.
 - b. If you have another working iSC250-V4 device, try swiping the card there.

Device is not working

1. Make sure that the iSC250-V4 connector is fully inserted into the back of the device.
2. Restart the device.
3. If you have another working iSC250-V4 device, swap the devices to determine if the problem is with the device, cable, POS, or power supply.
4. If the iSC250-V4 device is directly connected to a host, reset the host by turning it off and back on again.

⚠ Changes or modifications to this device not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

⚠ Any liquid spill under the custom cover must be removed right away.

⚠ The main port at the back must not be used to connect a standard video HDMI cable. Only connect cables provided by Ingenico.

Environment:

This product is labelled in accordance with European Directive 2002/96/EC concerning Waste Electrical and Electronic Equipment (WEEE). Ingenico ensures that efficient collection and recycling schemes are set-up for WEEE according to the local regulation of your country. Please contact your retailers for more detailed information. Packaging waste must also be collected separately to assure a proper disposal and recycling. Please note that proper recycling of the WEEE will ensure safety of human health and environment.

Terminal Location

The iSC250-V4 device may be mounted on a flat surface, wall, or customer stand (recommended).

⚠ Do not place the iSC250-V4 device on a PC monitor, adjacent to an electronically active security tag deactivation system, or near other sources of magnetic fields.

The iSC250-V4 device must be at least 12 inches away from an electronically active type of security tag deactivation pad.

There are two types of security tag deactivation systems:

- An electronically active system sends out a powerful and potentially disruptive signal to deactivate the security tag. If the iSC250-V4 device is placed too close to the system's pad, or placed above the pad, the signature capture files may be corrupted.
- A passive system is a permanent magnet type that does not send out a signal. This type does not affect the iSC250-V4 device.

The device is designed to operate in the following environment:

- Operating temperature of 5°C to 40°C
- Operating humidity of 10% to 90% RH non-condensing

The terminal is intended for internal use only.

More Information

For more information on cleaning, troubleshooting, operating the device, features, specifications, accessories, the system menu, security, and downloading see the *Ingenico iSC250-V4 User Guide*.



The associated symbol means that WEEE must not be thrown away but collected separately and recycled