


ELECTRON

QUICK START GUIDE

Getting started

Device Layout



App Menu



Back Button



Home Button




Menu Button



History Button



Volume +/- Buttons



Basic functions


Charging / Power ON/OFF / Wi-Fi / Menu

**You can access the full user manual for more information.*

Prior to using the device, fully charge the battery. The device has a built in battery that uses only the supplied charger to charge it.

In order to prolong the service life of the product, use the device until the battery is depleted for the first two times before charging the battery again.

To charge the battery, connect one end of the charger to your wall outlet. Plug the USB cable into the charger and the other end to the device's DC jack.



Note:

When the device is not in use, be sure to turn it off to conserve the battery.

1. Press the Power button to power ON the device. To power ON the device, press and hold the Power button for a few seconds until the startup image appears on the screen.



Slide the lock icon to unlock the tablet.

2. To Power OFF the tablet, press and hold the Power button for a few seconds, then a "Power OFF" dialog box will pop up.

Select "OK" to power OFF your tablet.

3. When the tablet is already powered ON, tap the power button once to put the tablet in sleep mode.
4. When the tablet is in sleep mode, tap the Power button once to wake the tablet.

Slide the lock icon to unlock the tablet.

Basic functions

Charging / Power ON/OFF / Wi-Fi / Menu

1. Select the “Settings” icon from the Menu.



2. Slide the Wi-Fi switch to the “ON” position.



3. Select your Wi-Fi network from the list.
4. Enter the required password.
5. Once connected, the Wi-Fi connectivity icon will be shown at the bottom-right side of the Home screen.



1. **Menu**

From the Home Screen, select the apps menu icon in the top-right side of the home screen to access the app list.



2. Select the app you'd like to open.



3. Select the Back button to return to the previous screen; Select the Home button to return to the Home screen.



Personalize your device

Email / Wallpaper / Connect

1. From the Menu, select “Email”.

Email account:

Email address: _____ **Manual setup**

Password: _____ **Next**

2. Enter your Email address, password and tap “Next”.
3. Select which type of email account you are setting up and it's complete settings.

You will need to enter your user name, password, and server information depending on the type of email account, or you can change the settings by tapping “Manual Setup”. Tap “Next” and select “OK” to accept the activation.

1. Press and hold on a blank spot on the Home Screen and a menu will show up. Select from pictures in your gallery or the pre-loaded live and standard wallpapers. Once selected, tap “Set Wallpaper”.


Choose wallpaper from

 Gallery

 Live wallpapers

 Wallpapers


1. Connect the supplied USB cable from your tablet to an unused USB port on your computer.



2. Touch the "USB" icon on the top-left side on your tablet, and select "USB Connected".




3. Touch "Turn on USB storage".



4. Once connected successfully, select the "hipstreet" drive on your computer to view/edit/add/delete files on your device.



5. When finished, touch "Turn off USB storage" and disconnect the cable.



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a **Class B digital device**, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This device complies with Canadian ICES-003 and RSS-210

The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License.

CONTACT US

If you encounter any difficulties with this product, please visit our website at www.hipstreet.com and review our support section or call us. Our representatives are ready to help you with any questions about your product. We can guide you through connections, first-time use, or any of the features. Just give us a call or send us an email.

North America	1- 888-456-2426
UK	0800-051-8330
Netherlands	0800-404-0006
Germany	0800-180-7686

Monday through Friday: 8:30am – 5:00pm
Email: support@hipstreet.com

We want you to start enjoying your product right away!



hipstreet



hipstreet

North America: **1 888 456 2426**

UK: **0800 051 8330**

Netherlands: **0800 404 0006**

Germany: **0800 180 7686**