



USER MANUAL & IMPORTANT SAFETY INFORMATION



FANTASY C-RINGZ CONTROLCORE ELITE REMOTE-CONTROLLED VIBRATING COCK BLOCKER



www.pipedreamproducts.com/docs

SKU	PD5973-23
UPC	603912779158

English

ControlCore Elite

TOTAL CONTROL. ELECTRIFIED.

Product Overview

® Lock up your partner and take control of their pleasure with powerful vibration and electrifying E-Stim. Fantasy C-Ringz ControlCore Elite combines a silicone chastity cage with Core Drive vibration and Electro Pulse E-Stim. Vibration and E-Stim can be controlled independently or used together, using either the buttons on the cage or the wireless remote. Precision Fit rings and Secure Core locking provide a customized fit.

Key Features

- 10-function vibration and independent 5-function electro-stimulation
- Rechargeable cage and wireless remote with magnetic charging
- Elite Silicone cage with ventilation and urination openings
- Three interchangeable comfort rings and integrated locking system

Specifications

Total Length	4.6 in. (11.6 cm)	Total Width	1.8 in. (4.6 cm)
Internal Length	3.7 in. (9.4 cm)	Weight	0.4 lb. (160 g)
Medium Ring ID	1.8 in. (4.6 cm)	Large Ring ID	2.0 in. (5.1 cm)
Extra Large Ring ID	2.1 in. (5.5 cm)	Materials	Silicone, alloy, plastic
Charge Time	60 min.	Run Time	120 min.

Includes: (1) Control Core Elite, (1) remote control, (3) Precision Fit rings, (2) keys, (1) locking pin, and (1) charging cord.

How to Use

- **Prepare:** Clean before first use. Inspect the cage, rings, and locking parts for damage. Test locking and unlocking before fitting; keep a key immediately accessible.
- **Charge:** The supplied charge cord can charge both the cage and remote. Attach to clean, dry magnetic contacts. Charge time: 60 minutes; run time: 120 minutes. Disconnect before use. Never charge while worn or wet.
- **Travel Lock:** Press and hold both cage buttons together for 5 seconds to lock or unlock. Two buzzes/blinks confirm locked; one confirms unlocked. Charging also unlocks the device.
- **Fit & Lock:** Start with the largest ring. Choose a fit that does not pinch or restrict circulation. Attach the cage and secure the locking pin and lock in place. Avoid trapping skin or hair; never force parts.
- **Cage Operation:** Hold cage Power for 3 seconds to enter standby. From standby, press Power to cycle vibration or the bottom button to cycle E-Stim.
- **Remote Operation:** Press and hold remote Power for 3 seconds to switch on and pair with the cage. Press the top button to cycle vibration or the bottom button to cycle E-Stim. Begin with the lowest setting; increase only while comfortable.
- **Power Off & Remove:** Hold each unit's Power button for 3 seconds to switch off. Always power off the remote after use to preserve its battery. Unlock and remove gently. If you experience pain, numbness, coldness, swelling, or discoloration, stop use and remove the product immediately. If removal is impossible, seek urgent medical help.

Care & Cleaning

Switch off and disconnect charging cords. Wash the cage and rings with antibacterial cleaner and warm water; rinse and dry fully. Wipe the remote with a damp cloth. The cage is IPX6 and the remote IPX3. Do not immerse either unit or use boiling water, dishwashers, or harsh chemicals. Dry charging contacts completely before charging.

Safety Information

Remove rings within 30 minutes; wait at least 60 minutes between uses. Never sleep while wearing. Do not leave the wearer alone or restrict access to a key. Do not use E-Stim with a pacemaker or implanted electronic device. Consult a clinician before use if a medical condition affects circulation or sensation. Do not use on damaged skin or if intoxication or reduced hand strength prevents safe removal. Use water-based lubricant only; follow the product guide for E-Stim contact requirements. For consenting adults only; sold as a novelty, not for therapy. Keep out of reach of children.

Storage

Store clean, fully dry, and switched off in a cool place away from direct sunlight and extreme heat. Keep separate from other soft toys. Store the keys and locking pin safely and protect the charging contacts.

Warranty

This product includes a 1-Year Warranty. Register at pipedreamproducts.com/register

Contact

Email: CustomerService@pipedreamproducts.com
Website: www.pipedreamproducts.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

RF warning for portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.